

IsoUs – Ultimate Step G Code User Manual

www.promax.it



The contained information in this handbook are only informative and they can be changed without warning and they must not be understood as some engagement from Promax srl. Promax srl does not assume responsibility or obligations for errors or inaccuracies that can be found in this handbook. Except how much granted from the license, no part of this publication can be reproduced, saved in a recording system or transmitted in whatever form or with any means, electronic, mechanical or recording system or otherwise without Promax srl authorization.
Any reference to names of society or products have only demonstrative scope and it does not allude to some real organization.

Rev. 4.4.8 © Promax srl

1 INTRODUCTION

This manual explains ISO programming and all relative functions. The method of programming can change with the used PC model (keyboard, touch-screen), however main concept remains unchanged.

To manage ISO programs refer to **USER INTERFACE** manual.

2 ISOUS RULES

2.1 BLOCK

A block is formed by one or more ISO function ended with CR/LF character.

The sequence of more blocks composes a program (defined PartProgram) that it is managed by user interface.

All characters forming the block must be UPPER-CASE.

Isous editor makes an automatic conversion of lower-case characters.

G1X100Y100Z10

2.2 LINE NUMBER OR BLOCK NUMBER

Line number or block number defines block position inside the PROGRAM.

Such position is useful in some features (block restart, retrace, etc.).

Isous ignores line marks Nxx before block, therefore the real line number is the number showed on ISO editor window.



Isous ignores **N10** and **N30** characters, therefore the real line is showed on the left bar. 1 and 2 in this example.

2.3 PROGRAM RUNNING

Program running is made by Isous user interface. When in run, program can be PAUSED or STOPPED.

2.4 AXIS NAME

Isous don't use any particular convention to define axis type (linear or rotative) by name (X,Y, etc.). Definition must be setted only in configuration. Isous manages up to 9 axis with the following names:

X,Y,Z,A,B,C,U,V,W

2.5 HOMING

All axis refer to an HOME POSITION made after switch on. Home position follows an HOMING procedure selected by relative machine parameters.

2.6 WORK ORIGIN

Isous manages up to 256 different WORK ORIGINS. Each origin defines a reference point of zero, all following positions refers to this point. Origins can be set both manually by interface and with dedicated instructions inserted in PartProgram. Furthermore they can be SUSPENDED, RESTORED or DISABLED.

2.7 WORK OFFSET

As well origin, Isous can manage up to 256 WORK OFFSET. An OFFSET works as a new origin manageable only with PartProgram. Also OFFSETS can be SUSPENDED, RESTORED or DISABLED.

2.8 HEADS

Isous manages 256 working HEADS for a single machine.

Each head refers to machine origin and it is automatically pre-setted (do not need to use WORK ORIGIN e WORK OFFSET). Used head can be recall by PartProgram with Hn instruction. It programs automatically head offset of all axis (refered to machine origin).

2.9 MODAL FUNCTIONS

MODAL functions remains active for all current PartProgram and also the subsequent ones until a (or more) particular function disables it. G0,G1,G2,G3 etc. are modal functions and therefore it doesn't need repeat them until another function exclude it. G1 excludes G0,G2 e G3, G2 excludes G0,G1 e G3 etc.

G1X100Y100

X300Y120Z10

X450

In this example it is used modal G1 function. In block 2 and 3 it isn't necessary to insert G1 because it remains active.

2.10 RECOGNIZED CODES

Almost all recognized codes are highlighted with a colour. However, in the few cases when it doesn't happen, it doesn't mean instruction isn't recognized.

When Isous editor doesn't recognize an instruction it is underlined with RED and it shows error window.

2.11 NUMERIC VALUES SETTING

Isous works with two numeric values types:

INTEGER

FLOATING

Integer values are used for all defined quantities (Loop numbers, etc.). When it is insert a floating value instead of integer one, Isous generate an error warning the user.

Floating values are used for all REAL quantities (axis position, radius, etc.).

Isous uses as decimal separator character “.” (DOT).

2.12 PROGRAM REMARKS

Isous don't use CNC classic convention for program remarks.

Remarks starts with “//” characters and terminates with end line. Isous editor highlights it with GREEN colour.

Remarks can be insert also on the right of block.

Remarks are ignored by PartProgram and all its content are discarded.

// This is a remark

G1X100Y100 // This is a remark too

3 ISO NS INSTRUCTIONS

3.1 RECOGNIZED G CODES

Code G	Description	TASK1	TASK2
<u>G0</u>	RAPID positioning	NO	NO
<u>G0.1</u>	RAPID positioning single Axis with private Acceleration	NO	NO
<u>G1</u>	Linear Interpolation at F programmed speed	NO	NO
<u>G1.1</u>	G1-G2-G3 Suspension and set G0	NO	NO
<u>G1.2</u>	G1 Resume	NO	NO
<u>G2</u>	CW circular interpolation	NO	NO
<u>G3</u>	CCW circular interpolation	NO	NO
<u>G4</u>	Timed pause	YES	YES
<u>G4.1</u>	Time Add on Calc Time	NO	NO
<u>G10</u>	Enable external axis OVERRIDE ASSI on potentiometer	YES	YES
<u>G11</u>	Disable external axis OVERRIDE ASSI on potentiometer	YES	YES
<u>G17</u>	Set work plane on X-Y	NO	NO
<u>G18</u>	Set work plane on Z-X	NO	NO
<u>G18.1</u>	Set work plane on Z-X but not in PREVIEW	NO	NO
<u>G19</u>	Set work plane on Y-Z	NO	NO
<u>G19.1</u>	Set work plane on Y-Z but not in PREVIEW	NO	NO
<u>G20</u>	Axes in Inch	NO	NO
<u>G21</u>	Axes in millimeters	NO	NO
<u>G22</u>	Change axis of the work plane	NO	NO
<u>G23</u>	Restore axis of the work plane (disable G22)	NO	NO
<u>G24</u>	Enable horizontal mirror	NO	NO
<u>G25</u>	Disable horizontal mirror G24	NO	NO
<u>G26</u>	Change a couple of axis	NO	NO
<u>G27</u>	Suspend G26	NO	NO
<u>G28</u>	Resume G26	NO	NO
<u>G30</u>	Enable automatic insert of fillet on edges	NO	NO
<u>G31</u>	Suspend G30	NO	NO
<u>G32</u>	Resume G30	NO	NO
<u>G33</u>	Enable automatic insert of bevel on edges	NO	NO
<u>G34</u>	Suspend G33	NO	NO
<u>G35</u>	Resume G33	NO	NO
<u>G36</u>	Gestione assi rotativi	NO	NO
<u>G40</u>	Disable TOOL RADIUS compensation	NO	NO
<u>G41</u>	Enable TOOL RADIUS compensation LEFT	NO	NO

<u>G42</u>	Enable TOOL RADIUS compensation RIGHT	NO	NO
<u>G43</u>	Enable TOOL LENGTH compensation	NO	NO
<u>G44</u>	Disable TOOL LENGTH compensation	NO	NO
<u>G44.1</u>	Suspend G43	NO	NO
<u>G44.2</u>	Resume G43	NO	NO
<u>G45</u>	Enable TOOL LENGTH compensation, parameter from TOOL TABLE	NO	NO
<u>G46</u>	Disable G45	NO	NO
<u>G47</u>	Set mode of start/stop TOOL compensation G41 G42	NO	NO
<u>G48</u>	Define Depth Axis	NO	NO
<u>G49</u>	MILD MODE – Edge Smoothing	NO	NO
<u>G50</u>	Working plane rotation	NO	NO
<u>G51</u>	Suspend plane rotation G50	NO	NO
<u>G52</u>	Restore plane rotation G50	NO	NO
<u>G53</u>	As G98 (for compatibility to other cn)	NO	NO
<u>G54</u> <u>G54.n</u>	Work origin from memory, AXIS X (or axis selected by following parameters XYZ etc	NO	NO
<u>G55</u>	Work origin from memory, AXIS Y	NO	NO
<u>G56</u>	Work origin from memory, AXIS Z	NO	NO
<u>G57</u>	Work origin from memory, AXIS XY	NO	NO
<u>G58</u>	Work origin from memory, AXIS YZ	NO	NO
<u>G59</u>	Work origin from memory, AXIS XZ	NO	NO
<u>G60</u>	Enable FAST interpolation without stop on segments	NO	NO
<u>G61</u>	Enable interpolation with stop on segments	NO	NO
<u>G62</u>	Wait stop axis	NO	NO
<u>G63</u>	G1 Enable PX_MOVETO (3D interpolation outside selected plane) without stop	NO	NO
<u>G64</u>	G1 Enable interpolation on selected plane PX_LINETO (2D plane interpolation	NO	NO
<u>G65</u>	Enable 3D interpolation PX_MOVETO with calculated stop on edge by parameters	NO	NO
<u>G66</u>	AFC – Adaptive Feed Control	NO	NO
<u>G66 X-100</u>	NEW AFC – Adaptive Feed Control	NO	NO
<u>G67</u>	PX_MOVETO for movement outside plane and PX_LINETO for inside ones	NO	NO
<u>G68</u>	Always using of PX_LINETO in G1 “TRANSPORTED AXIS”	NO	NO
<u>G69</u>	LHK – Depth of buffer Look Ahead on virtual CN	NO	NO
<u>G70</u>	Set work plane on a generic couple of axis	NO	NO
<u>G71</u> <u>G71.1</u> <u>G71.2</u>	Start axis home searching Enable Axis Disable Axis	NO	NO
<u>G72</u>	Enable N.U.R.B.S (Not Uniform Rational BSpline) filter	NO	NO
<u>G73</u>	Enable Noise filter	NO	NO
<u>G74</u>	Enable RLS (Remove Len Segment) filter	NO	NO

<u>G75</u>	Use G64 for movement inside work plane and G65 for movement outside work plane	NO	NO
<u>G80 (G1080)</u>	Forced pause by code	YES	YES
<u>G81 (G1081)</u>	Management secondary axes LIMITS	YES	YES
<u>G82 (G1082)</u>	Work ORIGIN at current position with sensor offset	NO	NO
<u>G83 (G1083)</u>	Update CPU1 counter	NO	NO
<u>G84 (G1084)</u>	Preset CPU axis	NO	NO
<u>G85</u>	Work OFFSET at current position with sensor offset	NO	NO
<u>G86</u>	Hardware preset axis on module 360 degrees	NO	NO
<u>G87</u>	Suspend head offset selected with Hn	NO	NO
<u>G88</u>	Resume head offset selected with Hn	NO	NO
<u>G89</u>	HardWare Preset of axis position	NO	NO
<u>G90</u>	Values with ABSOLUTE position	NO	NO
<u>G91</u>	Values with INCREMENTAL position		
<u>G91.1</u>	Force the values in ABSOLUTE (G90) and store the current state (G90-G91)	NO	NO
<u>G91.2</u>	Resume the state stored with G91.1 (G90 if was G90 or G91 if was G91)		
<u>G92</u>	Work ORIGIN at current position	NO	NO
<u>G93</u>	Work OFFSET at selected position	NO	NO
<u>G94</u>	Work ORIGIN at selected position	NO	NO
<u>G95</u>	Work OFFSET at current position	NO	NO
<u>G96</u>	Suspend work offset G93-G95	NO	NO
<u>G97</u>	Resume work offset G92-G94	NO	NO
<u>G98</u>	Suspend work origin G92-G94	NO	NO
<u>G99</u>	Resume work origin G92-G94	NO	NO
<u>G100</u>	Synchronous comand for VIRTUAL axis	NO	NO
<u>G101</u>	AXIS STOP comand	YES	YES
<u>G102</u>	Start sensor acquisition	NO	NO
<u>G103</u>	Set RTCP parameters	NO	NO
<u>G104</u>	Enable RTCP	NO	NO
<u>G105</u>	Suspend RTCP	NO	NO
<u>G106</u>	Smoothing Filter	NO	NO
<u>G107</u>	Management Interrupt Macro	NO	NO
<u>G108</u>	Management Special Axes	NO	NO
<u>G120</u>	Enable vertical mirror	NO	NO
<u>G121</u>	Disable vertical mirror G20	NO	NO
<u>G940</u>	MOVE axes excluding WORK ORIGIN only in the actual block	NO	NO
<u>G1028 (G28)</u>	Return to Home	NO	NO
<u>G1050</u>	Disable Scaling	NO	NO
<u>G1051</u>	Enable Scaling	NO	NO

<u>G1080 (G80)</u>	Drilling	NO	NO
<u>G1081 (G81)</u>	Drilling	NO	NO
<u>G1082 (G82)</u>	Drilling	NO	NO
<u>G1083 (G83)</u>	DRILLING	NO	NO
<u>G1084 (G84)</u>	TAPPING	NO	NO

4 OTHERS RECOGNIZED CODES

Code	Description	TASK1	TASK2
<u>X</u>	Axis X position	NO	NO
<u>Y</u>	Axis Y position	NO	NO
<u>Z</u>	Axis Z position	NO	NO
<u>A</u>	Axis A position	NO	NO
<u>B</u>	Axis B position	NO	NO
<u>C</u>	Axis C position	NO	NO
<u>U</u>	Axis U position	NO	NO
<u>V</u>	Axis V position	NO	NO
<u>W</u>	Axis W position	NO	NO
<u>QX</u>	Channel 0 position	NO	NO
<u>QY</u>	Channel 1 position	NO	NO
<u>QZ</u>	Channel 2 position	NO	NO
<u>QA</u>	Channel 3 position	NO	NO
<u>QB</u>	Channel 4 position	NO	NO
<u>QC</u>	Channel 5 position	NO	NO
<u>QU</u>	Channel 6 position	NO	NO
<u>QV</u>	Channel 7 position	NO	NO
<u>QW</u>	Channel 8 position	NO	NO
<u>DX</u>	Axis X relative position	NO	NO
<u>DY</u>	Axis Y relative position	NO	NO
<u>DZ</u>	Axis Z relative position	NO	NO
<u>DA</u>	Axis A relative position	NO	NO
<u>DB</u>	Axis B relative position	NO	NO
<u>DC</u>	Axis C relative position	NO	NO
<u>DU</u>	Axis U relative position	NO	NO
<u>DV</u>	Axis W relative position	NO	NO
<u>DW</u>	Axis W relative position	NO	NO
<u>OX</u>	Set Origin number for axis X	NO	NO
<u>OY</u>	Set Origin number for axis Y	NO	NO

<u>OZ</u>	Set Origin number for axis Z	NO	NO
<u>OA</u>	Set Origin number for axis A	NO	NO
<u>OB</u>	Set Origin number for axis B	NO	NO
<u>OC</u>	Set Origin number for axis C	NO	NO
<u>OU</u>	Set Origin number for axis U	NO	NO
<u>OV</u>	Set Origin number for axis V	NO	NO
<u>OW</u>	Set Origin number for axis W	NO	NO
<u>DOX</u>	Origin Ofset fo axis X	NO	NO
<u>DOY</u>	Origin Ofset fo axis Y	NO	NO
<u>DOZ</u>	Origin Ofset fo axis Z	NO	NO
<u>DOA</u>	Origin Ofset fo axis A	NO	NO
<u>DOB</u>	Origin Ofset fo axis B	NO	NO
<u>DOC</u>	Origin Ofset fo axis C	NO	NO
<u>DOU</u>	Origin Ofset fo axis U	NO	NO
<u>DOV</u>	Origin Ofset fo axis V	NO	NO
<u>DOW</u>	Origin Ofset fo axis W	NO	NO
<u>F</u>	Axis FEED	NO	NO
<u>S</u>	Spinale speed	YES	YES
<u>N</u>	Line number (optional)	NO	NO
<u>D</u>	Tool diameter	NO	NO
<u>M</u>	M function	YES	YES
<u>HM</u>	HM function	YES	YES
<u>H</u>	Select head	NO	NO
<u>T</u>	Select tool	NO	NO
<u>I</u>	CENTER X coordinate for G2 G3	NO	NO
<u>J</u>	CENTER Y coordinate for G2 G3	NO	NO
<u>K</u>	CENTER Z coordinate for G2 G3 (optional)	NO	NO
<u>R</u>	Radius for G2 G3	NO	NO
<u>USER_ZERO</u>	Index of WORK ORIGIN LIST	NO	NO
<u>USER_OFFSET</u>	Index of WORK OFFSET LIST	NO	NO
<u>STOP_MODE</u>	Defines the STOP Button function mode	NO	NO
<u>PAUSE_MODE</u>	Defines the Pause function mode	NO	NO

4.1 PROGRAM FLOW INSTRUCTIONS

Code	Description	TASK1	TASK2
<u>IF</u>	Start IF cycle	YES	YES
<u>ELSE</u>	Relative to IF cycle	YES	YES
<u>END_IF</u>	End IF cycle	YES	YES
<u>LOOP</u>	Start LOOP cycle	YES	YES
<u>END_LOOP</u>	End LOOP cycle	YES	YES
<u>GOTO</u>	Jump to LABEL or line number	YES	YES
<u>GOSUB</u>	Call of Soubrutine	YES	YES
<u>RETURN</u>	Retrun from Soubrutine	YES	YES
<u>@</u>	LABEL definition	YES	YES
<u>//</u>	Start remarks	YES	YES
<u>END_PROGRAM</u>	End of program	YES	YES
<u>WAIT_INPUT</u>	Wait of digital input with Time Out	YES	YES
<u>ERROR</u>	Force stop program with error	YES	YES

4.2 MULTI TASK INSTRUCTIONS

Code	Description	TASK1	TASK2
<u>TASK.RUN</u>	Run TASK	YES	YES
<u>TASK.STOP</u>	Stop TASK	YES	YES
<u>TASK.PAUSE</u>	Pause TASK	YES	YES
<u>TASK.READVAR</u>	Read Variable from TASK	YES	YES
<u>TASK.WRITEVAR</u>	Write variable to TASK	YES	YES
<u>TASK.STATUS</u>	Read status TASK	YES	YES
<u>TASK.LOADCMD</u>	Load CMD in the TASK	YES	YES
<u>TASK.PRIORITY</u>	Set priority TASK	YES	YES
<u>USTASK</u>	Start Gcode Section for TASK1	NO	NO
<u>ENDUSTASK</u>	End Gcode section for TASK1	NO	NO

4.3 GENERIC INSTRUCTIONS

Code	Description	TASK1	TASK2
<u>SDO_DL</u>	Sdo download (can open)	YES	YES
<u>SDO_UL</u>	Sdo upload (can open)	YES	YES
<u>GET</u>	Read parameter of HM function	YES	YES
<u>READ_PARMAC</u>	Read machine parameter	YES	YES
<u>WRITE_PARMAC</u>	Write machine parameter	YES	YES
<u>LOAD_VAR</u>	Load a file of variable	YES	YES
<u>GET_VAR</u>	Read a variable from loaded file	YES	YES
<u>WRITE_VAR</u>	Wrtie a variable in memory list	YES	YES
<u>SAVE_VAR</u>	Save a file of variable on harddisk	YES	YES
<u>DIM_VAR</u>	Set dimension of memory list	YES	YES
<u>FILE_EXISTS</u>	Check if file exists	YES	YES
<u>REMOVE_VAR</u>	Remove a value from current list	YES	YES
<u>CLEAR_VAR</u>	Remove ALL values from current list	YES	YES
<u>OPT</u>	Compiler option	YES	YES
<u>IMPORT</u>	Import external file	NO	NO
<u>END_IMPORT</u>	End of Import program	NO	NO
<u>PA(n,par)</u>	Set ABSOLUTE target positioner	YES	YES
<u>PD(n,par)</u>	Set REALTIVE target positioner	YES	YES
<u>PF(n)</u>	Set FEED positioner	YES	YES
<u>PS(n)</u>	STOP positioner	YES	YES
<u>PM(n,par)</u>	STATUS positioner	YES	YES
<u>RESUME_T</u>	Resume the PartProgram from last instruction Tn used	NO	NO
<u>DIM</u>	ARRAY management	YES	YES
<u>DEBUG_INFO</u>	Write informations in Log file	YES	YES
<u>SAVE_T</u>	Save the tools table in the Isous cfg	YES	YES

4.4 MATH AND LOGICAL OPERATORS

Code	Description	TASK1	TASK2
<code>+</code>	Addiction	YES	YES
<code>-</code>	Subtraction	YES	YES
<code>*</code>	Multiplication	YES	YES
<code>/</code>	Division	YES	YES
<code>(</code>	Open bracket	YES	YES
<code>)</code>	Cosed bracket	YES	YES
<code>[</code>	Start expresion for axis count ex: G1X[\$var+\$var1]	YES	YES
<code>]</code>	End expresion for axis count ex: G1X[\$var+\$var1]	YES	YES
<code>^</code>	POW	YES	YES
<code>%</code>	XOR	YES	YES
<code>></code>	Greater	YES	YES
<code><</code>	Less	YES	YES
<code>>=</code>	Greater or equal	YES	YES
<code><=</code>	Less or equal	YES	YES
<code><></code>	Not equal	YES	YES
<code>=</code>	Equal	YES	YES
<code> </code>	Logic Or	YES	YES
<code>&&</code>	Logic And	YES	YES
<code> </code>	Or Bit	YES	YES
<code>&</code>	And Bit	YES	YES
<code>!</code>	Negate	YES	YES
<code>~</code>	Not Bit	YES	YES
<code>>></code>	Shift bit right	YES	YES
<code><<</code>	Shift bit left	YES	YES

4.5 MATH FUNCTIONS

Code	Description	TASK1	TASK2
<u>SIN</u>	Sinus	YES	YES
<u>COS</u>	Cosinus	YES	YES
<u>LOG</u>	Logarithm	YES	YES
<u>EXP</u>	Exponetial	YES	YES
<u>SQR</u>	Square root	YES	YES
<u>TAN</u>	Tangent	YES	YES
<u>ATAN</u>	Arctangent	YES	YES
<u>ASIN</u>	Arcsinus	YES	YES
<u>ACOS</u>	Arccos	YES	YES
<u>INT</u>	Integer part of float rounded	YES	YES
<u>FIX</u>	Integer part of float whitout rounded	YES	YES
<u>ABS</u>	Absolute value	YES	YES
<u>DRG</u>	Set degrees for COS,SIN,TAN,ACOS,ASIN,ATAN	YES	YES
<u>RAD</u>	Set radians for COS,SIN,TAN,ACOS,ASIN,ATAN	YES	YES

4.6 VARIABLES and CONSTANTS

Code	Description	TASK1	TASK2
<u>NUMBER</u>	Numeric constant ex: 432.12	YES	YES
<u>\$VARNAME</u>	Generic double value ex: \$VAR1	YES	YES
<u>\$[Qn]</u>	Demand axis position ex: \$[Q0] - \$[Q100]	YES	YES
<u>\$[Rn]</u>	Actual axis position ex: \$[R0] - \$[R100]	YES	YES
<u>\$[In]</u>	Digital input ex: \$[I10]	YES	YES
<u>\$[On]</u>	Digital output ex: \$[O10]	YES	YES
<u>\$[Tn]</u>	TIMER ex: \$[T3]	YES	YES
<u>\$[Un]</u>	Tool parameter ex: \$[U12]	YES	YES
<u>\$[Cn]</u>	Axis counter ex: \$[CO]	YES	YES
<u>\$[Hn]</u>	Head parameter ex: \$[H1]	YES	YES
<u>\$[Xn]</u>	Special parameters Variables ex: \$[X1]	YES	YES
<u>\$[Yn]</u>	Work origin position ex: \$[YO]	YES	YES
<u>\$[Wn]</u>	Work offset position ex: \$[W0]	YES	YES
<u>\$[Kn]</u>	User generic on CN	YES	YES
<u>\$[En]</u>	Positive Software limit axis set	YES	YES
<u>\$[Pn]</u>	Preview Parameters	YES	YES
<u>\$[Sn]</u>	Negative Software limit axis set	YES	YES
<u>\$[AO]</u>	Write Analog Out for SPINDLE	YES	YES
<u>\$[Jn]</u>	Macro Management	YES	YES

4.7 PREDEFINED VARIABLES

Code	Description	TASK1	TASK2
<u>\$ PARM_1</u>	Parameter 1 for M function	YES	YES
<u>\$ PARM_2</u>	Parameter 2 for M function	YES	YES
<u>\$ PARM_3</u>	Parameter 3 for M function	YES	YES
<u>\$ PARM_4</u>	Parameter 4 for M function	YES	YES
<u>\$ PARM_5</u>	Parameter 5 for M function	YES	YES

4.8 NsForms INSTRUCTIONS

Code	Description	TASK1	TASK2
<u>LIB.MESSAGE</u>	Show Message Box	NO	NO
<u>LIB.SHOWFORM</u>	Show NsForm	NO	NO
<u>LIB.CLOSEFORM</u>	Close NsForm	NO	NO
<u>LIB.FORMPROP</u>	Set Property NsForm	NO	NO
<u>LIB.FORMTEXT</u>	Set Caption NsForm	NO	NO
<u>LIB.ADDLABEL</u>	Add a NsLabel to NsForm	NO	NO
<u>LIB.LABELPROP</u>	Set NsLabel Property	NO	NO
<u>LIB.LABELTEXT</u>	Set Text NsLabel	NO	NO
<u>LIB.LABELPRINT</u>	Print Isous Variable to NsLabel	NO	NO
<u>LIB.ADDBUTTON</u>	Add a NsButton to NsForm	NO	NO
<u>LIB.BUTTONPROP</u>	Set NsButtonProperty	NO	NO
<u>LIB.BUTTONTEXT</u>	Set Text NsButton	NO	NO
<u>LIB.BUTTONPRINT</u>	Print Isous Variable to NsButton	NO	NO
<u>LIB.ADDINPUT</u>	Add a NsInput Object to NsForm	NO	NO
<u>LIB.INPUTPROP</u>	Set NsInput Property	NO	NO
<u>LIB.INPUTSETVALUE</u>	Set NsInput Value from Isous Variable	NO	NO

4.9 Compilator Switch and Directive

Code	Description	TASK1	TASK2
<u>IFDEF</u>	Compilator Switch IF	YES	YES
<u>ELSEDEF</u>	Compilator Switch ELSE	YES	YES
<u>ENDIFDEF</u>	Compilator Switch ENDIF	YES	YES
<u>NOAXESREADY</u>	Compilator directive Axes not Ready	YES	YES
<u>ONERROR</u>	Compilator directive On Error	YES	YES
<u>ONSTOP</u>	Compilator directive On Stop	YES	YES
<u>ENDON</u>	Compilator directive End On	YES	YES
<u>USET</u>	Compilator directive Use T	YES	YES
<u>USEH</u>	Compilator directive Use H	YES	YES

4.10 INSTRUCTIONS for remote controls

Code	Description	TASK1	TASK2
<u>REMOTE LOAD</u>	Load Gcode in Remote CN	YES	YES
<u>REMOTE RUN</u>	Run Gcode in Remote CN	YES	YES
<u>REMOTE STOP</u>	Stop Gcode in Remote CN	YES	YES
<u>REMOTE PAUSE</u>	Pausa Gcode in Remote CN	YES	YES
<u>REMOTE STATUS</u>	Read Status Gcode in Remote CN	YES	YES
<u>REMOTE MOVE</u>	Read Axes Mov in Remote CN	YES	YES
<u>REMOTE INFO</u>	Read Info in Remote CN	YES	YES
<u>REMOTE AXIS</u>	Read Axis value in Remote CN	YES	YES
<u>REMOTE GROUP</u>	Read Axes Values in Remote CN	YES	YES
<u>REMOTE READISOVAR</u> <u>REMOTE READVARNAME</u>	Read Gcode Variable in Remote CN	YES	YES
<u>REMOTE WRITEISOVAR</u> <u>REMOTE WRITEVARNAME</u>	Write Gcode Variable in Remote CN	YES	YES
<u>REMOTE READCNVAR</u>	Read User Generic variable in Remote CN	YES	YES
<u>REMOTE WRITECNVAR</u>	Write User Generic variable in Remote CN	YES	YES
<u>REMOTE READINPUT</u>	Read Digital Input in Remote CN	YES	YES
<u>REMOTE READOUT</u>	Load Gcode in Remote CN	YES	YES
<u>REMOTE WRITEOUT</u>	Run Gcode in Remote CN	YES	YES

4.11 INSTRUCTIONS for Multi Process Control

Code	Description	TASK1	TASK2
<u>CNC.LOAD</u>	Load Part Program On CN Process	YES	YES
<u>CNC.RUN</u>	Run Part Program On CN Process	YES	YES
<u>CNC.PREVIEW</u>	Preview Part Program On CN Process	YES	YES
<u>CNC.STOP</u>	Stop Part Program On CN Process	YES	YES
<u>CNC.PAUSE</u>	Pause Part Program On CN Process	YES	YES
<u>CNC.STATUS</u>	Read Status On CN Process	YES	YES
<u>CNC.STATUSBIT</u>	Read Status bit On CN Process	YES	YES
<u>CNC.INFO</u>	Read Informations On CN Process	YES	YES
<u>CNC.AXIS</u>	Read Axes Values On CN Process	YES	YES
<u>CNC.GROUP</u>	Read Group Axes Values On CN Process	YES	YES
<u>CNC.READVARADDR</u> <u>CNC.READVARNAME</u>	Read Gcode Variable On CN Process	YES	YES
<u>CNC.WRITEVARADDR</u> <u>CNC.WRITEVARNAME</u>	Write Read Gcode Variable On CN Process	YES	YES
<u>CNC.READPARMAC</u>	Read Machine Parameter On CN Process	YES	YES
<u>CNC.WRITEPARMAC</u>	Write Machine Parameter On CN Process	YES	YES
<u>CNC.ENABLEAXIS</u>	Enable Axis On CN Process	YES	YES
<u>CNC.HOMEAXIS</u>	Homing Axis On CN Process	YES	YES
<u>CNC.READGENERIC</u>	Read Generic Variable On CN Process	YES	YES
<u>CNC.WRITEGENERIC</u>	Write Generic Variable On CN Process	YES	YES

5 PROGRAM FLOW

Isous allows programming with an extension of standard ISO code. The adding instruction to control the program flow are BASIC style increasing programming performance. Therefore it's possible to manage conditional cycles, iterative cycles, jumps to labels, etc.

5.1 IF-ELSE-END_IF

It allows conditional execution of an instructions block depending of the result of expression. IF cycles can be nested without limits.

Syntax

```
IF condition
    [instr. true]
ELSE
    [instr. false]
END_IF
```

condition Mandatory. Any numeric expression with a result of True or False.

Instr. true Instructions block executed if condition is TRUE

Instr. false Optional. Instructions block executed if condition is FALSE

END_IF End of **IF ELSE** cycle

Ex:

```
IF $VAR=$VAR2*15+($VAR4+18)
    $VAR1=10
    G1X10Y20
ELSE
    $VAR1=0
    G1X0Y0
END_IF
```

5.2 LOOP - END_LOOP

Iterative cycle of the program. Instructions inside LOOP END_LOOP cycle are executed a number of time depended of expression result. LOOP cycles can be nested without limits.

Syntax

```
LOOP variable K
    [instructions]
END_LOOP
```

variable Mandatory. Any variable type \$name or numeric value

K Optional – If it is insert, in preview only one time (LOOP 100 K)

Instructions Instructions block executed in each cycle

END_LOOP End of **LOOP** cycle

Ex:

```
G91
$VAR=20+($VAR1*5)
LOOP $VAR
    G1X1.3Y1.2
    IF $VAR1=20
        GOTO EXIT_LOOP // FORCED EXIT FROM LOOP
    END_IF
END_LOOP
@EXIT_LOOP
```

5.3 GOTO

Unconditional jump to a label or line number identified by Nxx

Syntax

GOTO labelname
GOTO @linenumber

labelname Mandatory. A label of program defined with @labelname

@linenumber Line number identified by Nxx. if LineNumber = -1 restart the Partprogram

Ex:

```
IF $VAR1=0
    GOTO CYCLE_A
END_IF
IF $VAR1=1
    GOTO @100 // GOTO @-1 JUMP TO BEGIN
END_IF
// EXECUTE CYCLE A
@ CYCLE_A
G1X100Y100
.....
.....
// EXECUTE CYCLE B
N100G1X10Y10
```

5.4 GOSUB – RETURN

Jump to and return from a subroutine defined by a label.

Syntax

GOSUB labelname
GOSUB @linenumber

labelname Mandatory. A label of program defined with @labelname

@linenumber Line number identified by Nxx

it is mandatory that an instructions block which start with label, must to end with a RETURN

Ex:

```
IF $VAR1=0
    GOSUB CYCLE_A
END_IF
IF $VAR1=1
    GOSUB @100
END_IF
// EXECUTE CYCLE A
@ CYCLE_A
G1X100Y100
RETURN
// EXECUTE CYCLE B
N100G1X10Y10
RETURN
```

5.5 LABEL

A LABEL defines a jump point that can be used with GOTO and GOSUB. It isn't possible to have two or more LABEL with the same name, because it can cause a system conflict.

LABELs are exclusive for every PART PROGRAM, therefore ISOUS defines as private the LABELs that will be found in M or HM functions, so they don't have any effect in the PART PROGRAM.

It's a good thing to have LABEL with relevant names.

Syntax

`@labelname`

<code>@</code>	Mandatory. Identifier of LABEL
<code>labelname</code>	Mandatory. Unique name of the label All characters excluded math and logic operator are allowed

Ex:

```
@ CYCLE_A
G1X100Y100
```

.....

```
.....
```

```
@ CYCLE_B
G1X10Y10
```

5.6 END_PROGRAM

It forces an end of program. ISOUS inserts automatically this instruction at end of program list (end of file). However in some cases it can be necessary to end program in a particular point other than end of file.

Syntax

`END_PROGRAM`

Ex:

```
IF $VAR1=0
    END_PROGRAM // END PROGRAM IN PREMATURE MODE
END_IF
```

5.7 WAIT_INPUT

It waits a digital input for a programmed time. If time elapses without input being active it is possible to stop the program reporting an ALARM.

Syntax

`WAIT_INPUT input state time alarm`

<code>input</code>	Mandatory. Digital input number from 0 to 255
<code>state</code>	Mandatory. Logic state of input to continue the program (0 = OFF state, 1 = ON state)
<code>time</code>	Time in sec. (0.1 resolution). If time elapses it's possible to signal an alarm stopping the PartProgram <code>TIME=0 infinite wait</code>
<code>alarm</code>	Generated alarm code (refer to configuration file) 0 = No alarm generated

Ex:

```
WAIT_INPUT 2 1 5.3 12 // Wait input 2 at logic state ON for 5.3 sec. and
signal alarm 12 if condition is not happen //
```

5.8 ERROR

It cause an exit from PartProgram reporting an error. This instruction is useful to generate exceptions of PartProgram at events occurrences. Execution is stopped with an alarm.

Syntax

ERROR err_code

err_code Mandatory. Error code (refer to configuration file).

Ex:

```
IF $VAR1=0
    ERROR 10      // STOP PARTPROGRAM WITH ALLARM 10
END_IF
```

5.9 RESUME_T

Resumes the part program from the last statement used Tn.

It is used for tool management Damaged. In practice, when the measurement tool detects that the tool is damaged, through **RESUME_T** you can redo the work from last tool change made.

The parameter that follows **RESUME_T** is the tool alternative to that Damaged. This parameter is taken from the table tools.

Syntax

RESUME_T Tool_nr

Tool_nr Alternative Tool Number

5.10 SAVE_T

Saves the tools table in Isous cfg file.

With PartProgram is possible modify the tools table value. **SAVE_T** saves in permanent mode the modify.

Syntax

SAVE_T

```
T1 // SELECTED T1
$[U0]=10 // WRITE TOOL DIAMETER INDEX TABLE 0
$[U1]=100.3 // WRITE TOOL LENGTH INDEX TABLE 1
SAVE_T // SAVE THE TOOLS TABLE
```

6 GENERIC INSTRUCTIONS

6.1 SDO_DL

CanOpen SDO Down-Load function (refer to CanOpen documentation).
Write data in a CanOpen node.

Syntax

SDO_DL node index subindex len_data \$var

node	Mandatory. CanOpen node
index	Mandatory. Object index
subindex	Mandatory. Object sub-index
len_data	Mandatory. Length of datas inside \$Var (1 char – 2 int – 4 long)
\$Var	Mandatory. Variable containing data.

Ex:

```
// SEND TO NODE 2 AT INDEX 24596 AND SUBIND. 0
// 4 BYTE FROM VARIABLE $VAR1
SDO_DL 2 24596 0 4 $VAR1
```

6.2 SDO_UL

CanOpen SDO Up-Load function (refer to CanOpen documentation).
Read data in a CanOpen node.

Syntax

SDO_UL node index subindex len_data \$var

node	Mandatory. CanOpen node
index	Mandatory. Object index
subindex	Mandatory. Object sub-index
len_data	Mandatory. Length of datas inside \$Var (1 char – 2 int – 4 long)
\$Var	Mandatory. Variable where data will be write

Ex:

```
// READ FROM NODE 2 AT INDEX 24596 AND SUBIND. 0
// 4 BYTE WRITED IN VARAIBLE $VAR1
SDO_UL 2 24596 0 4 $VAR1
```

6.3 GET

Read parameter for HM function

ATTENTION: PARAMETERS ARE IN REVERSE ORDER COMPARED TO HOW THEY WERE WRITED

Ex:

```
HM 10 20 30 40
..
GET $PAR1 $PAR2 $PAR3 $PAR4 // READ PARAMETERS
then
$PAR1=40 $PAR2=30 $PAR3=20 $PAR4=10
```


6.4 READ_PARMAC

Read a machine parameter with name indication.

Syntax

READ_PARMAC "parname" \$var

parname Mandatory. Parameter name to read (ex: VJOG_X)

\$Var Mandatory. Variable where parameter value will be write

A runtime error will be generated if "parname" doesn't exist

ATTENTION: The name of parameter must be inside "..."

Ex:

READ_PARMAC "VJOG_X" \$VAR1

6.5 WRITE_PARMAC

Write a machine parameter with name indication.

Syntax

WRITE_PARMAC "parname" \$var

parname Mandatory. Parameter name to read (ex: VJOG_X)

\$Var Mandatory. Variable containing value to be write

A runtime error will be generated if "parname" doesn't exist

ATTENTION: The name of parameter must be inside "..."

ATTENTION: write of parameters can be cause system errors if execute inappropriately

Ex:

\$VAR1=100

WRITE_PARMAC "VJOG_X" \$VAR1

6.6 OPT

Set the option of compiler for M functions.

Change the function M for actual PartProgram

Syntax

OPT Options Value

Options Options:

MSTOP,MSTART,MEND,MGOBLOCK,MGORETRACE,MERROR,MPAUSE,MGOPAUSE

Value New value for M functions

EX:

OPT MSTOP 10 //M STOP = 10 for actual PartProgram

OPT MERROR -1 //Disable M error for actual PartProgram

6.7 PAUSE_MODE

Defines the way in which CNC must act PAUSE.

The modes are as follows:

- 0** Normal Mode(Pause Enabled,M Pause Enabled,M Resume Pause Enabled)
- 1** Pause Enabled, M Pause Enabled, **M Resume Pause Disabled**
- 2** Pause Enabled, **M pause Disabled**, M Resume Pause Enabled
- 3** Pause Enabled, **M pause Disabled**, **M Resume Pause Disabled**
- 4** **PAUSE DISABLED ON CNC**

Syntax

PAUSE_MODE val

Val Value or expression

Pause_Mode used to disable or limit the functionality of the PAUSE cycles during some special work: Ex: TOOL CHANGE etc..

6.8 IMPORT

Import an external file with various formats.

The predefined format is ISOUS. If present **NsImportFile.dll** file, this defines the import format.

Syntax

IMPORT “filename.ext”

filename It contains the absolute or relative file path.

If **FileName** initiates with \$APPATH,, the file is searched in the folder ISOUS

Import generates the events StartImport and EndImport when the file terminated execution

The MAIN part program resume execution when Import File is terminated.

import multiple files can be nested .

Ex:

IMPORT “\$APPATH\PROJECT\IMPORT\TESTIMPORT.ISO” // Import from Isous folder

IMPORT “C:\FILEIMPORT\TESTIMPORT.ISO” // import from absolute path

6.9 END_IMPORT

Terminate in anticipated mode a program called from function IMPORT and return to back program calling

Syntax

END_IMPORT

Ex:

IF \$VAR=0

END_IMPORT

END_IF

6.10 STOP_MODE

Defines the buttons STOP function

The modes are as follows:

- 0** Normal Mode
- 1** The STOP is disabled when the MACRO STOP is in EXECUTION
This allows to don't INTERRUPT NEVER the MACRO STOP
- 2** Interrupt the MACRO STOP with TWO PRESSIONS of BUTTON STOP
This allows to INTERRUPT the MACRO STOP, but must be press 2 times the button STOP

Syntax

STOP_MODE val

Val Value or expression

6.11 DEBUG_INFO

Write informations in the IsoUs_x.log file for Debug

Syntax

DEBUG_INFO "TextInfo" \$var

TextInfo Mandatory. Text of Informations

\$Var Mandatory. Variable of Debug can contain more informations.

The variable is printed after the TextInfo

UsDebug --> TextInfo : \$Var

ATTENTION: TextInfo must be inside “...”

\$VAR1=1

DEBUG_INFO "TEST DEBUG INFO" \$VAR1

7 INSTRUCTIONS FOR MANAGEMENT DISPLAY REMOTE HANDWHEEL WHC

7.1 LIB.HMESSAGE

Show text on display Remote HandWheel Promax WHC.

The WHC display has 4 ROW x 20 COL

Syntax

LIB.HMESSAGE “TEXT” DURATION_TIME

TEXT → Text of message

Special characters:

@RCC

WHERE R=Row Number (from 0 to 3)

CC=Col Number (from 0 to 19) the Col Number must have always 2 characters)

Ex: LIB.HMESSAGE “@105TEEXT” 5 Write on Row 1 Col 5

DURATION_TIME → Duration in Sec. of permanency (after this time the text will be deleted)

LIB.HMESSAGE “@100TEST TEXT” 5

write “TEST TEX”T Row 1 Col 0 for 5 seconds

8 NSFORMS INSTRUCTIONS


8.1 LIB.MESSAGE

Show a MessageBox with specified mode.

The program is suspended up to executed action in MessageBox

Syntax

LIB.MESSAGE "TEXT" "CAPTION" BUTTON ICON



TEXT

Body Message Text \N line feed carriage return

CAPTION

Message Title

BUTTON (value or variable)

- | | |
|---|----------|
| 0 | OK |
| 1 | YES - NO |

ICON (value or variable)

- | | |
|---|-------------|
| 0 | ERROR |
| 1 | WARNING |
| 2 | INFORMATION |
| 3 | QUESTION |
| 4 | NONE |

Ex:

```
LIB.MESSAGE "CONTINUE\NPART PROGRAM EXECUTION???" "WARNING!!!" 1 1
$BTN=$[X13] // READ THE BUTTON PRESSED
IF $BTN=2
    END_PROGRAM // END PROGRAM IF PRESSED NO
END_IF
```



The LIB.MESSAGE instruction returned the code button pressed in the variable **\$[X13]**.
this contain

- 0 → Button OK pressed
- 1 → Button SI pressed

2 → Button **NO** pressed

8.2 LIB.SHOWFORM

Show a NsForm. The properties must be set by **LIB.FORMPROP** instruction.
The NsForm is in any case closed when the actual Part Program is finished.

Only one NsForm is displayed

Syntax

LIB.SHOWFORM

8.3 LIB.CLOSEFORM

Close a NsForm previously opened .

Syntax

LIB.CLOSEFORM

8.4 LIB.FORMPROP

Set the NsForm properties. The properties can be setted before a **LIB.SHOWFORM**

Syntax

LIB.FORMPROP "PROPNAMe" PROPVAlUE (value or variable)

PROPNAMe (Property Name TEXT) :

VISIBLE

PropValue 0 (or < ZERO) NsForm Invisible
PropValue 1 (or > ZERO) NsForm Visible

WIDTH

PropValue > zero set **WIDTH** NSFORM

HEIGHT

PropValue > zero set **HEIGHT** NSFORM

LEFT

PropValue > zero Set the **LEFT** position

TOP

PropValue > zero Set the **TOP** position

BACKCLOR

PropValue Value 0 to 140. Set BACKCOLOR (see color table)

STARTPOSITION (must be set before SHOWFORM)

PropValue 0 (o r< di ZERO) Use the **LEFT** e **TOP** position

PropValue 1 (or > di ZERO) NsForm is centered on screen

WINDOWSTATE

PropValue 0 (or < di ZERO) Use **WIDTH** e **HEIGHT** dimensions

PropValue 1 (or > di ZERO) Use a Max dimension

CONTROLBOX

PropValue 0 (or < di ZERO) Control Box disable

PropValue 1 (or > di ZERO) Control Box Enable

Ex:

```
LIB.FORMPROP "WIDTH" 500
LIB.FORMPROP "HEIGHT" 300
LIB.FORMPROP "BACKCOLOR" 113 //RED
LIB.FORMPROP "STARTPOSITION" 1 //CENTER SCREEN
LIB.FORMTEXT "CAPTION"
LIB.SHOWFORM
```



8.5 LIB.FORMTEXT

Set the NsForm Caption. The properties can be setted before a LIB.SHOWFORM

Syntax

LIB.FORMTEXT "CAPTION"

CAPTION (TEXT) :

Text of Caption

Ex:

LIB.FORMTEXT "CAPTION"

8.6 LIB.ADDLABEL

Add a NsLabel to NsForm. The NaLabel properties can be setted before a LIB.SHOWFORM

Syntax

LIB.ADDLABEL "NAME"

NAME (TEXT) :

Univocal Name of NsLabel Whitout special characters

Ex:

LIB.ADDLABEL "LBL"

8.7 LIB.LABELPROP

Set the NsLabel properties. The properties can be setted before a **LIB.SHOWFORM** but before, is necessary that the NsLabel is added to NsForm with **LIB.ADDLABEL**

Syntax

LIB.LABELPROP "LBLNAME" "PROPNAM" PROPVALU (value or variable)

LBLNAME NsLabel Name

PROPNAM (Property Name TEXT) :

VISIBLE

PropValue 0 (< of ZERO) NsLabel Invisible

PropValue 1 (> of ZERO) NsLabel Visible (default)

AUTOSIZE

PropValue 0 (< of ZERO) NsLabel dimension by WHIDTH e HEIGHT

PropValue 1 (> of ZERO) NsLabel automatic dimension (default)

ENABLED

PropValue 0 (< of ZERO) NsLabel enabled (default)

PropValue 1 (> of ZERO) NsLabel disabled

WIDTH

PropValue > zero NSLabel Width (if autosize = 0)

HEIGHT

PropValue > zero NSLabel Height (if autosize = 0)

LEFT

PropValue > zero NsLabel Left position in NsForm

TOP

PropValue > zero NsLabel Top position in NsForm

DIMFONT

PropValue Value 6 to 100. Font Dimension

BACKCLOR

PropValue Value 0 to 140.Set BACKCOLOR (see color table)

FORECOLOR

PropValue Value 0 to 140.Set FORECOLOR (see color table)

STYLE (default 0)

PropValue:

0 Normal

1 *Italic*

2 **Bold**

3 ***Bold Italic***

ALIGN (default 0)

PropValue:

0 Middle Left

1 Middle Center

2 Middle Right

3 Top Left

4 Top Center

5 Top Right

6 Bottom Left

7 Bottom Center

8 Bottom Right

BORDER (default 0)

PropValue:

0 None

1 *Fixed Single*

2 *Fixed 3D*

Ex:

```
LIB.FORMPROP "WIDTH" 500
LIB.FORMPROP "HEIGHT" 300
LIB.FORMPROP "STARTPOSITION" 1
LIB.FORMTEXT "TEST LABEL"
LIB.ADDLABEL "LBL"
LIB.LABELPROP "LBL" "AUTOSIZE" 0
LIB.LABELPROP "LBL" "WIDTH" 100
LIB.LABELPROP "LBL" "HEIGHT" 50
LIB.LABELPROP "LBL" "LEFT" 5
LIB.LABELPROP "LBL" "TOP" 10
LIB.LABELPROP "LBL" "DIMFONT" 12
LIB.LABELPROP "LBL" "ALIGN" 0
LIB.LABELPROP "LBL" "BACKCOLOR" 9
LIB.LABELPROP "LBL" "FORECOLOR" 137
LIB.LABELTEXT "LBL" "MY LABEL"
LIB.SHOWFORM
```

8.8 LIB.LABELTEXT

Write a Text in to NsLabel

Syntax


LIB.LABELTEXT "LBLNAME" "TEXT"

LBLNAME NsLabel Name

TEXT NsLabel Text

Ex:

LIB.LABELTEXT "LBL" " MY LABEL"



8.9 LIB.LABELPRINT

Write a Isous Variable in to NsLabel

Syntax

LIB.LABELPRINT "LBLNAME" "FORMAT" \$VAR

LBLNAME NsLabel Name

FORMAT Print Format:

“I” Only Integer value

“Fndec” Number of decimal

\$VAR Isous variable

Ex:

\$VAR=103.2569

LIB.LABELPRINT "LBL" "I" \$VAR //PRINT 103

LIB.LABELPRINT "LBL" "F1" \$VAR //PRINT 103.2

LIB.LABELPRINT "LBL" "F4" \$VAR // PRINT 103.2569

8.10 LIB.ADDBUTTON

Add a NsButton to NsForm. The NsButton properties can be set before a LIB.SHOWFORM

Syntax

LIB.ADDBUTTON "NAME"

NAME (TEXT) :

Univocal Name of NsButton Without special characters

Ex:

LIB.ADDBUTTON "BTN"

8.11 LIB.BUTTONPROP

Set the NsButton properties. The properties can be set before a LIB.SHOWFORM but before, it is necessary that the NsButton is added to NsForm with **LIB.ADDBUTTON**

Syntax

LIB.BUTTONPROP "BTNNNAME" "PROPNNAME" PROPVALUE (value or variable)

BTNNNAME NsButton Name

PROPNNAME (Property Name TEXT) :

VISIBLE

PropValue 0 (< of ZERO) NsButton Invisible

PropValue 1 (> of ZERO) NsButton Visible (default)

ENABLED

PropValue 0 (< of ZERO) NsButton enabled (default)

PropValue 1 (> of ZERO) NsButton disabled

WIDTH

PropValue > zero NsButton Width

HEIGHT

PropValue > zero NsButton Height

LEFT

PropValue > zero NsButton Left position in NsForm

TOP

PropValue > zero NsButton Top position in NsForm

DIMFONT

PropValue Value 6 to 100. Font Dimension

BACKCLOR

PropValue Value 0 to 140. Set BACKCOLOR (see color table)

FORECOLOR

PropValue Value 0 to 140. Set FORECOLOR (see color table)

STYLE (default 0)

PropValue:

0 Normal **1** *Italic* **2** **Bold** **3** **Bold Italic**

ALIGN (default 1)

PropValue:

0 Middle Left	1 Middle Center	2 Middle Right
3 Top Left	4 Top Center	5 Top Right
6 Bottom Left	7 Bottom Center	8 Bottom Right

DEST

Destination variable writing. Indicates the destination variable where the value is written to Source

LIB.BUTTONPROP "BTN" "DEST" \$VAR

SOURCE

Source variable. Value to write to DEST

When you press the value of the source variable is written to DEST.

If fixed number can not contain decimal places

LIB.BUTTONPROP "BTN" "SOURCE" \$VAR1

LIB.BUTTONPROP "BTN" "SOURCE" 1230


CLOSEFORM (default 0)

PropValue 0 (0 < of ZERO) When press the NsForm is Not closed

PropValue 1 (0 > of ZERO) When press the NsForm is closed

Ex:

```
LIB.FORMPROP "WIDTH" 500
LIB.FORMPROP "HEIGHT" 300
LIB.FORMPROP "STARTPOSITION" 1
LIB.FORMTEXT "TEST BUTTON"
LIB.ADDBUTTON "BTN"
LIB.BUTTONPROP "BTN" "WIDTH" 100
LIB.BUTTONPROP "BTN" "HEIGHT" 50
LIB.BUTTONPROP "BTN" "LEFT" 50
LIB.BUTTONPROP "BTN" "TOP" 50
LIB.BUTTONPROP "BTN" "DIMFONT" 12
LIB.BUTTONPROP "BTN" "ALIGN" 1
LIB.BUTTONTEXT "BTN" "MY BUTTON"
LIB.BUTTONPROP "BTN" "DEST" $VAR
$VAR=0
$VAR1=100.2
LIB.BUTTONPROP "BTN" "SOURCE" $VAR1
LIB.SHOWFORM
```



8.12 LIB.BUTTONTEXT

Write a Text in to NsButton

Syntax

LIB.BUTTONTEXT "BTNNNAME" "TEXT"

BTNNNAME NsButton Name

TEXT NsButton Text

Ex:

LIB.BUTTONTEXT "BTN" " MY BUTTON"

8.13 LIB.BUTTONPRINT

Write a Isous Variable in to NsButton

Syntax

LIB.BUTTONPRINT "BTNNNAME" "FORMAT" \$VAR

BTNNNAME NsButton Name

FORMAT Print Format:

“I” Only Integer value

“F_ndec” Number of decimal

\$VAR Isous variable

Ex:

\$VAR=103.2569

LIB.BUTTONPRINT "BTN" "I" \$VAR //PRINT 103

LIB.BUTTONPRINT "BTN" "F1" \$VAR //PRINT 103.2

LIB.BUTTONPRINT "BTN" "F4" \$VAR // PRINT 103.2569

8.14 LIB.ADDINPUT

Add a NsInput to NsForm. The NsInput properties can be setted before a LIB.SHOWFORM

The NsInput Object is used to write numerical value to Isous variable

Syntax

LIB.ADDINPUT "NAME"

NAME (TEXT) :

Univocal Name of NsInput Without special characters

Ex:

LIB.ADDINPUT "INP"



Button **SET** when pressed writes the value in Isous variable identified in “**DEST**”

If **AUTOSET=1** the value is automatically written when this is changed

8.15 LIB.INPUTPROP

Set the NsInput properties. The properties can be setted before a **LIB.SHOWFORM** but before, is necessary that the NsInput is added to NsForm with **LIB.ADDBUTTON**

Syntax

LIB.INPUTPROP "INPNAME" "PROPNAM" PROPVAL (value or variable)

INPNAME NsInput Name

PROPNAM (Property Name TEXT) :

VISIBLE

PropValue 0 (< of ZERO) NsInput Invisible

PropValue 1 (> of ZERO) NsInput Visible (default)

ENABLED

PropValue 0 (< of ZERO) NsInput enabled (default)

PropValue 1 (> of ZERO) NsInput disabled

WIDTH

PropValue > zero NsInput Width

LEFT

PropValue > zero NsInput Left position in NsForm

TOP

PropValue > zero NsInput Top position in NsForm

DIMFONT

PropValue Value 6 to 100. Font Dimension

BACKCLOR

PropValue Value 0 to 140. Set BACKCOLOR (see color table)

FORECOLOR

PropValue Value 0 to 140. Set FORECOLOR (see color table)

ALIGN (default 0)

PropValue:

0 Left **1** Center **2** Right

DEST

Destination variable writing. Indicates the destination variable where the value is written

LIB.BUTTONPROP "BTN" "DEST" \$VAR

MIN

PropValue Minimum value accepted (double)

MAX

PropValue Maximum value accepted (double)

NDECIMAL

PropValue > zero Number of decimals displayed

INCREMENT

PropValue Increment value when pressed up - down buttons (double)


AUTOSET

PropValue 0 (< ZERO) The value is writes when pressed the button SET

PropValue 1 (> ZERO) The value is automatically writes when this changed

Es:

```
LIB.FORMPROP "WIDTH" 500
LIB.FORMPROP "HEIGHT" 300
LIB.FORMPROP "STARTPOSITION" 1
LIB.FORMTEXT "TEST INPUT"
LIB.ADDINPUT"INP"
LIB.INPUTPROP "INP" "WIDTH" 100
LIB.INPUTPROP "INP" "DIMFONT" 20
LIB.INPUTPROP "INP" "LEFT" 50
LIB.INPUTPROP "INP" "TOP" 50
LIB.INPUTPROP "INP" "ALIGN" 1
LIB.INPUTPROP "INP" "DEST" $VAR
LIB.INPUTPROP "INP" "MIN" 0
LIB.INPUTPROP "INP" "MAX" 100
LIB.INPUTPROP "INP" "NDECIMAL" 3
$VAR1=0.01
LIB.INPUTPROP "INP" "INCREMENT" $VAR1
$VAR=0
```



8.16 LIB.INPUTSETVALUE

Write a Isous Variable in to NsInput

Syntax

LIB.INPUTSETVALUE "INPNAME" \$VAR

INPNAME NsInput Name

\$VAR Isous variable

Ex:

\$VAR=103.2569

LIB.INPUTSETVALUE "INP" \$VAR //SET VALUE AT 103.2569

8.17 COLOR TABLE

Following color table to refer when the property is a color

0	ALICEBLUE		35	DARKSLATEGRAY		70	LIGHTSALMON	
1	ANTIQUEWHITE		36	DARKTURQUOISE		71	LIGHTSEAGREEN	
2	AQUA		37	DARKVIOLET		72	LIGHTSKYBLUE	
3	AQUAMARINE		38	DEEPPINK		73	LIGHTSLATEGRAY	
4	AZURE		39	DEEPSKYBLUE		74	LIGHTSTEELBLUE	
5	BEIGE		40	DIMGRAY		75	LIGHTYELLOW	
6	BISQUE		41	DODGERBLUE		76	LIME	
7	BLACK		42	FIREBRICK		77	LIMEGREEN	
8	BLANCHEDALMOND		43	FLORALWHITE		78	LINEN	
9	BLUE		44	FORESTGREEN		79	MAGENTA	
10	BLUEVIOLET		45	FUCHSIA		80	MAROON	
11	BROWN		46	GAINSBORO		81	MEDIUMAQUAMARINE	
12	BURLYWOOD		47	GHOSTWHITE		82	MEDIUMBLUE	
13	CADETBLUE		48	GOLD		83	MEDIUMORCHID	
14	CHARTREUSE		49	GOLDENROD		84	MEDIUMPURPLE	
15	CHOCOLATE		50	GRAY		85	MEDIUMSEAGREEN	
16	CORAL		51	GREEN		86	MEDIUMSLATEBLUE	
17	CORNFLOWERBLUE		52	GREENYELLOW		87	MEDIUMSPRINGGREEN	
18	CORNSILK		53	HONEYDEW		88	MEDIUMTURQUOISE	
19	CRIMSON		54	HOTPINK		89	MEDIUMVIOLETRED	
20	CYAN		55	INDIANRED		90	MIDNIGHTBLUE	
21	DARKBLUE		56	INDIGO		91	MINTCREAM	
22	DARKCYAN		57	IVORY		92	MISTYROSE	
23	DARKGOLDENROD		58	KHAKI		93	MOCCASIN	
24	DARKGRAY		59	LAVENDER		94	NAVAJOWHITE	
25	DARKGREEN		60	LAVENDERBLUSH		95	NAVY	
26	DARKKHAKI		61	LAWNGREEN		96	OLDLACE	
27	DARKMAGENTA		62	LEMONCHIFFON		97	OLIVE	
28	DARKOLIVEGREEN		63	LIGHTBLUE		98	OLIVEDRAB	
29	DARKORANGE		64	LIGHTCORAL		99	ORANGE	
30	DARKORCHID		65	LIGHTCYAN		100	ORANGERED	
31	DARKRED		66	LIGHTGOLDENRODYELLOW		101	ORCHID	
32	DARKSALMON		67	LIGHTGRAY		102	PALEGOLDENROD	
33	DARKSEAGREEN		68	LIGHTGREEN		103	PALEGREEN	
34	DARKSLATEBLUE		69	LIGHTPINK		104	PALETURQUOISE	

105	PALEVIOLETRED		140	YELLOWGREEN	
106	PAPAYAWHIP				
107	PEACHPUFF				
108	PERU				
109	PINK				
110	PLUM				
111	POWDERBLUE				
112	PURPLE				
113	RED				
114	ROSYBROWN				
115	ROYALBLUE				
116	SADDLEBROWN				
117	SALMON				
118	SANDYBROWN				
119	SEAGREEN				
120	SEASHELL				
121	SIENNA				
122	SILVER				
123	SKYBLUE				
124	SLATEBLUE				
125	SLATEGRAY				
126	SNOW				
127	SPRINGGREEN				
128	STEELBLUE				
129	TAN				
130	TEAL				
131	THISTLE				
132	TOMATO				
133	TRANSPARENT				
134	TURQUOISE				
135	VIOLET				
136	WHEAT				
137	WHITE				
138	WHITESMOKE				
139	YELLOW				

9 COMPILATOR SWITCH

The compilator switch, allows to give some directives to compilator by the constructs:

IFDEF
ELSEDEF
ENDIFDEF

This allow to compile only the code which is part of the logic of switch selected.

Currently is available only one system switch:

AXES

It contains the number of Axes configured in the IsoUs application:

Ex: for 3 AXES configuration

IFDEF AXES=3 // AXES NUMBER=3

G1 X100 Y100 Z200

ENDIFDEF

IFDEF AXES=4 //AXES NUMBER=4

G1 X100 Y100 Z200 A200

ENDIFDEF

In this example, only the code **G1X100Y100Z200** will be compiled, the code **G1X100Y100Z200A200** will be removed.

In the normal condition, without switch directive, will be showed an error AXIS NOT CONFIGURED (A)

Is possible add a custom switch, see:

[System Utility – 3.5.2 Add a Custom Parameter](#)

9.1 IFDEF

Instruction IF on the switch selected:

IFDEF AXES=3

If the condition is true, the code content between **IFDEF** and **ELSEDEF** or **ENDIFDEF**, will be compiled, otherwise will be removed and compiled the code insert in the **ELSEDEF**

In the IFDEF can be used the following operators:

=	<i>Equal</i>
>	<i>Greater</i>
<	<i>Lower</i>
>=	<i>Greater Equal</i>
<=	<i>Lower Equal</i>
<>	<i>Different</i>

9.2 ELSEDEF

Instruction ELSE on the switch selected:

IFDEF AXES=3

G1 X100

ELSEDEF

G1 Y30

ENDIFDEF

If the condition is true, AXES<>3 the code content between ELSEDEF and ENDIFDEF, will be compiled

9.3 ENDIFDEF

Instruction **ENDIFDEF**

9.4 NOAXESREADY

This Directive allows to run a Gcode though the axes are not ready. (generally it is inserted at the beginning the Gcode)

NOAXESREADY

```
G71.1 X // ENABLE X
G71.1 Y // ENABLE Y
G71 X      // HOMING X
G71 Y      // HOMING Y
```

9.5 ONERROR

This Directive allows to programming a Gcode part that will be performed when an error is occurred (Like to M Error)

Following will be performed the **M Error** if is set

ONERROR

```
$[O1]=0 // DISABLE OUT
$[O2]=0 // DISABLE OUT
ENDON
```

9.6 ONSTOP

This Directive allows to programming a Gcode part that will be performed when the CN go from RUN to STOP (Like to M Stop)

Following will be performed the **M Stop** if is set

ONSTOP

```
$[O1]=0 // DISABLE OUT
$[O2]=0 // DISABLE OUT
ENDON
```

9.7 ENDON

Ends **ONERROR** and **ONSTOP**

9.8 USET

This Directive allows performed a Macro after the instruction **Tn**

```
USET 5 // AFTER Tn WILL BE PERFORMED M5 MACRO
```

9.9 USEH

This Directive allows performed a Macro after the instruction **Hn**

```
USEH 6 // AFTER Hn WILL BE PERFORMED M6 MACRO
```

10 MATH FUNCTIONS

10.1 SIN

Return the sinus of an angle in a DOUBLE type value.

Syntax

SIN (angle)

angle Mandatory. Angle in radiant (it can be an expression)

Ex:

`$VAR=SIN($VAR1*3)`

10.2 COS

Return the co-sinus of an angle in a DOUBLE type value.

Syntax

COS (angle)

angle Mandatory. Angle in radiant (it can be an expression)

Ex:

`$VAR=COS($VAR1*3)`

10.3 LOG

Return the base of natural logarithm in a DOUBLE type value.

Syntax

LOG (expression)

expression Mandatory. Expression.

Ex:

`$VAR=LOG($VAR1*3)`

10.4 EXP

Return the exponential of an expression in a DOUBLE type value.

Syntax

EXP (expression)

expression Mandatory. Expression

Ex:

`$VAR=EXP(10.15)`

10.5 INT

Return the integer part of a DOUBLE value rounded

Syntax

INT (expression)

expression Mandatory. Numeric expression

Ex:

`$VAR=35.14`

`$VAR1=INT($VAR)`

10.6 FIX

Return the integer part of a DOUBLE value truncated

Syntax

FIX (**expression**)

expression Mandatory. Numeric expression

Ex:

\$VAR=35.14

\$VAR1=FIX(\$VAR)

10.7 ABS

Return the absolute value

Syntax

ABS (**expression**)

expression Mandatory. Numeric expression

Ex:

\$VAR=-35.14

\$VAR1=ABS(\$VAR)

10.8 DRG

Enable angle in **DEGREES** for COS,SIN,TAN,ACOS,ASIN,ATAN functions.

By default at each start of PART PROGRAM angle are setted in radiant

Syntax

DRG

10.9 RAD

Enable angle in **RADIANT** for COS,SIN,TAN,ACOS,ASIN,ATAN functions.

By default at each start of PART PROGRAM angle are setted in radiant

Syntax

RAD

10.10 SQR

Return the square root of an expression in DOUBLE type value.

Syntax

SQR (**expression**)

expression Mandatory. Expression

Ex:

\$VAR=SQR(\$VAR1)

10.11 TAN

Return the tangent of an angle in a DOUBLE type value.

Syntax

TAN (**angle**)

angle Mandatory. Angle in radiant (it can be an expression)

Ex:

\$VAR=TAN(\$VAR1*3)

10.12 ATAN

Return the arctangent of an expression. Result is from -3.14 to 3.14

Syntax

ATAN (expression)

expression Mandatory. Expression

Ex:

\$VAR=ATAN(\$VAR1*3)

10.13 ASIN

Return the arc-sinus of an expression.

Syntax

ASIN (expression)

expression Mandatory. Expression

Ex:

\$VAR=ASIN(\$VAR1*3)

10.14 ACOS

Return the arc-cos of an expression.

Syntax

ACOS (expression)

expression Mandatory. Expression

Ex:

\$VAR=ACOS(\$VAR1*3)

I. ISTRUZIONI PER IL CONTROLLO MULTIPROCESSO

L' istruzioni per il controllo del MultiProcesso, servono per gestire più CNC che sono eseguiti nella stessa unità PC. Non necessita di nessuna configurazione particolare, in quanto questa è automaticamente rilevata dal file IsoUs.cfg.

11 FUNCTIONS for Multi process Control

The instructions for multi process control allow to management more CNC (IsoUs Process) in the same PC
These functions no need any special configuration.

11.1 CNC.LOAD

Load a Gcode File in the Process.

Syntax

CNC.LOAD CN TypeRun InEditor "PATH"

CN Process Number from 1 to 8

TypeRun **0** Load Only

1 Load and Run

2 Load and Preview

3 Load, Preview and Run

InEditor **0** Not Send to UsEditor
1 Send to UsEditor

PATH (in quotes) If **PATH** starts with \$APPPATH, the path is Relative to IsoUs Folder installation

The file name must have the extension

Ex:

CNC.LOAD 1 1 1 "\$APPPATH\PROJECT\IMPORT\TEST.ISO" // RELATIVE PATH

CNC.LOAD 1 1 1 "C:\FILE\TEST.ISO" // ABSOLUTE PATH

11.2 CNC.RUN

Run Gcode in the Process.

Syntax

CNC.RUN CN

CN Process Number from 1 to 8

If **CN =-1** Run on all Process

Ex:

CNC.RUN 1 // RUN PROCESS 1

CNC.RUN -1 // RUN ALL PROCESS

11.3 CNC.PREVIEW

Preview Gcode in the Process.

Syntax

CNC.PREVIEW CN

CN Process Number from 1 to 8

If **CN =-1** Preview on all Process

Ex:

CNC.PREVIEW 1 // PREVIEW PROCESS 1

CNC.PREVIEW -1 // PREVIEW ALL PROCESS

11.4 CNC.STOP

Stop Gcode in the Process.

Syntax

CNC.STOP CN

CN Process Number from 1 to 8
If **CN =-1** Stop on all Process

Ex:

CNC.STOP 1 // STOP PROCESS 1
CNC. STOP -1 // STOP ALL PROCESS

11.5 CNC.PAUSE

Pause Gcode in the Process.

Syntax

CNC.PAUSE CN

CN Process Number from 1 to 8
If **CN =-1** Pause on all Process

Ex:

CNC.PAUSE 1 // PAUSE PROCESS 1
CNC. PAUSE -1 // PAUSE ALL PROCESS

11.6 CNC.STATUS

Read Status from Process.

Syntax

CNC.STATUS CN \$VAR

CN Process Number from 1 to 8
\$VAR Return Status (bit mapped)

Bit 0	Run	Bit 1	Error	Bit 2	Axes Move
Bit 3	Pause	Bit 4	Home X Ok	Bit 5	Home Y OK
Bit 6	Home Z Ok	Bit 7	Home A Ok	Bit 8	Home B Ok
Bit 9	Home C Ok	Bit 10	Home U Ok	Bit 11	Home V Ok
Bit 12	Home W Ok	Bit 13	Enable X	Bit 14	Enable Y
Bit 15	Enable Z	Bit 16	Enable A	Bit 17	Enable B
Bit 18	Enable C	Bit 19	Enable U	Bit 20	Enable V
Bit 21	Enable W	Bit 22	Ready to Run (Home and enable Ok on all Axes)		

Ex:

CNC.STATUS 1 \$VAR
\$VAR1=\$VAR & 1 //TEST RUN
IF \$VAR1 = 1
...// IS RUN

11.7 CNC.STATUSBIT

Read Status bit from Process.

Syntax

CNC.STATUS CN NrBit \$VAR

CN Process Number from 1 to 8
NrBit Bit number (see CNC.STATUS)
\$VAR Return Status bit

Ex:

CNC.STATUSBIT 1 1 \$VAR

IF \$VAR = 1
...// IS RUN

11.8 CNC.INFO

Read informations from Process.

Syntax

CNC.INFO CN InfoType \$VAR

CN Process Number from 1 to 8
InfoType Tipo informazione
 0 Read Demand Gcode Line in execution
 1 Read Real Gcode Line in execution
 2 Read Axes Resolution
 3 Read Feed Resolution
\$VAR Return Info

11.9 CNC.AXIS

Read Axis informations from Process.

Syntax

CNC.INFO CN AxisIndex AxisType \$VAR

CN Process Number from 1 to 8
AxisIndex Axis Index 0 to 8
AxisType Axis Information
 0 Read Demand Axis Value
 1 Read Real Axis Value
 2 Read Demand Axis Value (Syncro – Precise mode)
 3 Read Real Axis Value (Syncro – Precise mode)
 4 Read Total Offset Value (Work Origins,Offset Hn G43 etc.)
\$VAR Return Info

11.10 CNC.GROUP

Read Group Axis informations from Process.

Syntax

CNC.GROUP CN NrAxes AxisType \$VAR

CN	Process Number from 1 to 8
NrAxes	Group of Axis 1 to 9
AxisType	Axis Information 0 Read Demand Axis Value 1 Read Real Axis Value 2 Read Total Offset Value (Work Origins,Offset Hn G43 etc.)
\$VAR	Return Info Start Variable or Array

Ex:

// ALLOC 3 VARIABLES FOR 3 AXES

```
$VARX=0
$VARY=0
$VARZ=0
CNC.GROUP 1 3 0 $VARX
// $VARX=VALUE ASSE X
// $VARY= VALUE ASSE Y
// $VARZ= VALUE ASSE Z
```

Ex:

// ALLOC ARRAY

```
DIM $ARR 3
CNC.GROUP 1 3 0 $ARR
// $ARR[0]= VALUE ASSE X
// $ARR[1]== VALUE ASSE Y
// $ARR[2]= VALUE ASSE Z
```

11.11 CNC.READVARADDR

Read a Gcode Variable by Address from Process.

Syntax

CNC.READVARADDR CN AddrVar \$VAR

CN	Process Number from 1 to 8
AddrVar	Variable Address from 0 to 327667
\$VAR	Return Value

11.12 CNC.READVARNAME

Read a Gcode Variable by Name from Process.

Syntax

CNC.READVARNAME CN \$VAR “VARNAME”

CN Process Number from 1 to 8

\$VAR Return Value

VARNAME Variable Name UpperCase without \$ (in quotes)

11.13 CNC.WRITEVARADDR

Write a Gcode Variable by Address from Process.

Syntax

CNC.WRITEVARADDR CN AddrVar \$VAR

CN Process Number from 1 to 8

If **CN =-1** Write on all Process

AddrVar Variable Address from 0 to 327667

\$VAR Source Value

11.14 CNC.WRITEVARNAME

Write a Gcode Variable by Name from Process.

Syntax

CNC.WRITEVARNAME CN \$VAR “VARNAME”

CN Process Number from 1 to 8

If **CN =-1** Write on all Process

\$VAR Source Value

VARNAME Destination Variable Name UpperCase without \$ (in quotes)

11.15 CNC.READPARMAC

Read Machine Parameter from Process.

Syntax

CNC.READPARMAC CN \$VAR “PARNAME”

CN Process Number from 1 to 8

\$VAR Return Value

PARNAME Parameter Name (in quotes)

11.16 CNC.WRITEPARMAC

Write Machine Parameter to Process.

Syntax

CNC.WRITEPARMAC CN \$VAR “PARNAME”

CN Process Number from 1 to 8

\$VAR Source Value

PARNAME Parameter Name (in quotes)

11.17 CNC.ENABLEAXIS

Enable/Disable Axis to Process. (wait sequence finished)

Syntax

CNC.ENABLEAXIS CN AXIS STATE

CN	Process Number from 1 to 8
AXIS	Axis Index
STATE	Axis State
	0 Disable
	1 Enable

11.18 CNC.HOMEAXIS

Homing Axis to Process. (wait sequence finished) CNC.STOP for force Stop Homing

Syntax

CNC.HOMEAXIS CN AXIS

CN	Process Number from 1 to 8
AXIS	Axis Index

11.19 CNC.READGENERIC

Read Generic Variable (see below Type Generic)

Syntax

CNC.READGENERIC CN TYPE \$PAR \$VAR

CN	Process Number from 1 to 8
TYPE	Tipo Variable
\$PAR	Additional Parameter (if it is not managed put \$PAR=0)
\$VAR	return Value

11.20 CNC.WRITEGENERIC

Write Generic Variable (see below Type Generic)

Syntax

CNC.WRITEGENERIC CN TYPE \$PAR \$VAR

CN	Process Number from 1 to 8
TYPE	Tipo Variable
\$PAR	Additional Parameter (if it is not managed put \$PAR=0)
\$VAR	Source Value

Type Generic

TYPE	READ	WRITE	Description	\$PAR
0	V		Read Demand Axis Value (\$[Qn])	Axis Index
1	V		Read Real Axis Value (\$[Rn])	Axis Index
2	V		Read Digital Input (\$[In])	Index (0 to 255)
3	V	V	Read/Write Digital Output (\$[On])	Index (0 to 255)
4	V	V	Read/Write Tool Table Parameter (\$[Un])	Parameter Index
5	V		Read Head Parameter (\$[Hn])	Parameter Index
6	V		Read SPEED (\$[X0])	Not Used
7	V		Read Work Origins Enable (\$[X3])	Not Used
8	V		Read Offset Enable (\$[X4])	Not Used
9	V		Read FEED (\$[X8])	Not Used
10	V		Read Origin Value (\$[Yn])	Not Used
11	V		Read Offset Value (\$[Wn])	Axis Index
12	V		Read H Set	Not Used
13	V		Read T Set	Not Used
14	V	V	Read/Write User Generic (\$[Kn])	User Generic Index
15		V	Write Analo Value for SPINDLE	Not Used

12 REMOTE CONTROL FUNCTIONS

Remote functions allows to control more CNC connected in LAN (See **CN REMOTE CONFIGURATION**)

RunTimeError:

- E1082** Remote CNC not connect
- E1083** Remote CNC operation failure
- E1084** Remote CNC Gcode Error
- E1085** Remote CNC RUN Error
- E1086** Remote CNC File not found
- E1087** Remote CNC Axes not ready
- E1088** Remote CNC Already in RUN
- E1089** Remote CNC Axes not available
- E1090** Remote CNCD Gcode Variable not found

12.1 REMOTE.LOAD

Load a Gcode file on Remote CNC

Syntax

REMOTE LOAD CN RUN "PATH"

- CN** Number of CNC set in *clientNs.cfg file*
- RUN** **0** Only Load
1 Load and Run
- PATH** Remote Gcode file Path
If **PATH** starts with **\$APPPATH**, the path is Relative to Isous Folder installation

Ex:

REMOTE LOAD 0 1 "\$APPPATH\PROJECT\IMPORT\TEST.ISO" //RELATIVE PATH

REMOTE LOAD 0 1 "C:\FILE\TEST.ISO" //ABSOLUTE PATH

12.2 REMOTE.RUN

Run a Gcode file on Remote CNC

Syntax

REMOTE RUN CN

- CN** Number of CNC set in *clientNs.cfg file*

Ex:

REMOTE RUN 0 //run on CN 0

12.3 REMOTE.STOP

Stop a Gcode file on Remote CNC

Syntax

REMOTE STOP CN

- CN** Number of CNC set in *clientNs.cfg file*

Ex:

REMOTE STOP 0 //stop CN 0

12.4 REMOTE.PAUSE

Pause a Gcode file on Remote CNC

Syntax

REMOTE.PAUSE CN

CN Number of CNC set in *clientNs.cfg file*

Ex:

REMOTE.PAUSE 0 //pause CN 0

12.5 REMOTE.STATUS

Read a STATUS WORD on Remote CNC

Syntax

REMOTE.STATUS CN \$VAR

CN Number of CNC set in *clientNs.cfg file*

\$VAR **Gcode Variable**

Return in \$VAR (bit Mapped):

bit 0 → CN ERROR

bit 1 → CN RUN

bit 2 → CN AXES MOV

bit 3 → CN PAUSE

Ex:

```
REMOTE LOAD 0 0 ...
REMOTE LOAD 1 0 ...
REMOTE RUN 0
REMOTE RUN 1
@LBL_1
REMOTE STATUS 0 $VAR //READ STATUS CN 0 IN $VAR
REMOTE STATUS 1 $VAR1 // READ STATUS CN 1 IN $VAR1
$V1=$VAR&2 //TEST BIT RUN
$V2=$VAR1&2
IF $V1=2 || $V2=2 //WAIT IF RUN
    GOTO LBL_1
END_IF
```

12.6 REMOTE.MOVE

Read Axes Mov on Remote CNC

Syntax

REMOTE.MOVE CN \$VAR

CN Number of CNC set in *clientNs.cfg file*

\$VAR **Gcode Variable**

Return in \$VAR:

0 → Axes Stop

1 → Axes Mov

Es:

REMOTE MOVE 0 \$VAR //Read Axes Mov in \$VAR

12.7 REMOTE.INFO

Read Info on Remote CNC

Syntax

REMOTE.INFO CN TYPE \$VAR

CN Number of CNC set in *clientNs.cfg file*

TYPE Type of Information:

- 0 → Get Demand Line Worked
- 1 → Get Real Line Worked
- 2 → Get Current FEED
- 3 → Get % of Override
- 4 → Get Tool Table Set (T)
- 5 → Get Head Set (H)
- 6 → Get Axes Resolution Set (1000,10000 etc,)
- 7 → Get Feed Resolution Set (1000 etc.)

\$VAR **Gcode** Variable

Ex:

REMOTE.INFO 0 0 \$VAR //Read Demand Line Worked in \$VAR

12.8 REMOTE.AXIS

Read Axis Info on Remote CNC

Syntax

REMOTE.AXIS CN AXIS TYPE \$VAR

CN Number of CNC set in *clientNs.cfg file*

AXIS Axis 0=X - 1=Y - 2=Z - 3=A – 4=B – 5=C – 6=U -7=V - 8=W

TYPE Type of Information:

- 0 → Get Demand Absolute Axis Value (from ZERO ORIGIN)
- 1 → Get Demand Relative Axis Value (from Work Origin Set)
- 2 → Get Real Absolute Axis Value (from ZERO ORIGIN)
- 3 → Get Real Relative Axis Value (from Work Origin Set)
- 4 → Not Use
- 5 → Not Use
- 6 → Get Value Work Origin Set
- 7 → Get Value OffsetOrigin Set
- 8 → Get Work Origin Index Set
- 9 → Get Offset Origin Index Set

\$VAR **Gcode** Variable

Ex:

REMOTE.AXIS 0 1 0 \$VAR //Get Y Demand Position value

12.9 REMOTE.GROUP

Read Axes group Info on Remote CNC

Syntax

REMOTE.Axis CN NAXES TYPE \$VAR

CN Number of CNC set in *clientNs.cfg file*

NAXES Number of Axes to read

TYPE Type of Information:

0 → Get Group Demand Absolute Axis Value (from ZERO ORIGIN)

1 → Get Group Demand Relative Axis Value (from Work Origin Set)

2 → Get Group Real Absolute Axis Value (from ZERO ORIGIN)

3 → Get Real Relative Axis Value (from Work Origin Set)

4 → Not Use

5 → Not Use

6 → Get Group Value Work Origin Set

7 → Get Group Value OffsetOrigin Set

8 → Get Group Work Origin Index Set

9 → Get Group Offset Origin Index Set

\$VAR **Gcode Start Variable**

The Successive variables are get following the start Variable

Ex:

\$VARX=0 //Start Variable

\$VARY=0

\$VARZ=0

REMOTE.GROUP 0 3 0 \$VARX //Read X,Y,Z in VARX,VARY,VARZ

12.10 REMOTE.READISOVAR

Read a Gcode Variable on Remote CNC from Address

Syntax

REMOTE.READISOVAR CN ADDR \$VAR

CN Number of CNC set in *clientNs.cfg file*

ADDR Addr Gcode IsoVar from 10 to 32768 (from 0 to 9 are reserved)

\$VAR **Gcode Variable**

Ex:

REMOTE.READISOVAR 0 10 \$VAR //Read the variable addr 10 (first variable declared)

12.11 REMOTE.READVARNAME

Read a Gcode Variable on Remote CNC from Name

Syntax

REMOTE.READVARNAME CN \$VAR "RemoteVarName"

CN Number of CNC set in *clientNs.cfg file*

\$VAR **Gcode Variable**
RemoteVarName Remote Variable Name without \$

Ex:

REMOTE.READVARNAME 0 \$VAR "VAR1" //Read the variable name \$VAR1

12.12 REMOTE.WRITEISOVAR

Write a Gcode Variable on Remote CNC from Address

Syntax

REMOTE.WRITEISOVAR CN ADDR \$VAR

CN Number of CNC set in *clientNs.cfg file*
ADDR **Addr** Gcode IsoVar from 10 to 32768 (from 0 to 9 are reserved)
\$VAR **Gcode Variable**

Ex:

\$VAR=100.1

REMOTE.WRITEISOVAR 0 10 \$VAR //Write the variable addr 10

12.13 REMOTE.WRITENAMEVAR

Write a Gcode Variable on Remote CNC from Name

Syntax

REMOTE.WRITENAMEVAR CN \$VAR "RemoteVarName"

CN Number of CNC set in *clientNs.cfg file*
\$VAR **Gcode Variable**
RemoteVarName Remote Variable Name without \$

Ex:

\$VAR=100.1

REMOTE.WRITENAMEVAR 0 \$VAR "VAR1" // Write the variable \$VAR1

12.14 REMOTE.READCNVAR

Read a User Generic Variable on Remote CNC

Syntax

REMOTE.READCNVAR CN ADDR \$VAR

CN Number of CNC set in *clientNs.cfg file*
ADDR User Generic Variable addr from 0 to 9
\$VAR **Gcode Variable**

Ex:

REMOTE.READCNVAR 0 1 \$VAR //Read User Generic 1

12.15 REMOTE.WRITECNVAR

Write a User Generic Variable on Remote CNC

Syntax

REMOTE.WRITECNVAR CN ADDR \$VAR

CN	Number of CNC set in <i>clientNs.cfg file</i>
ADDR	User Generic Variable addr from 0 to 9
\$VAR	Gcode Variable

Ex:

\$VAR=10

REMOTE.WRITECNVAR 0 1 \$VAR //Write value 10 in USER GENERIC 1

12.16 REMOTE.READINPUT

Read a Digital Input on Remote CNC

Syntax

REMOTE.READINPUT CN NINP \$VAR

CN	Number of CNC set in <i>clientNs.cfg file</i>
NINP	Digital Input Number from 0 to 255
\$VAR	Gcode Variable
	0 → Input OFF
	1 → Input ON

Ex:

REMOTE.READINPUT 0 1 \$VAR //Read Digital Input 1

12.17 REMOTE.READOUTPUT

Read a Digital Output on Remote CNC

Syntax

REMOTE.READOUT CN NOUT \$VAR

CN	Number of CNC set in <i>clientNs.cfg file</i>
NOUT	Digital Output Number from 0 to 255
\$VAR	Gcode Variable
	0 → Output OFF
	1 → Output ON

Ex:

REMOTE.READOUT 0 1 \$VAR //Read Digital Output 1

12.18 REMOTE.WRITEOUTPUT

Write a Digital Output on Remote CNC

Syntax

REMOTE.WRITEOUT CN NOUT \$VAR

CN Number of CNC set in *clientNs.cfg file*
NOUT Digital Output Number from 0 to 255
\$VAR **Gcode** Variable
 0 → Output OFF
 1 → Output ON

Ex:

\$VAR=1

REMOTE.WRITEOUT 0 1 \$VAR //Set Digital Output 1

13 CN REMOTE CONFIGURATION

First to use the Remote Functions, need to configure the remote CNC in the LAN.
 The CNC can be in the same PC, or in the different PC, but connected at same LAN.
 The configuration of Remote CNC is in the following file::

NSCLIENT

NSSERVER

NSCLIENT

This represents the configuration of one or more CNCs that open the connection to a NS SERVER CNC. To configure client CNCs, just have a file named "ClientNs.cfg" in the Isous installation folder.

ClientNs.cfg

[USER_CN 0]

CN=IpAddr,port → CN 0 to process 0

CN=IpAddr,port → CN 1 to process 0

.

[USER_CN 1]

CN=IpAddr,port → CN 0 to process 1 (if present)

CN=IpAddr,port → CN 1 to process 1 (if present)

Where:

IpAddr → Server IP address for CN 0,1,2 etc.

port → Port Number for CN 0,1,2 etc.

NSSERVER

Represents a CNC server in a LAN network. This is to be configured as a server, you must have the PLUGIN "ServerNs.dll" (in Plugin \ Bin) with the following setup in UsPlugin.cfg file:

```
<Set      Name="UsServer"      Image=""      Title="@_US      SERVER"      Path="UsPlugin\Bin\UsServer.dll"
NameSpace="UsServer.GestUsServer" Autorun="False" Button="False" Enable="True" />
```

Additionally, the "ServerNs.cfg" file must be present in the Isous server installation folder that configures the server process listening port.

ServerNs.cfg

[USER_CN 0]

Port → Port in listening for CN 0

[USER_CN 1]

Port → Port in listening for CN 1 (if present)

.

.

Note

Be careful when configuring the Port. You must choose values that are not occupied by other operating system processes (typically higher values, eg 36000)

Example

Local LAN Configuration, Server IP Address 10.0.0.34 Port 36000

The PC that contains the server process must then have a static IP 10.0.0.34

The PC that contains the client process can have the same IP address as the same PC, but must have an appropriate address to the network eg: 10.0.0.50

ClientNs.cfg

[USER_CN 0]

CN=10.0.0.34,36000

ServerNs.cfg

[USER_CN 0]

36000

14 USING LOGIC OPERATORS

In this chapter will be explained how to use logical operator omitting classic math operators (+-*-/).

14.1 ROUND BRACKETS ()

They separate level of expressions, doing priority to content inside the brackets.

14.2 ISO EXPRESSIONS and SQUARE BRACKETS []

The use of square brackets is not permitted in generic expression. They are valid only for specific type of variable and exclusively in the functions listed below. In these ISO instructions identify, in them, an expression or a variable. That is because in origin ISO code accepted only numeric fields, therefore to remain compatible at this standard but to have the possibility of a powerful and more flexible language, Isous introduced square brackets [] to identify an expression or variable.

ISO INSTRUCTIONS WHERE ARE PERMITTED SQUARE BRACKETS []

Axis positions	X,Y,Z,A,B,C,U,V,W - DX,DY,DZ,DA,DB,DC,DU,DV,DW
Axis Feed	F
Speed	S
Tool diameter	D
Arc Center	I,J
Arc Radius	R
Tool	T
Head	H
Origin index	USER_ZERO
Offset index	USER_OFFSET

Ex:

```
G1X1000          // STANDARD ISO GCODE
G1DX1000         // INCREMENTAL VALUE (THE SAME G91)
G1X[$VAR]         // USE OF VARIABLE AS AXIS POSITION
G1X[$VAR+$VAR1*SQR(18)] // USE OF EXPRESION AS AXIS POSITION
```

14.3 VARIABLE TEST

To test variable Isous uses classic conditional operators = > < <> >= <= !

They are inserted in **IF ELSE END_IF** cycles allowing to execute cycles conditioned to one or more variable. Equal operators (=) can be combined to other logical operators OR (||) AND (&&). Round brackets can be used to prioritize expressions.

Ex:

```
IF $VAR=0 && $VAR1=5
    G1X100
ELSE
    G1X0
END_IF
```

14.4 BIT CONTROL

Isous makes available also operator to control the state of a single bit of a variable. They can be used in **IF ELSE END_IF** cycles or to **set/reset** single bit of a variable. It is also possible make a shift of the bits (left or right) and negate its state. All bit operations can be made only on INTEGER variables (excluding therefore decimal part).

Ex:

```
IF $VAR & 4          // TEST BIT 3 OF $VAR
    G1X100 // BIT IS ON
ELSE
    G1X0          // BIT IS OFF
END_IF

$VAR=$VAR | 1 // SET BIT 1 OF $VAR
$VAR=$VAR & 1 // RESET ALL BITS EXCEPT BIT 1 OF $VAR

$VAR=1
$VAR=$VAR<<3 // $VAR IS SHIFTED LEFT 3 TIME
```

15 VARIABLE TYPES

Isous introduced VARIABLE to increase programming facilities. There are two types of variable: INTEGER o DOUBLE (floating point). Variables can be combined in expression as all other common languages.

15.1 NUMERIC CONSTANTS

All explicit numeric values are numeric constants. Decimal point can be used.

Ex:

```
G1X100.13
$VAR=25.143
```

15.2 GENERIC VARIABLES “\$”

All generic variable are DOUBLE type and they can be used to store values inside PartProgram. When they are inserted in ISO instructions (X,Y,Z ecc) it must be delimited between **square brackets** [...].

Minimum value - **1.79769313486232 E308**

Maximum value **1.79769313486232 E308**

The maximum number of available variables is 2048 and are recognized by \$ prefix followed by an ALPHANUMERIC NAME.

Ex:

```
$VAR=1
$VAR=$VAR1*5
$VAR=SQR($VAR1)
G1X[$VAR]
```

15.3 AXIS POSITION VARIABLES

These variables contain the position value of axis and accordingly they are read only.

The maximum number of these variables is 9. They can be used in PartProgram to read axis position in a given time.

Demand axis position - ReadOnly

- \$[Qn] With n from **0** to **8** it identifies the axis. The value of **DEMAND POSITION** is written in the variable and it refers to a **RELATIVE** value inclusive of WORK ORIGIN and OFFSET
- With n from **100** to **108** it identifies the axis (subtracting 100). . The value of **DEMAND POSITION** is written in the variable and it refers to an **ABSOLUTE** position from HOME position

Actual axis position - ReadOnly

- \$[Rn] With n from **0** to **8** it identifies the axis. The value of **ACTUAL POSITION** is written in the variable and it refers to a **RELATIVE** value inclusive of WORK ORIGIN and OFFSET
- With n from **100** to **108** it identifies the axis (subtracting 100). . The value of **ACTUAL POSITION** is written in the variable and it refers to an **ABSOLUTE** position from HOME position

Relative position Absolute position

n=0 AXIS X	n=100 AXIS X
n=1 AXIS Y	n=101 AXIS Y
n=2 AXIS Z	n=102 ASSE Z
...etc.	...etc.

Ex:

```
IF $[Q0]>100.3 // TEST OF X AXIS DEMAND POSITION
    G101
END_IF
$VAR=$[R1] // READ ACTUAL POSITION OF Y AXIS
```

15.4 DIGITAL INPUT/OUTPUT VARIABLES

These variables allow to read all digital input or set/reset all digital output of CN. Rember digital output can be shared with PLC cycle on CN. This facilities is useful to make a simple PLC structure directly from ISO language without CN programming. I/O variables consider only 0 and 1 values. *These variables when inserted in PartProgram allow direct access to I/O without waiting axis movement sync. Therefore in specific cases can need to use G62 code (wait end movement) to have sync between axis and I/O.*

Input Variables – Read only

- \$[In] Where n is a value from **0** to **255** and it identifies CN input
Value=0, Input OFF - Value=1, Input ON

Output Variables – Read/Write

- \$[On] Where n is a value from **0** to **255** and it identifies CN output
Value=0, Input OFF - Value=1, Input ON

Ex:

```
IF $[I0]=1 // IF 1st INPUT IS ACTIVE
    $[O5]=1 // SET 6th OUTPUT
ELSE
    $[O5]=0 // ELSE CLEAR IT
END_IF
```

15.5 TIMER VARIABLES

These variables are useful to set system TIMERS. Timers can be used to make delays, time-outs, etc. The maximum numbers of timers available is 10. TIMERS are written with a time in milliseconds. After TIMER is set, it starts automatically to decrement until its value reach 0.

Timer Variables – Read/Write

\$[Tn] Where n is a value from **0** to **9** and it identifies the timer number

Ex:

```
$[T0]=1500          // SET TIMER 0 AT 1550 MILLISECONDS (1.5 SECONDS)
@CICLO
IF $[I0]=1
    GOTO EXIT      // EXIT IF INPUT 1 IS ON
END_IF
IF $[T0]=0          // TEST TIMER
    ERROR 10        // IF TIMER ELAPSES STOP PARTPROGRAM WITH ERROR 10
END_IF
GOTO CICLO          // REPEAT CYCLE
@EXIT
```

15.6 TOOL TABLE VARIABLES

They allow to read PARAMETERS from selected TOOL TABLE with **Tn**. The list below describes all parameters available for each TOOL TABLE and, as showed, they are up to maximum of 20 parameters per each tools.

Tool table variable – Read/Write

\$[Un] Where n is a value from **0** to **19** indicating the parameter address

Ex:

\$VAR=\$[U0] // READ DIAMETER OF THE SELECTED TOOL

Address	Description
0	Tool diameter
1	Tool length
2	Maximum tool rpm speed
3	User Define 1
4	User Define 2
5	User Define 3
6	User Define 4
7	User Define 5
8	User Define 6
9	User Define 7
10	User Define 8
11	User Define 9
12	User Define 10
13	User Define 11
14	User Define 12
15	User Define 13
16	User Define 14
17	User Define 15
18	User Define 16
19	User Define 17

15.7 HEAD TABLE VARIABLES

These variables allow to read and write parameters of the selected HEAD TABLE with **Hn**. The list below describes all parameters available for each HEAD TABLE and, as showed, they are up to maximum of 20 parameters per each head.

Tool table variable – ReadOnly

\$[Hn] Where n is a value from **0** to **19** indicating the parameter address

Ex:

\$VAR=\$[H0] // READ OFFSET X

Address	Descrizione
0	Head offset from home position of axis X
1	Head offset from home position of axis Y
2	Head offset from home position of axis Z
3	Head offset from home position of axis A
4	Head offset from home position of axis B
5	Head offset from home position of axis C
6	Head offset from home position of axis U
7	Head offset from home position of axis V
8	Sensor offset from 0 head of axis W
9	Sensor offset from 0 head of axis X
10	Sensor offset from 0 head of axis Y
11	Sensor offset from 0 head of axis Z
12	Sensor offset from 0 head of axis A
13	Sensor offset from 0 head of axis B
14	Sensor offset from 0 head of axis C
15	Sensor offset from 0 head of axis U
16	Sensor offset from 0 head of axis V
17	Sensor offset from 0 head of axis W
18	User Define 1
19	User Define 2

15.8 AXIS COUNTER VARIABLES

They are useful to read axis position from the interpolator. They don't contain the actual axis position but the position where it will be after position command. Generally these variable anticipate axis position before it has reached it. That is very useful for block restart facilities.

Axis counter variables – ReadOnly

\$[Cn] Where n is a value from **0** to **8** indicating the axis

16 LIMIT AXIS VARIABLES

They are useful to read the limit axis setted

Positive Limit – ReadOnly

\$[Nn] Where **n** is a value from **0** to **8** indicating the axis

Negative Limit – ReadOnly

\$[\$n] Where **n** is a value from **0** to **8** indicating the axis

17 PREVIEW PARAMETERS


This variable type reads or sets the Preveiw Parameters (simulation Gcode)

\$[Pn] Where “n” is a value from 0 to 7 that indicates the parameter number

Pn	Descrizione	Valori
0	Enable/Disable Rotative Axis	0 Disable 1 Enable
1	Set axis Z direction for rotative Axis	0 Positive direction downward 1 Negative direction downward
2	Simulation Type	0 Line 1 Mesh 2 Lathe 3 Close Mesh 4 LayerT
3	Enable/Disable Heads Offset	0 Disable 1 Enable
4	Select cursor type	0 Pointer 1 RTCP 10-49 Type Tools where 10 Tool0-11 Tool1 etc. 50-99 Type Blade where 50 blade0 -51 Blade1 etc
5	Index Axis Blade	from 0 to Axis number-1
6	Offset Blade	From 0 to 360
7	Tool Diameter	Positive value only
8	Box Start X	See figure below
9	Box Start Y	See figure below
10	Box Start Y	See figure below
11	Box Size X	See figure below
12	Box Size Y	See figure below
13	Box Size Z	See figure below
14	Show box	Value >0 shows the box with parameters P8..P13. This parameter must be written after the parameters P8..P13 are written

Show box for piece dimensions

With the parameters P8..P14 is possible draw a Box for emulate the piece dimensions in working

**Example:**

```
$[P8]=50      // START X
$[P9]=150    // START Y
$[P10]=0     // START Z
$[P11]=300    // SIZE X
$[P12]=200    // SIZE Y
$[P13]=70     // SIZE Z
$[P14]=1      // SHOWS BOX
```

17.1 GLOBAL VARIABLE

GLOBAL prefix can be applied only to GENERIC variables (\$name) and to use it in M or HM functions. GLOBAL prefix must be used when we want to share a variable between PartProgram and M/HM function, because by default Isous considers LABEL and VARIABLE private.

Ex:

```
//--- EXAMPLE FOR CODE OF PAUSE MACRO
//DEFINE $SAVEX AND $SAVEY AS GLOBAL
GLOBAL $SAVEX
GLOBAL $SAVEY
G62 // WAIT FOR AXIS IN POSITION
$SAVEX=$[Q0] // SAVE AXIS X POSITION
$SAVEY=$[Q1] // SAVE AXIS Y POSITION
G0X0Y0

//--- EXAMPLE FOR CODE OF RESTART FROM PAUSE MACRO
//DEFINE $SAVEX AND $SAVEY AS GLOBAL
GLOBAL $SAVEX
GLOBAL $SAVEY
G0X[$SAVEX] Y[$SAVEY] // MOVE AXIS TO POSITION SAVED IN PAUSE MACRO
G62
```

17.2 M FUNCTION VARIABLES (FOR CN)

These variable are useful to pass parameter to M functions defined in CN. That allows to condition M cycle by the value of them. The parameters must be write before to call M function. The number of passing parameters is defined in configuration up to maximum of 10 (default 5 parameters).

ATTENTION:

The CN get these parameters as integer value.

Ex:

```
// RUN M FUNCTION ON CN PASSING 2 PARAMETER
$_PARM_1=100
$_PARM_2=300
M15
```

17.3 SPECIAL PARAMETERS VARIABLES

They serve to read some parameters of Isous. The list below shows the readable parameters with these variables.

- \$[X0]** Read the current value of SPEED selected by S function - *ReadOnly*
- \$[X1]** Read the index of current WORK ORIGIN - *ReadOnly*
- \$[X2]** Read the index of current WORK OFFSET - *ReadOnly*
- \$[X3]** Read state of WORK ORIGIN – Value 1 if se enabled or 0 if disabled - *ReadOnly*
- \$[X4]** Read state of WORK OFFSET – Value 1 if se enabled or 0 if disabled – *ReadOnly*
- \$[X5]** Read the number of current head selected by H function – *ReadOnly*
- \$[X6]** Read the number of current tool selected by T function – *ReadOnly*
- \$[X7]** Read The RUN Type – *ReadOnly*
 - 0 NORMAL RUN**
 - 1 SIMULATION RUN**
 - 2 GO BLOCK RUN**
 - 3 RETRACE RUN**
 - 4 GCODE EXECUTION TIME CALCULATION RUN**

- X8 Read Last FEED – ReadOnly**
- X9 Read coordinate mode – ReadOnly**
- 0 G90 Absolute**
 - 1 G91 Relative**
- X10 Read work plane activated – ReadOnly**
- 0 XY G17**
 - 1 XZ G18**
 - 2 YZ G19**
 - 1 other**
- X11 Read tool length offset set – ReadOnly**
- 0 None**
 - 1 Value (+/-) tool length offset set**
- X12 Read axis tool length offset set – ReadOnly**
- 0 Axis X**
 - 1 Axis Y**
 - 2 Axis Z**
 - 3 Axis A**
 - 4 Axis B**
 - 5 Axis C**
 - 6 Axis U**
 - 7 Axis V**
 - 8 Axis W**
- X13 Read the button pressed by LIB MESSAGE – ReadOnly**
- X14 Read the type of GoBlock invoked – ReadOnly**
- 0 GoBlock from line or marker**
 - 1 GoBlock from M6Tn**
- X15 Read the Axis Index selected for JOG (Ex: 0=X – 1=Y etc.) – ReadOnly**
- X16 Read the Axis status in Velocity mode – ReadOnly**
- 0 Axis Stop**
 - 1 Axis in Acceleration**
 - 2 Axis in Deceleration**
 - 3 Axis in Velocity reached**
- X17 Read Run from CMD – ReadOnly**
- 0 NORMAL RUN (no CMD)**
 - 1 RUN CMD**
 - 2 RUN SCRIPT CMD**
- X18 Parameter P1 CMD – ReadOnly**
- X19 Parameter P2 CMD – ReadOnly**
- X20 Parameter P3 CMD – ReadOnly**
- X21 Parameter P4 CMD – ReadOnly**
- X22 Parameter P5 CMD – ReadOnly**
- X23 Parameter P6 CMD – ReadOnly**
- X24 Parameter P7 CMD – ReadOnly**
- X25 Parameter P8 CMD – ReadOnly**
- X26 Parameter P9 CMD – ReadOnly**
- X27 Parameter P10 CMD – ReadOnly**
- X28 Parameter X Canned Cycles – ReadOnly**
- X29 Parameter Y Canned Cycles – ReadOnly**
- X30 Parameter Z Canned Cycles – ReadOnly**
- X31 Parameter R Canned Cycles – ReadOnly**
- X32 Parameter P Canned Cycles – ReadOnly**
- X33 Parameter Q Canned Cycles – ReadOnly**
- X34 Parameter K Canned Cycles – ReadOnly**
- X35 Parameter F Canned Cycles – ReadOnly**

17.4 WORK ORIGIN AND OFFSET VARIABLES

These variables contain the current position of WORK ORIGIN and WORK OFFSET. The maximum number of these variables is 9 (one for each axis). They can be used in PartProgram to read the current zero positions.

Work Origin Variable - ReadOnly

\$[Yn] Where n is a value from **0** to **8** indicating the axis. The variable will contain the current position of WORK ORIGIN of axis indicated by n

Work Offset Variable - ReadOnly

\$[Wn] Where n is a value from **0** to **8** indicating the axis. The variable will contain the current position of WORK OFSET of axis indicated by n.

n=0 axis X, n=1 axis Y, n=2 axis Z, etc.

17.5 USER GENERIC VARIABLES

These variables are used to exchange data between CN and Isous. The maximum number available is **30**. They can be read or written and are 32 bit INTEGER type.

User generic variables - Read/Write

\$[Kn] Where n is a value from **0** to **29** indicating the variable

17.6 ARRAY VARIABLES - DIM

These variables are used like to USER GENERIC VARIABLES, but these, are **get/set** by Index.

First to use, is necessary declare the ARRAY DIMENSION with Function DIM, and the VARIABLE ARRAY NAME:

Ex:

DIM \$ARR 10

In the above example, was declared an ARRAY with name ARR with 10 elements.

The ELEMENTS are indexed from 0 to 9

ARRAY USAGE

The ARRAY VARIABLES contain the same values of GENERIC VARIABLES (double).

For Get/Set the value from ARRAY, the INDEX value must be enclosed between “[..]”.

Ex:

```
DIM $ARR 10
$INDEX=0
$VAR=2
LOOP 10
    $ARR[$INDEX]=$VAR*$INDEX
    $INDEX=$INDEX+1
END_LOOP
$INDEX=0
LOOP 10
    G1 X[$ARR[$INDEX]]
    $INDEX=$INDEX+1
END_LOOP
```

17.7 MARKER VARIABLES

Markers are normal variables written in PartProgram. In enhanced programming, using LOOP cycles and VARIABLES, restart from a LINE NUMBER is not enough, because axis position can be defined by variables written in a LOOP cycle. Using MARKERS it's possible restart PartProgram at value of one of these, not at a specific line number, allowing restart also inside LOOP cycles. MARKERS are defined with instruction **MARKER \$NAMEVAR DESCRIPTION**.

Markers can be restored from PlugIn "**BLOCK RESTART**"

Ex:

In the next example it is defined a Marker variable named **\$INC**.

It specifies a counter of the number of piece in working

```
MARKER $INC PIECE NUMBER
```

```
$VAR=0
```

```
$INC=0
```

```
F5
```

```
G1X0Y0
```

```
LOOP 10
```

```
    $INC=$INC+1
```

```
    G1X200
```

```
    $VAR=$VAR+50
```

```
    G0X0Y[$VAR]
```

```
END_LOOP
```

It will be possible restart PartProgram when **\$INC** variable (set as MARKER) takes a specific value.

17.8 VARIABLE FOR ANALOG SPINDLE OUTPUT

Allows to write in the Analog Output a value generally used for the **SPINDLE SPEED**.

Variable Analog Output - Read/Write

\$[A0]=val Where **val** depends of the Channel resolution

SETTABLE CHANNEL

Are available up to **16** different channels. These are set from **MACHINE PARAMETERS** table **SPINDLE** by parameter **SPEED_ANALOG_CH**.

The Channel from 0 to 15 are refer to Analog output on the **NGIO-NGPP** for **NGWARP** or **NGMSX** for **NGMEO**. The **Channel 0** is the first analog output of the **FIRST** board **NGIO-NGPP-NGMSX**, the **Channel 1** is the second analog output of the **FIRST** board **NGIO-NGPP-NGMSX**, The **Channel 2** is the first analog output of the **SECOND** board **NGIO-NGPP-NGMSX** etc

The Channel **NGMEO PWM** is the Analog Output only for **NGMEO** (optional)

The Channels **SPEED_X,Y,Z,A,B,C,U,V,W** are referred to control the Axis in SPEED MODE for the function **G108.4 e G108.5**.

These indicate which axis is connected to **G108.4**

Ex: **SPEED_X**, the **G108.4** function, is connected to Axis X and the **S** function set the speed for this axis

CHANNELS RESOLUTION

The Channels have the following resolution:

Channel 0 a 15 **12 bit** **Value from 0 to 2047**

Channel NGMEO PWM **8 bit** **Value from 0 to 255**

(**WARNING** The PWM Channel can saturate ,i.e. reach the 10V before of 255 value)

The Channel resolution is set from **MACHINE PARAMETERS** table **SPINDLE** by parameter **ANALOG_BIT_RES**.

Therefore set the following values:

Channel 0 -15 **2048**

NGMEO PWM **Max 256 generally a value from 210 to 230**

(First to all set this value to 256 , check by write **\$[A0]** with a value from 210 to 255, when the ouput is 10V this is the correct value for the parameter **ANALOG_BIT_RES**)

Example M3 CW SPINDLE

```
READ_PARMAC "SPEEDMAXSPINDLE" $MAX_RPM // READ MAX RPM AT 10V
READ_PARMAC "ANALOG_BIT_RES" $BIT_RES // READ BIT RESOLUTION
$CURRENT_SPEED=$[X0] // READ THE CURRENT SPEED SET BY S GCODE FUNCTION
$ANALOG_OUT=$CURRENT_SPEED*$BIT_RES/$MAX_RPM // CALC
$[A0]=$ANALOG_OUT // WRITE
$[O1]=1 //SET CW DIRECTION
$[O2]=1 // START
```

17.9 MACRO MANAGEMENT

The **J** variable (Read/Write) allows to Management the internal Macro

\$[Jn]	Valore	Descrizione
\$[J0]	1	Suspend: Mstop,Merror,Mpause,MEndProgram,Mtime,MinterruptDI, MinterruptDO, M50003,M50004,M60001,M60002,M60003,M60004
	0	Resume: Mstop,Merror,Mpause,MEndProgram,Mtime,MinterruptDI, MinterruptDO, M50003,M50004,M60001,M60002,M60003,M60004
\$[J1]	1	Suspend: Mstop
	0	Resume: Mstop
\$[J2]	1	Suspend: Merror
	0	Resume: Merror
\$[J3]	1	Suspend: Mpause
	0	Resume: Mpause
\$[J4]	1	Suspend: MEndProgram
	0	Resume: MEndProgram
\$[J5]	1	Suspend: Mtime
	0	Resume: Mtime
\$[J6]	1	Suspend: MinterruptDI
	0	Resume: MinterruptDI
\$[J7]	1	Suspend: MinterruptDO
	0	Resume: MinterruptDO
\$[J8]	1	Suspend: M50003
	0	Resume: M50003
\$[J9]	1	Suspend: M50004
	0	Resume: M50004
\$[J10]	1	Suspend: M60001
	0	Resume: M60001
\$[J11]	1	Suspend: M60002
	0	Resume: M60002
\$[J12]	1	Suspend: M60003
	0	Resume: M60003
\$[J13]	1	Suspend: M60004
	0	Resume: M60004
\$[J14]	1	Suspend: STOP – Emergency Only
	0	Resume: STOP
\$[J15]	1	Suspend: PAUSE
	0	Resume: PAUSE

18 POSITIONER

Isous provides the complete management of one or more axes positioners. These can be of different type and in any case their management is entrusted to the application of CNC in use VTB

19 PA-PD(n,par)espr Set Absolute position

PA allows movement of the positioner at **ABSOLUTE** target

PD allows movement of the positioner at **RELATIVE** target

n Positioner NUMBER from 0 to MAX

par Controlo parameter OPTIONAL

null Start at TARGET **ESPR** with Pending end of movement

0 Start at TARGET **ESPR** without **Pending end of movement**

1 Start at TARGET **ESPR** with **Pending end of movement**

2 Start HOMING (Espr must be present but not used)

3 Espr >0 Enable positioner

Espr <=0 Disable positioner

Ex:

PA(0)1000 // START AT TARGET 1000 POSITIONER 0
PA(0,0)1000 // START AT TARGET 1000 without pending end of movement
PA(0)[\$VAR] // START AT TARGET\$VAR i
PA(0,2)1// START HOMING
PA(0,3)1// ENABLE POSITIONER 0

20 PF(n)espr Set Positioner FEED

Set the FEED positioner. Espr FEED VALUE

n Positioner NUMBER from 0 to MAX

Ex:

PF(0)100 //FEED 100
PF(0)[\$VAR] // FEED \$VAR

21 PS(n) STOP Positioner

Stop POSITIONER

n Positioner NUMBER from 0 to MAX

Ex:

PS(0) // Stop positioner 0

22 _PM(n,par) Read status Positioner

Read the status postioner

n Positioner NUMBER from 0 to MAX

par Parameter

0 Return 0 Axis Stop fermo - 1 Axis movment

1 READ demand position

2 READ actual position

3 Return 1 axis enabled – 0 axis disabled

4 Return 1 HOMING make– 0 HOMING not make

5 Return 1 axis in ALLARM – 0 OK

Ex:

\$VAR=_PM(0,par)

23 WORK SETTING

In this charter are defined all axis motion functions.

23.1 DEFINITION OF AXIS POSITIONS

They define axis positions in the several interpolation functions (G0-G1-G2-G3). The axis code can be followed by a numeric value or by an expression identifying the position.

AXIS CODES

<i>X</i>	<i>Axis X</i>
<i>Y</i>	<i>Axis Y</i>
<i>Z</i>	<i>Axis Z</i>
<i>A</i>	<i>Axis A</i>
<i>B</i>	<i>Axis B</i>
<i>C</i>	<i>Axis C</i>
<i>U</i>	<i>Axis U</i>
<i>V</i>	<i>Axis V</i>
<i>W</i>	<i>Axis W</i>
<i>I</i>	<i>Arc center for X axis of work plane</i>
<i>J</i>	<i>Arc center for Y axis of work plane</i>
<i>K</i>	<i>Arc center for Z axis of work plane (only for G18 -G19)</i>
<i>R</i>	<i>Arc radius</i>

Syntax

CODE value or expression

Ex:

<i>X100Y20</i>	// POSITION BY NUMERIC VALUE
<i>DX100Y20</i>	// RELATIVE AND ABSOLUTE
<i>X[\$VAR]Y[\$VAR1]</i>	// POSITION BY VARIABLES
<i>X[COS(\$VAR)+\$VAR1]</i>	// POSITION BY EXPRESSION

23.1.1 Axis definition for Channel Address

<i>QX</i>	<i>Channel 0</i>	<i>QY</i>	<i>Channel 1</i>
<i>QZ</i>	<i>Channel 2</i>	<i>QA</i>	<i>Channel 3</i>
<i>QB</i>	<i>Channel 4</i>	<i>QC</i>	<i>Channel 5</i>
<i>QU</i>	<i>Channel 6</i>	<i>QV</i>	<i>Channel 7</i>
<i>QW</i>	<i>Channel 8</i>		

The axis position for channel address, allows to always refer to Axis not considering the AXES NAME

Ex if the axes are called in the following mode:

<i>X</i>	Channel 0
<i>Y</i>	Channel 1
<i>Z</i>	Channel 2
<i>B</i>	Channel 3
<i>C</i>	Channel 4
<i>W</i>	Channel 5

QX,QY etc. always refer to the channel and not at name

So

G1 X100 Y200 B300

Is like to

G1 QX100 QY200 QA300

23.1.2 G90 – PROGRAMMING WITH ABSOLUTE POSITIONS

Syntax

G90

Function type

MODAL (default)

Cancel

G91

Description

All following positions refer to current ZERO (HOME POSITION, WORK ORIGIN, WORK OFFSET), If no work origin or offset are used positions refer directly to home position.

23.1.3 G91 - PROGRAMMING WITH INCREMENTAL POSITIONS

Syntax

G91 G91.1 G91.2

Function type

MODAL

Cancel

G90

Description

All following positions refer to current axis position.


G91.1 Force the values in ABSOLUTE (G90) and store the current state (G90-G91)

G91.2 Resume the state stored with G91.1 (G90 if was G90 or G91 if was G91)

23.1.4 Definition of absolute and incremental positions

Ex:

```
G90          // SET ABSOLUTE POSITIONS
G1X100Y100 // AXIS MOVE TO P1=100,100
G91          // SET INCREMENTAL POSITIONS
X5Y-3       // AXIS MOVE TO P2=105,97
G90          // SET ABSOLUTE POSITIONS
X0Y0         // AXIS MOVE TO P3=0,0
```



23.2 WORK ORIGIN

Isous can manage up to **256 different work origins** selectable by **G94**, **G92** and **USER_ZERO** instructions. A work origin define a point of reference in relationship with home position.

23.2.1 Work origin By INDEX

These origins can be set on the fly by taking the value contained in 'file index' ZERI.VAL ". Unlike USER_ZERO, this can have different indexes for each axis.

Syntax

OXIndex OYIndex

Function type

MODAL

Cancel

G92-G82

Parameters

Index –Index Value from file "ZERI.VAL"

Description

Defines the new origin of the axes based on the value contained in 'index set'

Es:

```
OX0 OY1 OZ3 // SET origin X from INDEX 0, Y Index 1,Z Index 3
```


23.2.2 G94 – Work origin at position defined with parameter

Syntax

G94 Xvalue Yvalue (DX,DY ecc. Relative value)

Function type

MODAL

Cancel

G92-G82

Parameters

X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) followed by origin position


Description

It defines the new origin of one or more axis. Axis not included in parameters list keep the origin unchanged. The new position of zero axis will be defined in the parameter value.

The position value in the parameter refer to an ABSOLUTE position from HOME POSITION regardless of **G90 G91**. The new origin is automatically enabled with G94.

Ex:

G94 X80Y35 // SET NEW WORK ORIGIN AT 80,35



23.2.3 G54, G55, G56, G57, G58, G59 - Work origin from memory file

Syntax

G54 (axis code)

G54 XYZ or G54.n XYZ - G54 QX QY QZ o G54.n QX QY QZ

Function type

MODAL

Cancel

G92-G82

Parameters

X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW)

.n Number of INDEX ZERO (from 0 to 255). If omitted, uses the parameter USER_ZERO to set index

Description

It defines the new origin of one or more axis. Axis not included in parameters list keep the origin unchanged. The new position of zero axis will be defined in the parameter value.

The position value will be get from the ORIGIN FILE made by **PLUGIN WORK ORIGIN**.

The new origin is automatically enabled with these instructions.

If **G54** is invoked without parameters **AXIS X** will be set.

The **G54** function, can use the INDEX ZERO indicate in the .n

G54.n where n is a value from 0 to 255 refered to INDEX ORIGIN

If the parameter .n is omitted, is used USER_ZERO to set index.

The .n parameter not changes the value of USER_ZERO parameter.

Similarly: (these can not use the .n parameter)

G55 for AXIS Y

G56 for AXIS Z

G57 for AXES XY

G58 for AXES YZ

G59 for AXES XZ

Unlike G94, these functions set WORK ORIGIN from a file saved on pc allowing reload of ORIGINS after switch-off.

Ex:

USER_ZERO 0 // uses INDEX 0 (Option default)

G54 XYZ // Set ORIGIN to X Y Z

USER_ZERO 1 // uses INDEX 1

G55 // Set origin Y

G54.2 XYZ // SET Origin on XYZ by INDEX 2

23.2.4 G92 – Work origin in current axis position

Syntax

G92 XYZ etc.

Function type

MODAL

Cancel

G94-G82

Parameters

X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) axis to be zero

Description

It defines the new origin of one or more axis in the current position. Axis indicated are zeroed in current position.

23.2.5 G82 – Work origin in current axis position with sensor offset

(Shifted on G1082 if USE_G80_CYCLES=TRUE)

Syntax

G82 XYZ G82 QX QY QZ etc.

Function type

MODAL

Cancel

G94-G92

Parameters

X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) axis to be zero

Description

It defines the new origin of one or more axis in the current position taking into account acquisition sensor (G102). Axis indicated are zeroed in current position adding sensor offset.

This function must be used with origin acquisition cycles by G102.

23.2.6 G98 – G53 - Suspend work origin

Syntax

G98

G53

Function type

MODAL

Cancel

G82 G92 G94 -G54-G55-G56-G57-G58-G59

Description

It suspends all work origins. All following positions will be refer to HOMING POSITION (if WORK OFFSETS G93 or G95 are disabled)

23.2.7 G99 – Restore work origin

Syntax

G99

Function type

MODAL

Cancel

G98

Description

Restore work origin set with G92 or G94, disabling G98.

23.2.8 G940 MOVE axes excluding WORK ORIGIN only in the actual block

Syntax

G940 G1Xval Yval

Function type

deleting

Description

All axis movements follow G940 are performed with reference to home axes (WORK ORIGIN EXCLUDES)

23.2.9 USER_ZERO – Index of WORK ORIGIN LIST

Syntax

USER_ZERO expression

Function type

MODAL

Parameters

Expression or value indicating the index of ORIGIN LIST to be used

Description


Work origin is enabled with the position indexed in the ORIGIN LIST by USER_ZERO.

Ex:

```

USER_ZERO 0
G94 X20Y20      // STORE ORIGIN 0
USER_ZERO 1
G94 X50Y50      // STORE ORIGIN 1
USER_ZERO 2
G94 X150Y100    // STORE ORIGIN 2
USER_ZERO 0      // ENABLE ORIGIN 0
G1X10Y10        // MOVE TO P1
USER_ZERO 1      // ENABLE ORIGIN 1
G1X10Y10        // MOVE TO P2
USER_ZERO 2      // ENABLE ORIGIN 2
G1X10Y10        // MOVE TO P3

```



23.3 WORK OFFSET

Isous can manage up to **256 different work offsets** selectable by **G93**, **G95** and **USER_OFFSET** instructions. A work offset is an additional work origin respecting G92 and G94 functions. As the last one these define a point of reference in relationship with home position. For example see WORK ORIGIN.

23.3.1 G93 - Work offset at position defined with parameter

Syntax

G93 Xvalue Yvalue (DX,DY ecc. Relative value)

G93 P(n)value DP(n)value for positioner

Or **DOXvalue DOYvalue**

Function type

MODAL

Cancel

G85 G95

Parameters

X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) followed by offset position

Description

It defines the new offset of one or more axis. Axis not included in parameters list keep the offset unchanged. The new position of zero axis will be defined in the parameter value.

The position value in the parameter refer to an ABSOLUTE position from HOME POSITION regardless of **G90 G91**. The new offset is automatically enabled with G93.

23.3.2 G95 - Work offset in current axis position

Syntax

G92 XYZ etc.

Function type

MODAL

Cancel

G85 G93

Parameters

X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) axis to be offset

Description

It defines the new offset of one or more axis in the current position. Axis indicated are zeroed in current position.

23.3.3 G85 - Work offset in current axis position with sensor offset

Syntax

G85 XYZ G85 QX QY QZ etc.etc.

Function type

MODAL

Cancel

G93-G95

Parameters

X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) axis to be zero

Description

It defines the new offset of one or more axis in the current position taking into account acquisition sensor (G102). Axis indicated are zeroed in current position adding sensor offset.

This function must be used with origin acquisition cycles by G102.

23.3.4 G86 - Hardware preset axis on module 360 degrees

Syntax

G86 XYZ etc. G86 QX QY QZ etc.

Function type

IMMEDIATE

Parameters

X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) axis to be preset

Description

The G86 function, is used for rotative axes.

It preset in hardware mode, the absolute axis position to the relative angle.

Ex:

I position axis is 1.450, the relative degrees is 10

23.3.5 G96 - Suspend work offset

Syntax

G96

Function type

MODAL

Cancel

G85 G93 G95

Description

It suspends all work offset. All following positions will be refer to HOMING POSITION (if WORK ORIGINS G92 or G94 are disabled).

23.3.6 G97 - Restore work origin

Syntax

G97

Function type

MODAL

Cancel

G96

Description

Restore work offset set with G93 or G95, disabling G96.

23.3.7 USER_OFFSET - Index of WORK OFFSET LIST

Syntax

USER_OFFSET expression

Function type

MODAL

Parameters

Expression or value indicating the index of OFFSET LIST to be used

Description

Work offset is enabled with the position indexed in the OFFSET LIST by USER_OFFSET.

Ex:

```
USER_OFFSET 0
G94 X20Y20      // STORE OFFSET 0
USER_OFFSET 1
G94 X50Y50      // STORE OFFSET 1
USER_OFFSET 2
G94 X150Y100   // STORE OFFSET 2
USER_OFFSET 0 // ENABLE OFFSET 0
G1X10Y10        // MOVE TO P1
USER_OFFSET 1 // ENABLE OFFSET 1
G1X10Y10        // MOVE TO P2
USER_OFFSET 2 // ENABLE OFFSET 2
G1X10Y10        // MOVE TO P3
```

Refer to ORIGIN example for drawing.

23.4 Work head selection – H function

Isous can manage up to **256 different tools heads**.

Each head refer to home position by the value in the HEADS TABLE.

By default no head is enabled, with Hn function it's possible to select one of 256 available heads (first head =0). All offset (one for each axis) of the selected head will be automatically enabled.

23.4.1 Hn – Select head

Syntax

H expression

Function type

MODAL

Parameters

Expression or value identifying selected head (firts head 0)

Description

Offset of the selected head are enabled.

Ex:

H0 // SELECT FIRST HEAD

23.4.2 G87 – Suspend head offset

Syntax

G87

Function type

MODAL

Cancel

G88

Description

Offset of selected head are disabled.

Ex:

G87 // SUSPEND HEAD OFFSET

23.4.3 G88 – Restore head offset

Syntax

G88

Function type

MODAL

Cancel

G87

Description

Last enabled head offset are restored.

Ex:

G88 // RESTORE HEAD OFFSET

23.5 ROTATIVE AXIS

Isous can manage rotative axis in several modes. G36 function selects mode.

23.5.1 G36 – Rotative axis definition

Syntax

G36 Xmode AXISNAME

Function type

MODAL

Parameters

Mode: 0 → Disable (set linear axis)

1 → Shorter path.

2 → Always positive

3 → Always negative

4 → Shorter path when G1, disabled when G2/G3

AXISNAME name of rotative axis (ex A,B etc.)

Description

Mode 1,4 - Shorter path

CN chooses the shorter path to reach the position selected.

Mode 4 is similar to mode 1 but in G2/G3 interpolation this facilities is disabled.


Ex:

G36 X1 A


G1 A45

G1 A315

first movement **G1 A45**



second movement **G1 A315**



Mode 2,3 – Always positive/negative


The selected axis rotates always in the same sense.

G36 X2 A


G1 A45

G1 A315

first movement **G1 A45**



second movement **G1 A315**



23.6 HARDWARE PRESET OF AXIS

In particular cases can be necessary preset axis positions in Hardware mode allowing to avoid Overflow in single direction axis.

Hardware preset must be used with particular attention, because if axis works with a following error, it doesn't take into consider. Consequently it's possible to lost encoder pulses and reference to home position.

23.6.1 G89 – Hardware preset of axis position

Syntax

G89 Xvalue Yvalue (DX,DY ecc. Relative value)

Function type

DIRECT

Cancel

All origin and offset functions

Parameters

X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) followed by preset value

Description

It defines a new value for current axis positions.

23.7 HARDWARE PRESET OF AXIS

In some cases it is necessary to preset the counters of the axes after recovering from a PAUSE, or to RETRACE. This is because during the PAUSE or first RETRACE, the axes are moved using special functions (shift-type etc..).

Not properly updating the counters, abnormal movements may occur during the step of interpolation axes. Generally counters axes are always updated and therefore there is no need an update, but there are cases such as those listed above that require an update. Always use an upgrade at the end of the axis M of recovery from the PAUSE by RETRACE is still a good thing .

23.7.1 G84 – Preset Axes counters

(Shifted on G1084 if USE_G80_CYCLES=TRUE)

Syntax

G84 X Y Z G84 QX QY QZ....

Function type

DIRECT

Parameters

X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) axes to update

Unless indicated no axis are updated all axes

Description

The G84 function copies the values of the coordinates axes by process (typically taken from PAUSE or RETRACE) the process of WORK.

23.7.2 G83 – Preset CPU 1 counters

(Shifted on G1083 if USE_G80_CYCLES=TRUE)

Syntax

G83

Function type

DIRECT

Description

The G83 function is only used to force the update of the counters of the CPU 1, the one that works on MACRO PAUSE, STOP, ERROR.

it is advisable to start with the MACRO code G83

23.8 CANNED CYCLES

IsoUs Use 4 Canned Cycles:
G81,G82,G83,G84 (G1081,G1082,G1083,G1084)


23.8.1 *G1080 – Disabled Canned Cycles* (Shifted on G80 if USE_G80_CYCLES=TRUE)

Syntax
G1080

23.8.2 *G1081 – Drilling Cycle* (Shifted on G81 if USE_G80_CYCLES=TRUE)

Syntax
G1081 Xval Yval Zval Rval Kval Fval

X X position first drilling (optional) not inserted start for current point
Y Y position first drilling (optional) not inserted start for current point
Z Drilling Depth
R Disengagement
K Repetition (Optional) Active only if G91 and X or Y is inserted)
F Drilling Feed (Optional)




23.8.3 G1082 – Drilling Cycle

(Shifted on G82 if USE_G80_CYCLES=TRUE)

Syntax**G1082 Xval Yval Zval Pval Rval Kval Fval**

- X** X position first drilling (optional) not inserted start for current point
- Y** Y position first drilling (optional) not inserted start for current point
- Z** Drilling Depth
- P** Dwell Ms
- R** Disengagement
- K** Repetition (Optional) Active only if G91 and X or Y is inserted)
- F** Drilling Feed (Optional)




23.8.4 G1083 – Drilling Cycle

(Shifted on G83 if USE_G80_CYCLES=TRUE)

Syntax**G1083 Xval Yval Zval Rval Qval Kval Fval**

- X** X position first drilling (optional) not inserted start for current point
- Y** Y position first drilling (optional) not inserted start for current point
- Z** Drilling Depth
- R** Disengagement
- Q** Increase
- K** Repetition (Optional) Active only if G91 and X or Y is inserted)
- F** Drilling Feed (Optional)




23.8.5 G1084 – Tapping Cycle

(Shifted on G84 if USE_G80_CYCLES=TRUE)

Syntax**G1084 Xval Yval Zval Pval Rval Kval Qval Fval**

- X** X position first drilling (optional) not inserted start for current point
- Y** Y position first drilling (optional) not inserted start for current point
- Z** Tapping Depth
- P** Dwell Ms
- R** Disengagement
- K** Repetition (Optional) Active only if G91 and X or Y is inserted)
- Q** Tapping STEP (mm) only for INTERPOLATE MODE (**MODE_G84=TRUE**)
- F** Tapping Feed (Optional)



- 1) Move in G0 X,Y
- 2) Move in G0 ad R
- 3) Tapping in G1 to Z interpolate with Axis A A (Set S and F ROT_G84 parameter defines CW or CCW rotation)
- 4) Dwell P Ms
- 5) Return in G0 to R

23.9 SELECT WORK PLANE

Work plane defines:

- The plane for circular interpolation
- The plane where to calculate the axis stop (fast interpolation G60)
- The plane where to calculate the radius tool compensation

23.9.1 G17 – Select work plane on X-Y

Syntax

G17

Function type

MODAL

Cancel

G18 G19 G70

23.9.2 G18 - Select work plane on X-Z

Syntax

G18

Function type

MODAL

Cancel

G17 G19 G70

23.9.3 G18.1 - Select work plane on X-Z but not in PREVIEW

Syntax

G18.1

Function type

MODAL

Cancel

G17 G19 G70

Select the work plane on X-Z, but in PREVIEW remains X-Y

23.9.4 G19 - Select work plane on Y-Z

Syntax

G19

Function type

MODAL

Cancel

G17 G18 G70

23.9.5 G19.1 - Select work plane on Y-Z but not in PREVIEW

Syntax

G19.1

Function type

MODAL

Cancel

G17 G18 G70

Select the work plane on Y-Z, but in PREVIEW remains X-Y

23.9.6 **G70** - Select work plane on axis by parameters

Syntax

G70 AXIS1 AXIS2

Function type

MODAL

Cancel

G17 G18 G19

Parameters

Name of the couple of axis formed the new work plane

Ex:

G70XA // select work plane on axis X and A

G70QXQA // select work plane on Channel 0 Channel 3

23.10 START SEARCH OF HOME POSITION

With G71 function Isous allows to execute searching of home position directly in PartProgram. It can be used, for example, when there are spindle axis with double function:

SPEED AXIS
CONTROLLED AXIS

In these cases when we switch function mode to a controlled axis it will be necessary to make searching of home position.

23.10.1 G71 – Start Homing cycle

Syntax

G71 AXIS

Function type

DIRECT

Parameter

Name of axis to be homed

Description

It starts searching of home position for selected axis. Searching mode is defined by machine parameter RZERO_MODE. PartProgram waits for ending of homing procedure.

However STOP PROGRAM is always active. By the parameter of configuration TIME_OUT_HOME can be generated an error (1005 Time Out axis Home) if searching isn't terminated in the set time.

Ex:

G71 X

23.10.2 G71.1 Enable Axis

Syntax

G71.1 AXIS

Function type

DIRECT

Parameter

Name of axis to be enabled

Description

Enable the Axis selected

Ex:

G71.1 X

23.10.3 G71.2 Disable Axis

Syntax

G71.2 AXIS

Function type

DIRECT

Parameter

Name of axis to be disabled

Description

Disable the Axis selected

Ex:

G71.2 X

23.11 AXIS MOVEMENT FUNCTIONS

23.11.1 G0 – Rapid positioning

Syntax

G0

Function type

MODAL

Cancel

G1 G2 G3

Description

G0 defines linear movement type with maximum axis speed.

Maximum speed of each axis is defined by machine parameters.

Isous use a specific calculation of axis speed reducing to minimum the axis STRESS during rapid positioning. Unlike other CN where G0 defines **NOT-INTERPOLATED** movement, Isous move axis always in **INTERPOLATION** mode, but calculating the best speed. In this mode we can obtain always a **FLUID MOTION** where all axis start and arrive simultaneously. Furthermore it is used a specific **ACCELERATION** parameter different from the working one. It is recommended to use G0 only for movement with tool not in working.

Ex:

G0X0Y0Z0 // MOVE TO 0,0,0 POSITION

23.11.2 G0.1 – Rapid positioning with private Acceleration

Syntax

G0.1 AxisName Value

Function type

Immediate

Cancel

G1 G2 G3

Description

G0.1 defines linear movement type with maximum axis speed with private Acceleration. The Acceleration is got from **ACC_G0.1_AxisName** parameter. Only one axis at time can be insert in the **G0.1** function. The others features are the same of **G0**.

Ex:

G0.1 X0 // MOVE TO 0 POSITION

23.11.3 G1 – Linear interpolation at programmed F speed

Syntax

G1

Function type

MODAL

Cancel

G0 G2 G3

Description

G1 defines linear interpolation mode at programmed speed. If movement are on selected work plane and it's enabled **FAST interpolation (without stop on edge)** G60, Isous calculates automatically stop on edge. G1 enables movement at programmed F speed and can be modified by override potentiometer (if not disabled with G11). According to CN we can obtain different performance about number of segment processed in a time unit. Cn of NG35 series process about **350 segments per second**, instead **120** for CN of NGM13 series. That defines the maximum working velocity when the path is formed by **micro-segments**. All CN have a movement buffer, Isous tries to maintain it full (in G60 mode). If buffer empties CN stops axis obtaining a not fluid movement.

Ex:

G1X300Y200Z20

23.11.4 G1.1 – G1-G2-G3 Suspension and Set G0

Syntax

G1.1

Function type

Immediate

Cancel

G1 G2 G3

Description

G1.1 save the current Gx setted (G1 G2 G3) and force a G0 for the next movements

Ex:

G1.1X300Y200Z20

23.11.5 G1.2 – Resume Gx saved with G1.1

Syntax

G1.2

Function type

Immediate

Cancel

G0

Description

G1.2 Resume the G saved with G1.1

Ex:

G1.2X300Y200Z20

23.11.6 G2/G3 - Circular interpolation at programmed F speed

Syntax

G2 (cw)

G3 (ccw)

Function type

MODAL

Cancel

G0 G1

Description

G2 and G3 define circular interpolation at programmed speed. If movement are on selected work plane and it's enabled **FAST interpolation (without stop on edge) G60**, Isous calculates automatically stop on edge. G2 and G3 enable movement at programmed F speed and can be modified by override potentiometer (if not disabled with G11).

Circular interpolation can be executed by center parameters I and J, or by radius parameter R. With the second one it's not possible to generate a complete circle, for that it must be used I and J.


SHORT WAY and LONG WAY arc

Using radium parameter there are two arcs defined by the same parameters. The selection is via radius sign.

If RADIUS is positive a SHORT WAY ARC is generated.

If RADIUS is negative a LONG WAY ARC is generated.

See the example for details.



Ex:

G0X100Y100

G2X300Y100R-150 // EXECUTE LONG WAY ARC

G0X100Y100

G2X300Y100R150 // EXECUTE SHORT WAY ARC

23.11.7 G30 - Enable automatic insert of fillet on edges

Syntax

G30 Rradius Aangle

Function type

MODAL

Cancel

G33

Parameters

R *value of fillet radius (radius=0 disables the function)*

A *Angle degree of insert threshold*

Description


G30 inserts automatically fillets on edges. The fillet radius is defined with parameter R, parameter A defines the angle threshold under which G30 function doesn't intervene leaving path unchanged. This function is useful to soften movement in angular path.

Fillet is inserted only if it can be container inside two segment.

Setting a RADIUS=0 the function is disabled.


Ex:

```
// NORMAL PATH WITHOUT G30
G0 X75.45 Y157.46
G1 X107.84 Y167.43
G1 X108.3 Y142.73
G1 X117.36 Y150.44
G1 X126.2 Y139.34
G1 X140.92 Y142.51
```



Ex:

```
// SAME PATH USING G30
G0 X75.45 Y157.46
G30 R5 A20 // RADIUS=5 ANGLE=20 deg.
G1 X107.84 Y167.43
G1 X108.3 Y142.73
G1 X117.36 Y150.44
G1 X126.2 Y139.34
G1 X140.92 Y142.51
```



G31 – Suspend of automatic insert of fillet**Syntax****G31****Function type***MODAL***Cancel****G30****Description**

Suspend G30. It can be restore with G32.

23.11.8 G32 - Restore of automatic insert of fillet**Syntax****G32****Function type***MODAL***Cancel****G31****Description**

Restore G30 suspended by G31.

23.11.9 G33 - Enable automatic insert of bevel on edges**Syntax****G33 Rlen Aangle****Function type***MODAL***Cancel***G30***Parameter**

- R** *length of bevel (len=0 disables the function)*
- A** *Angle degree of insert threshold*

Description


G33 inserts automatically bevels on edges. The bevel length is defined with parameter R, parameter A defines the angle threshold under which G33 function doesn't intervene leaving path unchanged. This function is useful to soften movement in angular path.

Bevel is inserted only if it can be container inside two segment.

Setting a RADIUS=0 the function is disabled.


Ex:

```
// NORMAL PATH WITHOUT G33
G0 X75.45 Y157.46
G1 X107.84 Y167.43
G1 X108.3 Y142.73
G1 X117.36 Y150.44
G1 X126.2 Y139.34
G1 X140.92 Y142.51
```



Ex:

```
// SAME PATH USING G33
G0 X75.45 Y157.46
G33 R5 A20 // LEN=5MM ANGLE=20 deg.
G1 X107.84 Y167.43
G1 X108.3 Y142.73
G1 X117.36 Y150.44
G1 X126.2 Y139.34
G1 X140.92 Y142.51
```



Len=5 mm

23.11.10 *G34 - Suspend of automatic insert of bevel***Syntax****G34****Function type***MODAL***Cancel***G33***Description**

Suspend G33. It can be restore with G35.

23.11.11 *G35- Restore of automatic insert of bevel***Syntax****G35****Function type***MODAL***Cancel***G34***Description**

Restore G33 suspended by G34.

23.11.12 G102 – Start searching sensor position**Syntax****G102****Function type***DIRECT***Description**

It start acquisition from sensor.

Axis move to positions selected by X,Y,Z etc. The values refer to an absolute or relative position according with G90 G91. Selected **WORK ORIGIN** and **WORK OFFSET** are considered too. More axis can be move simultaneously (interpolated) and the speed is set with the machine parameter **ACQ_VEL**.

Also a acquisition mode can be selected by machine parameter **ACQ_MODE**.

Executing can be stopped by activation of **SENSOR** or by reaching **TARGET** position. In the first case PartProgram continues to execute from next block to G102.

In case of reaching of **TARGET** position PartProgram ends with **ACQ. SENSOR ERROR**.


G102 waits for axis stop before to proceed with acquisition cycle.

Ex:

G90

G102 X100 // ACQUISITION MOVING ONLY AXIS X UP TO POSITION 100

G92 X // SET WORK ORIGIN IN ACQUIRED POINT



23.12 PROGRAMMING AXIS INTERPOLATION SPEED

Interpolation speed is a very important parameter to obtain a fine working. Speed value is expressed in Mt/min with a resolution dependent by Isous configuration. Selected interpolation speed can be changed in automatic way (arc auto-reduction), or manually with parameter **F** or override potentiometer. F parameter acts only when invoked in PartProgram and however at begin of next segment, OVERRIDE potentiometer instead acts in any time allowing immediately change of speed.

23.12.1 **F – Speed of axis interpolation**

Syntax

Fval

Function type

MODAL

Parameter

Val *Value in Mt/min of speed*

Description

F function set vectorial speed of the axis. Such speed will be separated by interpolator according with the programmed trajectory.

G0 movement are not affected by parameter F.

Ex:

```
G0 X75.45 Y157.46      // RAPID MOVEMENT AT F MAX
F10.3                  // SET AXIS SPEED AT 10.3 MT/MIN
G1 X107.84 Y167.43
```

23.12.2 **ARC speed auto-reduction**

Function type

Configuration programming

Parameter

See Isous configuration

Description

Isous uses a special algorithm which allows to reduce automatically axis speed during circular interpolation. It simplifies F programming in path formed by arcs without to insert an appropriate speed for each arc (lower speed for lower radius – bigger speed for bigger radius), Isous does it for you.

The calculation is base on the centrifugal acceleration and it must be manually searched experimentally .

23.13 Work Plane Transformation

Here they are explained all function relative to manage with work plane such as: rotation and mirror.

23.13.1 G120 – Vertical mirror

Syntax

G120

Function type

MODAL

Cancel

G121

Description


It enables vertical mirror on selected work plane. It acts inverting automatically the sign of axis Y.

Ex:

```

G121 // DISABLE G120
// ***** EXECUTE FIRST SQUARE
G0 X100 Y100
G1 X150
Y50
X100
Y100
// ***** END FIRST SQUARE
G120 // ENABLE VERTICAL MIRROR
// ***** EXECUTE SECOND SQUARE
G0 X100 Y100
G1 X150
Y50
X100
Y100
// ***** END SECOND SQUARE

```



23.13.2 G121 – Disable vertical mirror

Syntax

G121

Function type

MODAL

Cancel

G120

Description

Disable vertical mirror on work plane.

23.13.3 G24 – Horizontal mirror

Syntax

G24

Function type

MODAL

Cancel


G25

Description

It enables horizontal mirror on selected work plane. It acts inverting automatically the sign of axis X.

Es:

```
G25 // DISABLE G24
// ***** EXECUTE FIRST SQUARE
G0 X100 Y100
G1 X150
Y50
X100
Y100
// ***** END FIRST SQUARE
G24// ENABLE VERTICAL MIRROR
// ***** EXECUTE SECOND SQUARE
G0 X100 Y100
G1 X150
Y50
X100
Y100
// ***** END SECOND SQUARE
```



23.13.4 G25 – Disable horizontal mirror

Syntax

G25

Function type

MODAL

Cancel

G24

Description

Disable horizontal mirror on work plane.

23.13.5 G22 – Exchange axis of work plane

Syntax

G22

Function type

MODAL

Cancel

G23

Description

Axis of work plane are exchanged between them (ex. X with Y).

23.13.6 G23 – Restore axis of work plane**Syntax****G23****Function type***MODAL***Cancel****G22****Description**

Restore the original axis of work plane.

23.13.7 G26 – Exchange axis by parameter**Syntax****G26 Axis1 Axis2****Function type***MODAL***Cancel****G27****Description**

A couple of selected axis by parameters are exchanged between them.

Ex:

G26 YZ // EXCHANGE Y WITH Z**G26 QYZ // EXCHANGE CHANNEL 1 WITH CHANNEL 2****23.13.8 G27 – Suspend G26****Syntax****G27****Function type***MODAL***Cancel****G26****Description**

It suspends the axis exchanging set with G26

23.13.9 G28 – Restore G26

(Shifted on G1028 if USE_G80_CYCLES=TRUE)

Syntax**G28****Function type***MODAL***Cancel****G27****Description**

Restore axis exchanging set with G26

23.13.10 *G1028 – Return to Home*

(Shifted on G28 if USE_G80_CYCLES=TRUE)

Syntax**G1028 Xval Yval Zval....****Description**Return to **HOME**, the Axes values are indicates in the parameters **G28HOME_X**, **G28HOME_Y** etc.**Xval,Yval,Zval** etc. Optional Parameters

If they are inserted before to go to HOME position the Axes are moved to Xval,Yval,Zval position

The FEED is get to previous F set or the G0 function

23.13.11 *G51 – Suspend work plane rotation***Syntax****G51****Function type****MODAL****Cancel****G50 G52****Description**

Suspend the rotation of work plane.

23.13.12 *G52 – Restore work plane rotation***Syntax****G52****Function type****MODAL****Cancel****G51****Description**

Restore last work plane rotation set with G50.


23.13.13 *G50 - Work plane rotation***Syntax****G50 Xcenterx Ycentery Zangle (DX,DY Relative value)****Function type****MODAL****Cancel****G51****Parameters****X Rotation center axis X****Y Rotation center axis Y****Z Rotation angle in degree****Description**

It execute a rotation of work plane. All following position will be modified with this transformation.

At each start of PartProgram rotation center is disabled.

Ex:

```
// ROTATION OF A SQUARE
$ROT=0
LOOP 24
G0 X100 Y100
G1 X150
Y50
X100
Y100
$ROT=$ROT+15// INCR. ANGLE
G50 X100 Y50 Z[$ROT]// ROTATION
END_LOOP
```



23.13.14 *G1050 – Disable Scaling***Syntax****G1050****Function type***MODAL***Cancel*****G1051*****Description**

G1050 function, disable SCALING G1051

23.13.15 *G1051 – Enable Scaling***Syntax****G1051 Xcentrox Ycentroy Zcentroz IratioX Jratioy Kratioz Pratioxyz****Function type***MODAL***Cancel*****G1050*****Parameters**


- X** *X Scaling Center – se non inserito viene presa la posizione attuale dell' asse X*
- Y** *Y Scaling Center – se non inserito viene presa la posizione attuale dell' asse Y*
- Z** *Z Scaling Center – se non inserito viene presa la posizione attuale dell' asse Z*
- I** *X Ratio – X<1 reduces X>1 increases - if it is not inserted, uses the previous value*
- J** *Y Ratio – Y<1 reduces Y>1 increases - if it is not inserted, uses the previous value*
- K** *Z Ratio – Z<1 reduces Z>1 increases - if it is not inserted, uses the previous value*
- P** *XYZ Ratio – P<1 reduces P>1 increases – Uses the same Ratio for X,Y,Z*

IF NO PARAMETERS ARE INSERTED (Only G1051) the previous values are used**Description**


G1051 allows to scaling the Gcode with X,Y,Z Coordinate center.

Ex:

```
//ORIGINAL
G0X0Y0
G1X10Y10
Y20
X20
Y10
X10
G0X0Y0
//SCALING
G1051 X15Y15I0.5J0.5
G1X10Y10
Y20
X20
Y10
X10
G0X0Y0
//SCALING
G1051 X15Y15I2J2
G1X10Y10
Y20
X20
Y10
X10
```

**Ex:**

```
//ORIGINAL
G0X0Y0
G1X10Y10
Y20
X20Y30
G3X40Y30R10
G1X50Y20
X50Y10
X10Y10
G0X0Y0
//SCALING
G1051 X30Y20I0.5J0.5
G1X10Y10
Y20
X20Y30
G3X40Y30R10
G1X50Y20
X50Y10
X10Y10
G0X0Y0
```



23.13.16 *G103 – Set RTCP parameters***Syntax****G103 Xval Yval Zval G103 QXval QYval QZval****Function type*****MODAL*****Parameters****X Value of parameter X****Y Value of parameter Y****Z Value of parameter Z****.....****Description**

Isous uses a **RTCP** (rotate tool center point) adaptable to any geometry of the machine. Therefore the value passed to function by G103 (max 9 value X,Y,Z,A,B,C,U,V,W) will determine the right parameters for a specific geometry. The calculation of RTPC must be set in installation phase and it will be necessary the intervention of a specialized technician. **G103** passes the parameters to CN without enabling RTCP function. Enable/disable is demanded to **G104-G105** function.

23.13.17 *G104 – Enable/restore RTCP***Syntax****G104****Function type*****MODAL*****Cancel*****G105*****Description**

G104 enable or restore RTCP function on CN.

23.13.18 *G105 – Disable RTCP***Syntax****G105****Function type*****MODAL*****Cancel*****G104*****Description**

G105 disable RTCP function on CN restoring normal interpolation. RTCP function can be restored with **G104**.


24 TOOL RADIUS COMPENSATION

ISOUS manages the tool offset compensation, that can be activated with G41 and G42 ISO function. This functions allow to adjust the tool track, according the tool diameter. Using this mode, it's possible to have some interference on tool track, if we have high diameter tools.

ISOUS can display on its interface, a graphic preview, where will be showed interfering points, due to make possible to adjust the track, previous the work start.

However the tool compensation will take high attention on the track elaboration.

Furthermore it will insert automatically connection arcs (with tool radius as arc radius) , if the intersection point of the compensation tracks, is very far away from real intersection point.



24.1.1 G41/G42 – Enable left/right radius tool compensation

Syntax

G41

Function type

MODAL

Cancel

G40

Description

G41 Enable left compensation.

G42 Enable right compensation.

Tool diameter is set by **D** function or by tool table **Tn**.

24.1.2 G40 – Disable radius tool compensation

Syntax

G40

Function type

MODAL

Cancel


G41 - G42

Description

G40 disables the radius tool compensation (both left and right).

PATH WITH G41**Ex:**

```
D5 // DIAMETER=5mm
G41 // LEFT COMP.
G0 X30 Y40
G1 X10 Y10
G1 X50 Y30
G2 X80 Y30 R15
G1 X90 Y25
G1 X110
G1 X130 Y20
G40
```

**PATH WITH G40****ADDING ARC****Ex:**

```
D5 // DIAMETER=5mm
G42 // RIGTH COMP.
G0 X30 Y40
G1 X10 Y10
G1 X50 Y30
G2 X80 Y30 R15
G1 X90 Y25
G1 X110
G1 X130 Y20
G40
```

**PATH WITH G42****24.1.3 D – Tool diameter****Syntax****Dvalue****Function type***MODAL***Cancel****Tn** (*optional correction set by TOOL TABLE*)**Parameter****Value** *Tool diameter in mm***Description**

D allows to set the value in mm of tool diameter to be used with G41 G42.

Tool diameter D must be set before G41-G42 and it must not changed until the compensation remains active.

24.1.4 G47 – Set tool entry mode

Syntax


G47 Xval

Function type

MODAL


Description

G47 allow to choose two modes of tool entry. The default mode is **G47 X0**: compensation starts on next segment. With **G47 X1** compensation starts immediately and it is useful with closet shape.



Ex. Working with **G47 X0** (default)

Ex. Working with **G47 X1**



NOTE:

Using G47X1 tool must be positioned in start point byl PartProgram (so already shifted from shape of tool radium). The end of compensation instead must follow this scheme:

G0 Z (UP) // raise Z

G40 // disable compensation

G1 Z (UP) // raise Z again

Example for compensation of a square:

G47 X1

F 2.5

G0 X 26.2332 Y 26.1708 // move tool on start point

F 5

G1 Z 0 // move Z to work position

D 3 // set tool diameter

G42 // enable compensation G42

G1 X 24.7332 Y 26.1708

G1 X 24.7332 Y 76.1708

G1 X 74.7332 Y 76.1708

G1 X 74.7332 Y 26.1708

G1 X 24.7332 Y 26.1708

G0 Z 20 // raise Z


G40 // disable compensation

G1 Z 20 // raise Z again

24.2 TOOL LENGTH COMPENSATION

It's possible to compensate tool length on any axis. It is useful when we want to work the same PartProgram with tools of different length. Tool length compensation acts only in the direction selected by G43 function.

The axis affected by compensation is selectable as well as length of correction. Length correction compensates movement on the selected axis. The effective tool length must be the measure of projection tools from spindle.



24.2.1 G43 – Enable tool length compensation from parameter

Syntax

G43 Xlen Kmode AXISdir(+/-) (DX Relative value)

Function type

MODAL

Cancel

G45 (*optional correction set by Tool Table*)

Parameters

len *tool length in mm es: 12.35*

If LEN=0 tool length is taken by tool table Tn

Mode *Optional K parameter, this can have the following values:*

K0 *Normal Mode how if K is omitted*

K1 *With this parameter, the tool length is used as additional OFFSET, therefore the axis value (ABSOLUTE,RELATIVE) is immediately updated
In this mode the "dir" parameter is not considered, the direction is defined by "LEN" sign (+ or -)*

K2 *As K1 but the sign of LEN TOOLS from table is inverted*

AXIS *Axis on which apply length compensation*

dir *Direction of compensation*

+ positive

- negative

Description

G43 enables tool length compensation. Corrections are applied only in the selected axis.

Ex:

G43 X10.3 Z+ // ENABLE POSITIVE COMPENSATION ON AXIS Z OF LEN=10.3mm

24.2.2 **G44 – Disable tool length compensation G43**

Syntax

G44

Function type

MODAL

Cancel

G43

Description

G44 disable tool length compensation set with G43

24.2.3 **G44.1 (2) – Suspend/Resume G43**

Syntax

G44.1 // Suspend G43

G44.2 // Resume G43 with old parameters

Function type

MODAL

Cancel

G43

Parameters

24.2.4 **G45 – Enable tool length compensation from tool table T**

Syntax

G45 AXISdir(+/-)

Function type

MODAL

Cancel

G43 (*optional correction set by Tool Table*)

Parameters


AXIS	Axis on which apply length compensation
dir	Direction of compensation
	+ positive
	- negative

Description

G45 works like G43 but the length of tool is taken only in the tool table with **Tn**.

Ex:

G45 Z+ // ENABLE POSITIVE TOOL LENGTH COMPENSATION ON AXIS Z



24.2.5 *G46 -- Disable tool length compensation G45*

Syntax

G46

Function type

MODAL

Cancel

G45

Description

G46 disable tool length compensation set with G45

24.3 INTERPOLATION MODES

Isous can use several axis interpolation modes allowing to adapt it in a lot of types of machine.

24.3.1 G60 – Enable FAST interpolation without stop on segments

Syntax

G60

Function type

MODAL


Cancel

G61

Description

G60 enables interpolation without stop on segments. The threshold of angle under which axis don't stop is set by machine parameter.

In the points where axis don't stop, it is generated an optimal trajectory minimizing error. **G60** avails a buffer of movements inside CN which can be set from a value up to **1024** on NG35 series. It allows to work in fluid way paths formed by micro-segments.



24.3.2 G61 – Enable interpolation with stop on segments

Syntax

G61

Function type

MODAL

Cancel

G60

Description

G61 enables interpolation with stop on segment. In this interpolation mode axis are stop at the end of each segment.

24.3.3 G62 – Wait for stop axis

Syntax

G62

Function type

MODAL

Description

G62 waits until axis are stopped and movement buffer is empty. It is useful when CN is in fast interpolation and we need to wait all movements are terminated. Obviously It is obsolete working in G61 (stop on segment).

24.3.4 G63 – Interpolation outside work plane (PX_MOVETO)

Syntax

G63

Function type

MODAL

Cancel

G64-G65

Description

G63 enables interpolation with axis outside work plane. In this way it's possible to work trajectories in the space (3D) without to consider the work plane.

The stop on segment is programmed by G62. G63 is particularly useful in 3D working where movement is formed by three or more axis. Generally in this interpolation mode are executed working from CAM at which is demanded the calculation of edge on segments inserting G62 in the fit point.

24.3.5 G64 – Interpolation on work plane (default)

Syntax

G64

Function type

MODAL

Cancel

G63-G65

Description

G64 enables interpolation mode considering the work plane. This is the default mode selected on CN. **G64** calculates vectorial speed only with the axis of work plane (PX_LINETO), moving consequently the other.

Isous verifies automatically if there are movement of the work plane axis, otherwise it works as G63.

Using this mode it can verify some inconvenient when the two axis of the work plane do very little movement. The following example explains that.

G68 MUST BE ENABLED

Ex:

G64

G17

G1X0.001Y0.001Z10

In the above example axis X and Y on work plane move very little in relation to axis Z causing an high speed on axis Z that can be bigger than its limit.

The solution to that is the following:

G63

G17

G1X0.001Y0.001Z10

G64

Enabling interpolation outside work plane, Isous calculates the vectorial speed with all axis instead only the two axis of work plane.

24.3.6 G65 – Enable 3D interpolation PX_MOVETO with calculated stop on edge by parameters

Syntax

G65

Function type

MODAL

Cancel

G63-G64

Description

G65 Enables 3D interpolation calculating stop on edge by CN parameters.

G63-G64 MUST NOT BE ENABLED

Ex:

G65

G1X100Y100Z10

In the example PX_MOVETO (interpolation outside work plane) is used and stop on edge is calculated automatically by CN.

24.3.7 G75 – Enable G64 for movement inside the work plane , G65 for movement outside the work plane

Syntax

G75

Function type

MODAL

Cancel

G63-G64

Description

G75 Enable interpolation 2D **G64** when the movements are inside the work plane with **SGLP**, Enable interpolation 3D **G65** when the movements are outside the work plane with **SGL3D**.

G63-G64 MUST NOT BE ENABLED

24.3.8 G66 – AFC – Adaptive Feed Control

Syntax

G66 Xval Yvin Zval Aval

Function type

Disabled when PartProgram start

Parameters

Xval

0=disable AFC, 1=Enable AFC

if greater than 1, is carried out a moving average on the value of F calculated and the number of samples indicated in xVal. This makes it more "soft" means the change of the F calculated.

Yvin

(optional) axis inertia

Vin > 1 deceleration space increases


If it isn't present Vin=1 is set (no inertia)

Zval

(optional) Indicates the values of Delta F to below which are not considered.

ex:

Val = 0.3, a delta F d 0.3 or less is not considered and therefore the F is left to the previously calculated.



Aval

Minimum value below which is not diminished the F

Ex: if Val = 0.1 to 0.1 lower values of F are limited to 0.1

ATTENTION

To correct working of G66, also G69 (look ahead depth) must be set

Description

G66 enables the **AFC** filter to auto-calculate interpolation speed by path type. With **SGLAFC_n** parameters, the **AFC** algorithm computes the optimal speed for each segment. The analysis of speed is carried out in the **look ahead** segments buffer (set by **G69**). Obviously more the buffer is deep, more the result is accurate. The **AFC** algorithm works only on **G1** segments and it makes sense only in paths formed by **MICRO-SEGMENTS**. It's basilar understand **AFC** can change the axis speed in each single segment and therefore the resulting speed can be inconstant along path. The **SGLAFC_** parameter of each single axis defines the instant speed gap it can bear without problems. If, in the analyzed segment, even a single axis exceeds its threshold, the speed is reduce to fit set parameters. In the presence of edges (defined by **SGL3D_n** parameters) axis are decelerated to a stop.

AFC is very useful in works where it doesn't need a constant speed along path. In such a cases **AFC** allows to move at speed as high as the path makes it possible, slowing in critical points (curves).

24.3.9 G66 X-100 – NEW AFC – Adaptive Feed Control

Syntax

G66 X-100 Yarc Zaccs Afmin Bflevel Cval UaxisIndex VminLen WangDiff FnumSeg SradiusMax

Function type

Disabled when PartProgram start

Parameters

X-100	<i>NAFC - New AFC enabled</i> <i>0 Disabled</i> <i>-101 Disabled in PREVIEW</i> <i>Use X-101 for enabled the NEW AFC but disabled in PREVIEW</i> <i>Some times the new AFC can slow the PREVIEW function</i>
Yarc	<i>(optional) Y1 the ARCS G2-G3 are excluded in the AFC algorithm. In this case the parameter ACC_RAGGIO_MAX is used, otherwise the G2-G3 are included in the NEW AFC algorithm.</i> SET IN THIS CASE THE PARAMETER ACC_RAGGIO_MAX TO A VALUE 90
Zaccs	<i>(optional) Inserts a SMOOTHING filter on ACC PEAKS</i> <i>Decimal Values from 0 to 1 (ex Z0.7) big values, means filter weak. Default value=0</i>
Afmin	<i>(optional) Minimum value below which is not diminished the F</i> <i>Ex: if Val = 0.1 to 0.1 lower values of F are limited to 0.1. Default value Disable</i>
BFastMode	<i>(optional) Fast Mode for Acc calculation</i> <i>FastMode=0 The Acceleration is controlled also on the segments of the FindArc function</i> <i>FastMode=1 The Acceleration is not controlled on the segments of the FindArc function</i> <i>Default FastMode=1</i>
Cval	<i>(Optional) Special Functions see description. Default value=0</i>
UAxisIndex	<i>(Optional) If is used the tangential Axis (like to cutter) insert the Axis Index (0,1,2) that indicate the tangential Axis.</i>
VminLen	<i>(Optional) Indicates the minimum length (mm) for G1 element to be considered an ARC. G1 elements greater this value, are not considered as an ARC. Used only when the FindArc function is enabled parameter C bit 4=1. Default value=10 mm</i>
WRadiusTol	<i>(Optional) Indicates the tolerance of the Radius for FindArc function</i> <i>All the G1 segments which fall within the indicated tolerance are considered members of the same ARC. Higher values give less precise data.</i> <i>Default value 5 (5 % of tolerance)</i>
FnumSeg	<i>(Optional) Indicates the minimum number of consecutive G1 elements that respect the parameters V and W to be considered an ARC. Used only when the FindArc function is enabled parameter C bit 4=1. Default value=3</i>
SradiusMax	<i>(Optional) Indicates the maximum radius calculated by FindArc function. Radius greater this value are not considered as an ARC. Used only when the FindArc function is enabled parameter C bit 4=1. Default value=100 mm</i>

Description

G66 X-100 enables the new algorithm **NAFC** for Feed calculate on the Gcode files.

This new algorithm is better than old **G66** and uses the following parameters:

ACC_MAX_X,Y,Z etc.

The **ACC_MAX_** parameter must be set to a value greater or equal to **ACC_LAV** parameter. It means the max acceleration that the Axis can support, over it , the FEED is reduced.

G66 X-100 uses a look ahead depth equal to CNC, therefore is not necessary set the **G69** function.

Usually is not necessary insert other optional parameters for the **G66 X-100**, only the parameters **ACC_MAX_** are setted, but is possible improve the algorithm by the **Z** and **B** parameters.

Z decimal values from **0** (disabled) to **5** (minimum effect) uses a smoothing on ACC PEAKS Reference value could be **Z0.5**.

With this parameter, are avoided big feed reduction.

B integer values from **0** (disabled) to **5** (maximum effect) improve the feed calculation.

If is necessary excluded the **G2 G3** from the algorithm, set the **Y** to **1**.

In this case, the **G2-G3** feed reduction is performed by **ACC_RAGGIO_MAX** parameter.

Set **ACC_RAGGIO_MAX** to a value **90** if the **G2-G3** feed reduction is included in the algorithm.

If is used the tangential Axis (Cut Plotter) insert in the **U parameter**, the index of axis (0-1-2 etc.)

The tangential axis speed control is made when the system must interpolate on the work-plane, with the optional third axis moved in position "in time". For example with the "transported axis" (**G68**) or on the arcs (**G2-G3**) where the speed is always and only calculated on the work-plane axes.

In these cases, on every segment, the actual speed of the third axis will be compared with the maximum (**VMAX_**) inserted in the parameter list. If it'll be overcome, a new interpolation speed will be calculated, to make the tangential axis to move at his maximum speed. In this way, the segment will be executed at the maximum possible speed, but always supported by all axes.

Setting the bit 5 to 1, this control will be disabled.

FindArc

If the Bit 4 of parameter C is set to 1 (decimal value=16), is enabled the algorithm **FindArc**. It search ARCS in the consecutive G1 elements by parameters **V W F S**.


If an ARC is found, the RADIUS is calculated and the FEED is reduced by **ACC_RAGGIO_MAX** parameter, as G2-G3 element.



This function can operate with **NAFC** algorithm (feed reduced by **ACC_MAX_**) but this has the priority.

C Parameter Special Functions Bit Mapped

- Bit 0=1 RLS Removes the Short Segments G1 that can't be worked at current FEED
Bit 1=1 JOING1 Join the G1 belonging the same line G1



- Bit 2=1 Excludes the FEED reduction
 Only RLS and JOING1
- Bit 3=1 Excludes NAFC. Feed calculation by ACC_MAX_
- Bit 4=1 Enables FINDARC
- Bit 5=1 Excludes tangential axis from FEED control

24.3.10 G67 – Px_Moveto for movement outside plane and Px_Lineto for inside one

Syntax

G67

Function type

MODAL

Cancel

G68

Description

G67 works with a combination of PX_MOVETO for movement outside work plane (3D) and PX_LINETO for movements inside work plane. Furthermore when PX_MOVETO is used axis are stop at end of segment.

G63-G65 MUST NOT BE ENABLED

G68

24.3.11 G68 – Always using of PX_LINETO in G1 “TRANSPORTED AXIS” (with possibility to combine with PX_MOVETO)

Syntax

G68 Xval YTangAxis

Function type

MODAL

Cancel

G67

Parameter

Xval

Optional parameter (it must be enabled G69)

val>0 limit speed of eventually tangential axis

If tangential axis exceed this speed transported axis is disabled and PX_MOVETO is invoked

Val=0 disable

Val=-1 axis is never transported, but it is only calculated the edge threshold on work plane (as G65 but with SGLP)

YTangAxis *Optional Index of axis to be set as TANGENTIAL*

Description

G68 invokes always PX_LINETO for movement both inside and outside work plane, allowing to manage interpolation for particular machine types (for ex. cutting with tangent blade).

AXIS OUTSIDE WORK PLANE BECAME “TRANSPORTED”

These axis (outside plane), moving to final position with determination of vectorial speed by the only axis on work plane, don't' affect the resulting speed of tool.

An example of use with this interpolation mode can be the CUTTING PLOTTER one, where the blade must be tangent to path. Resulting working speed is realy the programmed one by F, tangential axis instead will be moved to its final position in the same time of the other.

X parameter allows to obtain mixed interpolation between “TRANSPORTED AXIS” and normal axis.

Using this interpolation mode there can come out a problem: the “TRANSPORTED AXIS” can reach a speed over its limit. Setting this limit with X parameter Isous identifies such points and invoke PX_MOVETO reducing resulting speed.

G63-G65 MUST NOT BE ENABLED

24.3.12 G69 – LHK – Buffer look ahead depth

Syntax

G69 Xval AXISTANG

Function type

Disabled when PartProgram start

Parameters

val	<i>Number of elements in the buffer</i>
	<i>If VAL<20 AFC is disabled</i>
	<i>VAL is limited to number of blocks of PartProgram</i>

ASSIXTANG *Optional axis to be set as TANGENTIAL (Ex. Z A etc.)*

If it isn't present no tangential axis is set

Description

G69 defines and enables the deep of **look ahead** segments buffer. It allows proper operation in functions which use it (G66 – G72 – G73 – G74). More the buffer is deep, more the result is accurate.

Depth is however limited to a value <20 (LHK disabled) to value major of part program length. A typical value can be 200.

This function also defines an optional tangential axis (for ex. cutting blade). This is necessary because functions related to **G69** (G66 – G72 – G73 – G74) can change the original path, adding or removing segments necessitating to recalculate the angle of tangent axis.

Ex:

G69 X200 A

In the above example buffer depth is set at 200 elements and axis A is set as TANGENTIAL.

24.4 ISOUS FILTERS

Isous is equipped with several filtering algorithms to modify original path formed by PartProgram. Filter can be useful especially when PartPrograms comes from CAM (for ex. scanner acquisition) having a “NOISE” path.

Filters acts only in G1 blocks and however it must be enabled G69 function (LHK depth).

They can be **2D** features (work plane axis) or **3D** features (work plane axis and depth axis).

Filters however **DOESN'T ACT ON MORE THAN THREE AXIS**.

WARNING

The depth axis is automatically taken from axis XYZ which remains outside work plane.

Work plane X,Y Depth axis Z

Work plane X,Z Depth axis Y

Work plane Y,Z Depth axis X

When filtering is active current working lines in PART PROGRAM can be shifted to original ones.

It can happen some of these are removed and other are divided in more segments.

SEQUENCE OF FILTER

All available filters can be combined together, it can be invoked in following sequence:

NOISE	G73	(if enabled)
NURBS	G72	(if enabled)
FINE NOISE	G73	(if enabled)
RLS	G74	(if enabled)
SMOOTHING	G106	(if enabled)
AFC	G66	(if enabled)

24.4.1 G72 – N.U.R.B.S (Non Uniform Rational Bspline) (2D 3D)

Syntax

G72 Xval Yminlen Zorder Alenseg

Function type

Disabled when PartProgram start

Parameters

val *0 – disable NURBS filter*
1 – enable NURBS filter

minlen *Minimum G1 segment length to be inserted in NURBS filter.*
Filter acts in a buffer which has a continuous series of segments with a length less than MINLEN parameter. When a segment greater than this length is met, the NURBS buffer is computer making an interpolation on points.
The typical default value is 0.2 mm
Optional parameter, if it isn't present last value or default value is taken.

order *Order of NURBS curve (value from 1 to 7)*
It defines the accuracy of resulting. Lower value corresponds to a best accuracy.
order=1 original point are carried back.
Typical default value is 3.
Optional parameter, if it isn't present last value or default value is taken.

lenseg *It defines the minimum segments length at output curve resulting to points interpolation.*
At lower value corresponds to a less segments length and to a greater number of resulting segments (curve more accurate)
Typical default value is 0.2mm
Optional parameter, if it isn't present last value or default value is taken.

Description

NURBS are a type of curve suitable to solve B-Spline problem, mainly the impossibility to draw simple shape as circle. By this evolution it's possible to generate conic curves, and to represent very complex curves with less number of control points.

N.U.R.B.S. (Not Uniform Rational B-Spline) are rational curves defined by control points and its relative weights.

Increasing the weights value of a point the curve approaches to the point. On the contrary the point will cause a less variation on the curve.

ISOUS uses this interpolation mode to “SOFTEN” a series of segments.

Some example are showed below to better explain NURBS filter.

NURBS filter acts also on 3D paths


NURBS FILTER IS THE SECOND TO BE INVOKED ON ORIGINAL PATH

ORIGINAL PATH

```

G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59


```

**PATH FILTERED with NURBS MiLen=7mm Order=3 LenSeg=0.2mm**

```

G69X200 // ENABLE LHK
// ENABLE NURBS LEN 7 MM ORDER 3 SEGMENT 0.2
G72X1Y7
G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59


```

**PATH FILTERED with NURBS MiLen=5mm Order=3 LenSeg=0.2mm**

```

G69X200 // ENABLE LHK
// ENABLE NURBS LEN 5 MM ORDER 3 SEGMENT 0.2
G72X1Y5
G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59

```



PATH FILTERED with NURBS MiLen=7mm Order=5 LenSeg=0.2mm

With higher order NURBS path deviates most from the original path


G69X200 // ENABLE LHK

G72X1Y7Z5

```

G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59

```

**PATH FILTERED with NURBS MiLen=7mm Order=2 LenSeg=0.2mm**

With **Order=2** changes are almost null even in marked circles original path is slightly modified


G69X200 // ENABLE LHK

G72X1Y7Z1

```

G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59

```

**PATH FILTERED with NURBS MiLen=7mm Order=1 LenSeg=0.2mm**

Original path not filtered


G69X200 // ENABLE LHK

G72X1Y7Z1

```

G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59

```



24.4.2 G73 – NOISE (2D-3D)

Syntax

G73 Xval Yminang Zminlen Aonlyvar

Function type

Disabled when PartProgram start

Parameters

val	0 – disable NOISE, disable FINE NOISE 1 – enable NOISE, disable FINE NOISE 2 – disable NOISE, enable FINE NOISE 3 – enable NOISE, enable FINE NOISE
------------	--

minang Minimum edge angle to be consider noise

Typical default value is 25 degree

Optional parameter, if it isn't present last value or default value is taken.

minlen Minimum G1 segment length to be inserted in NOISE filter.

Filter acts in a buffer which has a continuous series of segments with a length less than MINLEN parameter. When a segment greater than this length is met, the NOISE buffer is computer making an interpolation on points.

Typical default value is 0.4 mm


Optional parameter, if it isn't present last value or default value is taken.

onlyvar 0 – remove all edge matching the parameters

1 – remove only cusps matching the parameters (sudden changes of angle)

Typical default value is 0

Optional parameter, if it isn't present last value or default value is taken.



Description

NOISE filter helps to remove **G1** segments forming small edge (or cusps) which are defined as noise.

This is very useful in combination with NURBS filters increasing its performance.


Some example are showed below to better explain NOISE filter.

NOISE filter acts in 2D or 3D paths


NOISE FILTER IS THE FIRST FILTER IT IS INVOKED IN THE ORIGINAL PATH

ORIGINAL PATH


```
G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59
```

**PATH FILTERED with MinAng=45 MinLen=5**

```
G69X200 // ABILITA LHK
G73X1Y45Z5
G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59
```

**PATH FILTERED with MinAng=45 MinLen=3**

```
G69X200 // ABILITA LHK
G73X1Y45Z3
G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59
```



24.4.3 G74 – RLS Remove Len Segment (2D 3D)

Syntax

G74 Xval Ylenmin


Function type

Disabled when PartProgram start

Parameters

<i>val</i>	<i>0 – disable RLS filter</i> <i>1 – enable RLS filter</i>
------------	---

<i>lenmin</i>	<i>Minimum G1 segment length allowed.</i> <i>Segments with length less than this value are removed.</i> <i>Typical default value is 0.5 mm</i> <i>With lenmin=0 the value is automatically calculated by programmed speed (F).</i> <u><i>Optional parameter, if it isn't present last value or default value is taken.</i></u>
---------------	--



Description

RLS filter allows to remove “**SHORT**” **G1** segments which couldn’t be worked at requested speed (travel time less than CN sample). Setting a **ZERO** value, Isous calculates automatically the length optimizing it to current speed. The result is an exclusion of “void segment”, freeing the movement BUFFER and allowing greater work speed.

ATTENTION

When RLS is enable override potentiometer is disabled.

RLS filter acts on both 2D and 3D paths

RLS FILTER IS 4th TO BE INVOKED ON ORIGINAL PATH

24.4.4 *G106 – Smoothing (2D 3D)*

Syntax

G106.ax Xval ALevel Bminlen

Function type

Disabled when PartProgram start

Parameters

<i>.ax</i>	<i>Axis index where is set the filter (from 0 to n) normally 0 is X axis ex: G106.0</i>
<i>val</i>	<i>0 – Filter Smoothing disabled</i> <i>1 - Filter Smoothing Enabled</i>
<i>Level</i>	<i>Smoothing level (from 0 to 1)</i> <i>Values low have more effect to smoothing ex. A0.3</i> <i>Typical value is 0.7</i> <i><u>Optional parameter, if it isn't present last value or default value is taken.</u></i>
<i>minlen</i>	<i>Minimum G1 segment length allowed.</i> <i>Segment more large this value, not are inserted in the filter</i> <i>Typical default value is disable</i> <i>The length is calculated by axes vector (for all axes).</i> <i>Is necessary set only one time</i> <i>If the parameter is not present, the last length value is used</i>

Description


The **SMOOTHING** filter, is used to smoothing G1 segment, it allows to increase the execution speed, but decreased the precision respect to original path.

The **SMOOTHING** is activated for any axes with separate parameters.

THE SMOOTHING FILTER IS 5th TO BE INVOKED ON ORIGINAL PATH

ORIGINAL PATH

G60
G0 Z3
G0 X30.4845 Y258.703
F15
G01 Z-1
X36.1945 Y260.416 F15
X40.7625 Y257.8465
X44.7595 Y260.1305
X52.7535 Y260.416
X63.6025 Y256.99
X67.0285 Y250.138
X63.0315 Y247.854
X60.1765 Y244.428
X64.7445 Y239.289
X61.033 Y239.289
X62.746 Y234.721
X65.601 Y235.863
X70.4545 Y235.5775
X75.0225 Y238.147
X84.7295 Y237.8615
X87.299 Y239.86
X95.5785 Y239.86
X99.0045 Y241.002
X101.2885 Y236.1485
X107.284 Y237.576
X116.1345 Y231.866
X145.2555 Y233.008
X158.103 Y230.4385
X170.9505 Y234.15
X178.088 Y232.1515
X194.9325 Y229.2965
X200.357 Y232.437
X205.7815 Y219.304
X196.0745 Y216.1635
X193.7905 Y207.5985
X196.6455 Y199.89
X193.7905 Y198.748
X196.36 Y190.4685
X194.076 Y186.4715
X194.9325 Y182.4745
X199.5005 Y179.334
X193.7905 Y177.9065
X200.0715 Y175.0515
X193.7905 Y172.7675
X198.644 Y170.769
X191.5065 Y167.343
X196.6455 Y163.346
X191.221 Y161.062
X195.789 Y158.207
X188.0805 Y156.494
X191.792 Y153.068
X188.0805 Y150.784
X191.5065 Y148.2145
X179.801 Y138.793
X160.387 Y147.0725
G0 X160.387 Y147.0725




PATH – Smoothing on X,Y level A0.2 Min Len Segment 8 mm B8

```

G60
G0 Z3
G69X200
G106.0 A0.2 B8
G106.1
G0X30.4845 Y258.703
F15
G01 Z-1
X36.1945 Y260.416 F15
X40.7625 Y257.8465
X44.7595 Y260.1305
X52.7535 Y260.416
X63.6025 Y256.99
X67.0285 Y250.138
X63.0315 Y247.854
X60.1765 Y244.428
X64.7445 Y239.289
X61.033 Y239.289
X62.746 Y234.721
X65.601 Y235.863
X70.4545 Y235.5775
X75.0225 Y238.147
X84.7295 Y237.8615
X87.299 Y239.86
X95.5785 Y239.86
X99.0045 Y241.002
X101.2885 Y236.1485
X107.284 Y237.576
X116.1345 Y231.866
X145.2555 Y233.008
X158.103 Y230.4385
X170.9505 Y234.15
X178.088 Y232.1515
X194.9325 Y229.2965
X200.357 Y232.437
X205.7815 Y219.304
X196.0745 Y216.1635
X193.7905 Y207.5985
X196.6455 Y199.89
X193.7905 Y198.748
X196.36 Y190.4685
X194.076 Y186.4715
X194.9325 Y182.4745
X199.5005 Y179.334
X193.7905 Y177.9065
X200.0715 Y175.0515
X193.7905 Y172.7675
X198.644 Y170.769
X191.5065 Y167.343
X196.6455 Y163.346
X191.221 Y161.062
X195.789 Y158.207
X188.0805 Y156.494
X191.792 Y153.068
X188.0805 Y150.784
X191.5065 Y148.2145
X179.801 Y138.793
X160.387 Y147.0725
G0 X160.387 Y147.0725

```



24.5 Interrupt MACRO

Allows to use 3 types of MACRO that are execute in **INTERRUPT MODE**.

These MACRO have a fixed NUMBER and must be created with this number

<i>Time</i>	M50000
<i>On Digital Input</i>	M50001
<i>On Digital Output</i>	M50002
<i>Each Axes Movement</i>	M50003 e M50004

The management of these macro is performed by **G107** function

24.5.1 G107 – Management Interrupt Macro

Syntax

G107 X0

Disable All Interrupt Macro – Excluding M50003 and M50004

G107 X1

Enable All Interrupt Macro – Excluding M50003 and M50004

G107 X2

Suspend All Interrupt Macro – Excluding M50003 and M50004

G107 X3

Resume All Interrupt Macro – Excluding M50003 and M50004

(If they are disabled remain disabled)

G107.0 Xtime

Macro M50000 activated at Time

Time in millisecond (X-1 Disabled)

When the MACRO is in execution, it is automatically disabled, and will be enabled when the execution is finished

Example:

1) Generate MACRO 50000

```

G62                      // WAIT AXES STOP
$SAVEX=$[Q0]              // SAVE X
$SAVEY=$[Q1]              // SAVE Y
$SAVEZ=$[Q2]              // SAVE Z
G0XY0Z0                  // MOVE AXES
G4F1                     // PAUSE
G0X[$SAVEX]Y[$SAVEY]      // RESUME AXES VALUES XY
G0Z[$SAVEZ]               // RESUME AXIS VALUE Z
G4F1                     // PAUSE

```

2) Activation in the Gcode each 5 Seconds

G107.0 X5000

The macro **M50000** will be executed each 5 seconds

G107.1 XDI

Macro M50001 Activated when the DIGITAL INPUT IS ON

DI Indicate the DIGITAL INPUT NUMBER from 0 to 31 (-1 Disabled)

When the MACRO is in execution, it is automatically disabled, and will be enabled when the execution is finished

Example:

1) Generate MACRO 50001

```

G62                      // WAIT AXES STOP
$SAVEX=$[Q0]              // SAVE X
$SAVEY=$[Q1]              // SAVE Y
$SAVEZ=$[Q2]              // SAVE Z
GOXYOZO                 // MOVE AXES
G4F1                     // PAUSE
GOX[$SAVEX]Y[$SAVEY]      // RESUME AXES VALUES XY
GOZ[$SAVEZ]               // RESUME AXIS VALUE Z
G4F1                     // PAUSE

```

2) Activation in the Gcode when the FIRST DIGITAL INPUT IS ON

G107.1 X0

The M50001 will be executed when the DIGITAL INPUT will be from OFF to ON

G107.2 XDO

Macro M50002 Activated when the DIGITAL OUTPUT IS ON

DO Indicate the DIGITAL OUTPUT NUMBER from 0 to 31 (-1 Disabled)

When the MACRO is in execution, it is automatically disabled, and will be enabled when the execution is finished

Example:

1) Generate MACRO 50002

```

G62                      // WAIT AXES STOP
$SAVEX=$[Q0]              // SAVE X
$SAVEY=$[Q1]              // SAVE Y
$SAVEZ=$[Q2]              // SAVE Z
GOXYOZO                 // MOVE AXES
G4F1                     // PAUSE
GOX[$SAVEX]Y[$SAVEY]      // RESUME AXES VALUES XY
GOZ[$SAVEZ]               // RESUME AXIS VALUE Z
G4F1                     // PAUSE

```

2) Activation in the Gcode when the FIRST DIGITAL OUPUT IS ON

G107.2 X0

The M50002 will be executed when the DIGITAL OUPUT will be from OFF to ON

G107.3 Xp1 Yp2 Zp3 Ap4 Bp5 Cp6**G107.4 Xp1 Yp2 Zp3 Ap4 Bp5 Cp6**

Macro M50003 and M50004 Activated each Axes movement

If the Gcode line, contains the Axes movement, the M50003 or M50004, will be called

Parameter:

P1 0 Disable Macro M50003 or M50004

1 Enable Macro M50003 or M50004

P2..P6 User Parameter can be used in the M50003 and M50004 code

These Parameters are passed by Address

P2 Address 20000

P3 Address 20001

P4 Address 20002

P5 Address 20003

P6 Address 20004

Example:**1) Generate MACRO 50003**

```
$FEED1=$[:20000]          // FEED1 ON P2 Y
$FEED2=$[:20001]          // FEED2 ON P3 Z
F[$FEED1]
G1X0Y0Z0                  // MOVE AXES WITH FEED1 (Y)
G4F1                      // PAUSE
F[$FEED2]
G1X100Y100Z100            // MOVE AXES WITH FEED2 (Z)
G4F1                      // PAUSE
```

1) Activation in the Gcode

```
G0X0Y0Z0
G107.3 X1 Y10.2 Z5.3    // ENABLE M50003 WITH FEED1=10.2 AND FEED2=5.3
F2
G1X20Y20Z20              // TO END THIS LINE THE M50003 IS CALLED
G1X30Y30Z30              // TO END THIS LINE THE M50003 IS CALLED
G1X40Y40Z40              // TO END THIS LINE THE M50003 IS CALLED
G107.3 X0                  // DISABLE M50003
```

The FEED setted in the Gcode, are saved first the M50003 or M50004 execution, and restored to end Macro

24.6 EMERGENCY MACRO M60000 in STOP Mode

The **EMERGENCY MACRO M60000** is activated when the **CN** finds an **EMEGENCY ALARM** and it is in **STOP** mode

When the CN is in **RUN** mode will be activated the **MACRO ERROR** configured.

The **EMERGENCY MACRO** has a fixed code **M60000**

Therefore is necessary generate a macro **M60000** by PluGIn **MHM** and it will be immediately ready.

Generally in this macro is insert only the code for Digital or Analog outputs management, because the Axes movement will be stooped by CN when the Emergency will be found.

For disactivate the EMERGENCY MACRO M60000 is necessary remove from the folder **DATA_M** the file **M60000.bin**

The folder **DATA_M** is in the IsoUs folder installation.

24.7 G108 Management Special Axes

This function allows of management the Special Axes. This enable special functions on the axis different from normal use.

24.7.1 G108.0 G108.1 G108.2 G108.3 - Master Slaves Axes

The function G108.0 .1 .2 .3 allows to enable the MASTER-SLAVE.

In other words, allows to connect one or more axes to single master. So, when the master it is moved, the slaves axes are moved in the same mode of master axes

Is possible management up to 4 Groups of Master Slaves respectively with G108.0 G108.1 G108.2 and G108.3

The max number of slaves connected to master, is 8.

Syntax

G108.x 0

Remove all slaves of the group

G108.x 1

Suspend all slaves of the group

G108.x 2

Resume all slaves of the group previously programmed

G108.x M,S1,S2,S3..(-)S4 ecc.

Coonects the Slaves

M = Axis Master (is always the first programmed with G108.x)

S1 = Slave 1

S2 = Slave 2

Etc.

The sign “-“ before of slave, inverts the slave direction, respect to master

Example:

G108.0 X,A,-C // X Master A Slave C slave with invert direction

G108.1 Y,Z,B,U // Y Master Z,B,U Slaves

.

.

G108.0 0 // Remove first Group of slaves

24.7.2 G108.4 G108.5 G108.6 SPEED MODE AXIS

The **G108.4** function, allows to connect one Axis from Interpolator to **SPEED MODE**, therefore the axis is no longer controlled by a target value, but in velocity mode. The **SPEED** can be set by the Function **S** if the channel is set in correct mode (see [16.8](#))

The function **G108.5** retrieve the Axis from **SPEED MODE** to **INTERPOLATOR MODE**

The function **G108.6** is like to **G108.5** but the Axis value is RESET to ZERO.

This allows to avoid the AXIS LIMITS ERROR

The Axis status in Speed mode can be read by special variable [\\$\[X16\]](#)

Syntax

G108.4 X,Y,Z,A,B,C,U,V,W

Connects the Axis (one Only) From Interpolator to Speed mode.

G108.5 X,Y,Z,A,B,C,U,V,W

Retrieve the Axis from Speed Mode To Interpolator mode.

G108.6 X,Y,Z,A,B,C,U,V,W

Retrieve the Axis from Speed Mode To Interpolator mode. VALUE IS RESET TO ZERO

24.7.3 G108.7 G108.8 G108.9 Physical exchange Axes

The **G108.7** allows to exchange a pair of Axes in the **CNC** level

Is possible to exchange one or more pair of Axes

G108.8 Restore the pair of Axes previously exchanged

G108.9 Restore ALL pair of Axes previously exchanged

Syntax

G108.7 XA

Exchange X with A

G108.8 XA

Restore the pair XA in the original mode

G108.9

Restore ALL pair previously exchanged

24.8 VIRTUAL AXIS

Virtual axis are commands inserted in the interpolation buffer but they don't refer to a real axis. In detail they are synchronous command which can enable events in precise point of path. This commands must be used when CN works with fast interpolation. Furthermore command function must be implemented in CN.

24.8.1 **G100 – Comando sincrono per asse virtuale**

Syntax

G100 Xcmd

Function type

Direct

Parameter

Cmd *Command code to send to CN*

Description

G100 sends a command to CN synchronously with path. Such a command must be implemented in CN by VTB environment to work properly (refer to CN documentation).

Example to manage a digital output in fast interpolation.

PartProgram

```

G60      //ENABLE FAST INTERPOLATION
G1X100Y100
X120Y110
X130
G100 X1// SET OUTPUT
X200Y160
X210Y180
G100 X0// CLEAR OUTPUT
X300Y200
X310Y220

```

Two function must be implemented in CN for:

G100 X0 Clear output

G100 X1 Set output

This is the VTB code to be written in TaskPlc using output n.0

' **G100 command for set/clear output**

ISOV1.out0=INTERPOLA1.cmd

24.9 OTHER GENERIC G FUNCTIONS

24.9.1 G4 – Timed pause

Syntax

G4 Fvalue

Function type

Direct

Parameter

Value Time seconds (resolution up to tenth of second)

Description

G4 allows to pause PartProgram for the time set by F parameter.

Ex:

G4F2.5 // PAUSE OF 2.5 SEC

24.9.2 G4.1 – Time Add on Calc Time

Syntax

G4.1 Fvalue

Function type

Direct

Parameter

Value Time in sec to add

Description

G4.1 adds an extra time to Calc Time Function. This allows to include extra PLC time (wait input etc.) Normally it is inserted in the M functions M3,M4,M5 M6 etc.

This function is activated only during Calc Time function, and it is excluded in a normal RUN.

24.9.3 G10 – Enable external OVERRIDE potentiometer

Syntax

G10

Function type

Modal - default

Cancel

G11

Description

G10 enables speed control by external potentiometer.

24.9.4 G11 – Disable external OVERRIDE potentiometer

Syntax

G11

Function type

Modal

Cancel

G10

Description

G11 disables speed control by external potentiometer.

24.9.5 G101 – Axis Stop command

Syntax

G101

Function type

Direct

Description

G101 commands a stop to axis in current position. The example below explains this function.

Ex:

In this example axis X move to position 100. During positioning a digital input is tested (Input 0), if it activates the movements is stopped. If axis terminates its movement PartProgram is ended with an error.

```

G60
F1
G1X100
@INITLOOP
IF $[Q0]=100    // IF X REACHES 100
  GOTO ERR      // ERROR
END_IF
IF $[I0]=1      // WAIT FOR INPUT
  G101    // IF ACTIVE, AXIS STOP AND EXIT
  GOTO EXIT
ELSE
  GOTO INITLOOP // CONTINUE LOOP
END_IF
@EXIT
.
.
.

@ERR
.
.
```

24.9.6 G80 – Forced pause by code

(Shifted on G1080 if USE_G80_CYCLES=TRUE)

Syntax

G80 Xcode

Function type

Direct

Parameter

Code *Code of pause (refer to configuration)*

Description

G80 forced CN to pause state and setting a pause code. **CODE** parameter defines the message code to be showed. If code hasn't been configured a message "NO CODE PAUSE" is showed. The PAUSE procedure is the same of the hardware one.

Ex:

G80 X4 // PAUSE IS FORCED WITH CODE 4

24.9.7 G81 – Management secondary axes LIMITS

(Shifted on G1081 if USE_G80_CYCLES=TRUE)

Syntax**G81 Xmode****Function type***Direct***Parameter**

<i>mode</i>	<i>Mode of LIMITS management</i>
X0	<i>Set FIRST POSITIVE LIMITS (default – LIMITE_P_)</i>
X1	<i>Set FIRST NEGATIVE LIMITS (default – LIMITE_N_)</i>
X2	<i>Set SECOND POSITIVE LIMITS (2ND_LIMITE_P_)</i>
X3	<i>Set SECOND NEGATIVE LIMITS (2ND_LIMITE_N_)</i>

Description

Sometimes is necessary change in temporary mode the Axes limits for make the axes movements outside to primary limits (Eg: TOOL CHANGE)

In Isous is possible used the SECONDARY LIMITS positive and negative

Machine parametr:**2ND_LIMITE_N_****2ND_LIMITE_P_**

This parameters can be activated or disactivated by G81 function.

If the secondary limits remain activated, when the PART PROGRAM is finished, automatically are reset to primary LIMITS.

This function is tipically used to TOOL CHANGE MACRO (M6)

Ex:**G81 X3 // ACTIVE SECONDARY NEGATIVE LIMITS****G81 X1 // ACTIVE PRIMARY NEGATIVE LIMITS****24.9.8 G20 – Axes Values in Inch****Syntax****G20****Function type***Modal***Cancel****G21****Description**

G20 Enable the Programmation Axes Values in Inch.(G0-G1-G2-G3 etc)

24.9.9 G21 – Axes Values in Millimeters**Syntax****G21****Function type***Modal - Default***Cancel****G20****Description**

G20 Enable the Programmation Axes Values in Millimeters.(G0-G1-G2-G3 etc)

24.10 VARIABLE MANAGEMENT FUNCTIONS

Isous manages files which can contain the state of some variable. These files are stored on the PC HardDisk. It's possible to load them (one at a time) by Partprogram. When file has been loaded a list of saved variables is filled. The length of the list depends to the number of stored variable. There is no limit to list length. These variables can be read or written in the list by specific instructions in the PartProgram. In other words it's possible to obtain Backups of variables state for generic use.

24.10.1 LOAD_VAR – load a variables file in current list

Syntax

LOAD_VAR filename

Parameter

Filename *Name of the file to be loaded*

The name can contain extension but there must not be delimitation characters (+- etc.)*

Description

LOAD_VAR load the file named initializing the internal list with values container in the file.

The list is defined as an ARRAY of double values and we can access them by **GET_VAR** and **WRITE_VAR** functions. If the file will be not found Isous will show the relative error.

Ex:

```
LOAD_VAR MYFILE.PNT // LOAD FILE
GET_VAR $VAR1 0      // SET VAR1 FROM INDEX 0 OF THE LIST
GET_VAR $VAR2 1      // SET VAR2 FROM INDEX 1 OF THE LIST
```

24.10.2 GET_VAR – Read a value from the loaded list and store it in a variable

Syntax

GET_VAR \$var index

Parameters

\$var	<i>Name of the destination variable</i>
Index	<i>Expression indicating the index in the list</i>

Description

GET_VAR reads a value in the current list and stores it in a variable. The list must have been sized (by **DIM_VAR**) or however it must have a size greater or equal to INDEX. If index is over the list size an error will be showed.

Ex:

```
LOAD_VAR MYFILE.PNT // LOAD FILE
$INDEX=0
LOOP 10
  GET_VAR $VAR1 $INDEX      // LOAD X POSITION
  GET_VAR $VAR2 $INDEX+1    // LOAD Y POSITION
  G1 X[$VAR1]Y[$VAR2]       // MOVE
  $INDEX=$INDEX+2           // INCREASE INDEX
END_LOOP
```

24.10.3 WRITE_VAR – Write a value in the loaded list getting it from a variable

Syntax

WRITE_VAR \$var index

Parametri

\$var	<i>Name of the source variable</i>
index	<i>Expression indicating the index in the list</i>
ATTENTION: list must be sized for INDEX value	

Description

WRITE_VAR allows to store a value of the current list in a variable. The list must have been sized (by DIM_VAR) or however it must have a size greater or equal to INDEX. If index is over the list size an error will be showed.

Ex:

```
DIM_VAR 10          // SIZE LIST WITH 10 EMPTY ELEMENTS
WRITE_VAR $VAR1 0    // STORE VAR1 IN INDEX 0 OF THE LIST
WRITE_VAR $VAR1 1    // STORE VAR2 IN INDEX 1 OF THE LIST
SAVE_VAR MYFILE.PNT // SAVE FILE
```

24.10.4 SAVE_VAR – save a variables file with current list

Syntax

SAVE_VAR filename

Parameter

filename	<i>Name of the file to be saved</i>
<i>The name can contain extension but there must not be delimitation characters (+-* etc.)</i>	

Description

SAVE_VAR saves the value in the current list to the named file.

Ex:

```
DIM_VAR 10          // SIZE LIST WITH 10 EMPTY ELEMENTS
WRITE_VAR $VAR1 0    // STORE VAR1 IN INDEX 0 OF THE LIST
WRITE_VAR $VAR1 1    // STORE VAR2 IN INDEX 1 OF THE LIST
SAVE_VAR MYFILE.PNT // SAVE FILE
```

24.10.5 FILE_EXISTS – test if a file exists

Syntax

FILE_EXISTS \$var filename

Parameters

\$var	<i>Variable where to store result: 0=file not found, 1=file exists</i>
filename	<i>Name of the file</i>

The name can contain extension but there must not be delimitation characters (+- etc.)*

Description

FILE_EXISTS allows to test if a variable file exists.

Ex:

```
FILE_EXISTS $VAR MYFILE.PNT // TEST FILE
IF $VAR=0                // FILE NOT FOUND
...
END_IF
```

24.10.6 ADD_VAR – Add a value to current list

Syntax

ADD_VAR value

Parameter

value	<i>Expression or variable which value will be appended to the list</i>
--------------	--

Description

ADD_VAR appends a value to the current list. The list will be resizing to contain the new element.

Ex:

ADD_VAR \$VAR1	// APPEND VALUE FROM VAR1
ADD_VAR 10.23	// APPEND VALUE FROM CONSTANT
ADD_VAR \$VAR2*(\$VAR3+\$VAR4)	// APPEND VALUE FROM EXPRESSION

24.10.7 REMOVE_VAR – Remove a value from current list

Syntax

REMOVE_VAR Index

Parameter

index	<i>Expression indicating index of list to be removed</i>
--------------	--

Description

REMOVE_VAR remove a value from the current list. All index above the removed one will be re-indexed. If the index is over the list size an error will be showed.

Ex:

REMOVE_VAR 1 // REMOVE VALUE AT INDEX 1

24.10.8 CLEAR_VAR – Remove all values from the current list

Syntax

CLEAR_VAR

Description

CLEAR_VAR erase all the values from the current list. List will be sized at zero and the value cannot be restored.

Ex:

CLEAR_VAR	// CLEAR ALL CURRENT LIST
------------------	---------------------------

24.10.9 DIM_VAR – Size current list to a specific number of elements

Syntax

DIM_VAR Nelem

Parametri

Nelem *Expression indicating the number of elements to be sized
(the value of all elements will be set with ZERO)*

Description

DIM_VAR allows to re-size the current list. All last value will be lost and the new values will be set with ZERO.

Ex:

DIM_VAR 10 // SIZE LIST WITH 10 ELEMENTS

24.10.10 COUNT_VAR – Get the number of elements in the current list

Syntax

COUNT_VAR \$var

Parameter

\$var *Variable where to store the list size*

Description

COUNT_VAR gets the number of elements of the current list and store the value in a variable.

Ex:

```
COUNT_VAR $VAR1      // STORE SIZE IN VAR1
IF $VAR1=0              // IF LIST IS EMPTY
  DIM_VAR 10            // RE-SIZE THE LIST
```

24.11 HM FUNCTIONS

HM functions are an upgrade to standard M functions. They can use parameters passed to function when invoked like common high level languages as **C**.

Parameters are then read by HM function writing it in private variables.

HM functions reside on PC and they must be created with the specific utility of human interface.

24.11.1 Call of HM functions

Syntax

HMnum par1 par2 par3

Function type

Direct

Parameters

Num *Number code of HM function*

PARn *Variable or constant. Parameters must be separated by space*

Description

HM with code **NUM** is invoked passing it the parameters defined with **PARn**.

HM functions always wait for emptying of the MOVEMENT BUFFER before it is really invoked.

All parameters defined in the declaration must be inserted, else an errore will be generated.

Ex:

HM10 \$VAR1 \$VAR2 12.3 24.125 // CALL OF HM 10 PASSING 4 PARAMETERS

24.11.2 Building of a HM function

A **HM** function, before to be used, must be built and pre-compiled by specific option in the human interface. **HM** functions are formed by ISO code and they can be used all Isous functions. After pre-compiling **HM** is available to PartProgram.

VARIABLES and **LABELS** declared inside HM function are **PRIVATE** (not visible in PartProgram). In other words **VARIABLES** and **LABEL** could be a same name both in HM function and PartProgram, Isous recognized that automatically. It's possible to share **VARIABLES** with Partprogram declaring them with **GLOBAL prefix**. Inside **HM** function it's possible call other **HM** or **M** functions both on CN and PC.

Example of building of a HM function

```
GET $PAR1 $PAR2 $PAR3 $PAR4 // READ PARAMETERS
GLOBAL $PAUSE                // SHARE $PAUSE WITH PART PROGRAM
F[$PAR3]                      // SET FEED AT $PAR3
G1 X[$PAR1] Y[$PAR2] Z[$PAR3] // LINEAR INTERPOLATION
G4 F[$PAUSE]                  // PAUSE
```

As we can see from the example, a HM function is very similar to the high level languages. If there was a need to return a value we can do it using **GLOBAL** variables.

24.12 M FUNCTIONS

There are two type of M function:

- **Inside CN**
- **Inside PC**

Obviously function cannot have the same number. **M inside PC** are priority to **M inside CN**. If both they were present Isous invokes the PC one.

24.12.1 M functions inside CN

M function inside CN have to be built with VTB environment (refer to relative documentation). They can read some parameters from PartProgram or return it a value by some predefined variables.

PREDEFINED VARIABLES

```

$_PARM_1      parameter 1
$_PARM_2      parameter 2
$_PARM_3      parameter 3
.
.
$_PARM_n      parameter n

```

The number of parameters available depends to Isous configuration, but it's a limit of 10 parameters (default 5).

Each time PartProgram writes or reads a variable of \$_PARM_n type, they are read from CN memory. \$_PARM variables are 32 bit **INTEGER**. All parameters must be written before invoking M function and read at the end of it.
M functions always wait for emptying of the MOVEMENT BUFFER before it is really invoked.

Ex:

```

$_PARM_1=134 // WRITE PARAMETER 1
$_PARM_2=$VAR// WRITE PARAMETER 2
$_PARM_3=12600 // WRITE PARAMETER 3
M100           // INVOKE M100 FUNCTION
$VAR1=$_PARM_1 // READ PARAMETER 1 MODIFIED BY M100

```

24.12.2 M function inside PC

M function inside PC are very similar to HM functions, the only difference is that M functions cannot have any parameter. Therefore exchange of value must be made with GLOBAL variables.

A HM function, before to be used, must be built and pre-compiled by specific option in the human interface.

HM functions are formed by ISO code and they can be used all Isous functions. After pre-compiling HM is available to PartProgram.

VARIABLES and **LABELS** declared inside HM function are **PRIVATE** (not visible in PartProgram). In other words **VARIABLES** and **LABEL** could be a same name both in HM function and PartProgram, Isous recognized that automatically. It's possible to share VARIABLES with Partprogram declaring them with **GLOBAL prefix**.

Inside HM function it's possible call other HM or M functions both on CN and PC.

Example of building of a M function

```
GLOBAL $VAR1           // SHARE $VAR1 WITH PART PROGRAM
GLOBAL $VAR2           // SHARE $VAR2 WITH PART PROGRAM
G1 X$VAR1 Y$VAR2      // LINEAR INTERPOLATION
```

24.13 Essential M FUNCTIONS

In this section are described the essential M functions. These are necessary for correct machine operation.

24.13.1 START M

This function is execute when START PROGRAM is required. Its use is not important, because the preparatory M functions are inserted in to Part Program

24.13.2 END M

This function is execute when END PROGRAM is required. Its use is not important, because the preparatory M functions are inserted in to Part Program.

24.13.3 STOP M

This function is execute when STOP PROGRAM button is pressed. This function is VERY IMPORTANT.

It usually STOP ALL AXES and Spindle, water etc

Essential Functions In M STOP

- 1) G101 Stop axes
- 2) G62 Wait axes stop
- 3) SET/RESET output for spenlde,water etc.
- 4) Eventually parking axes

Se nessuna M di STOP viene configurata, il CNC blocca solamente gli assi nel punto di STOP.
If no M STOP configured, will stop only the axes by CNC.

24.13.4 PAUSE M

This function is execute when PAUSE PROGRAM button is pressed. This function is VERY IMPORTANT.
usually this function stops the spindle. the water and saves the positions axes for pause resume.

Essential Functions In M PAUSE (ex 3 axes)

- 1) GLOBAL \$SAVEX *GLOBAL variable for X AXIS*
- 2) GLOBAL \$SAVEY *GLOBAL variable for Y AXIS*
- 3) GLOBAL \$SAVEZ *GLOBAL variable for Z AXIS*
- 4) G62 Wait axes stop
- 5) \$SAVEX=\$[Q0] *Save X position*
- 6) \$SAVEY=\$[Q1] *Save Y position*
- 7) \$SAVEZ=\$[Q2] *Save Z position*
- 8) SET/RESET output for spenlde,water etc.
- 9) Eventually parking axes

If M PAUSE is not configured, will stop only the axes by CNC.

24.13.5 RESUME PAUSE M

This function is execute when START button is pressed after PAUSE PROGRAM. This function is VERY IMPORTANT. usually this function repositions the axes and SET/RESET output for spindle, water etc.

Essential Functions In M RESUME PAUSE (ex 3 assi)

- 1) GLOBAL \$SAVEX **GLOBAL variable for X AXIS**
- 2) GLOBAL \$SAVEY **GLOBAL variable for Y AXIS**
- 3) GLOBAL \$SAVEZ **GLOBAL variable for Z AXIS**
- 4) G96 **Offset suspension**
- 5) G98 **Work origins suspension**
- 6) G0 Z0 **Z axis to safety position**
- 7) F1 **SPEED axes**
- 8) G1 X[\$SAVEX] Y[\$SAVEY] **Axes X,Y, etc. To initial positions (these are saved by M pause)**
- 9) G62 **Wait axes in positions**
- 10) G1 Z[\$SAVEZ] **Axis Z to initial position (this is saved by M pause)**
- 11) G62 **Wait Z axis in position**
- 12) G97 **ResumeOffset**
- 13) G99 **Resume Work origins**
- 14) SET/RESET output for spenlde,water etc.

If no M resume pause configured, the CNC axes back to the starting point in the interpolation of a set F in the machine parameter "VRIPOS"

24.13.6 GO BLOCK M

This function is execute when START button is pressed by Plugin "**GO BLOCK**". usually this function repositions the axes and SET/RESET output for spindle, water etc.

Essential Functions In GO BLOCK M (ex 3 assi)

- 1) \$POSX=\$[C0] **Axis X position calculated by CNC**
- 2) \$POSY=\$[C1] **Axis Y position calculated by CNC**
- 3) \$POSZ=\$[C2] **Axis Z position calculated by CNC**
- 4) G96 **Offset suspension**
- 5) G98 **Work origins suspension**
- 6) G0 Z[0] **Z axis to safety position**
- 7) F1 **SPEED axes**
- 8) G1 X[\$POSX] Y[\$POSY] **Axes X,Y, etc. To initial positions**
- 9) G62 **Wait axes in positions**
- 10) G1 Z[\$POSZ] **Axis Z to initial position**
- 11) G62 **Wait Z axis in position**
- 12) G97 **ResumeOffset**
- 13) G99 **Resume Work origins**
- 14) SET/RESET output for spenlde,water etc.

24.13.7 GO RETRACE M

This function is execute when START button is pressed by Plugin "**RETRACE**". usually this function repositions the axes and SET/RESET output for spindle, water etc.

Essential Functions In M RETRACE

- 1) SET/RESET output for spenlde,water etc.

24.14 DEFINING DEPTH AXIS

The depth axis is used for some functions Isous. Normally, this axis is related to the work plan selected:

Work Plane XY	Depth axis Z
Work Plane XZ	Depth axis Y
Work Plane YZ	Depth axis X

The depth axis is used by the simulation process and the way PREVIEW and by G47 function

24.14.1 G48 Define Depth axis

Syntax

G48 axis name

Function type

immediate

Parameters

Axis Name *ex: X,Y,Z,A,B etc.*

Description

G48 definisce un asse di profondità diverso da quelli scelti in automatico da Isous.

Se l' asse scelto è uguale ad uno degli assi del piano di lavoro impostato, viene generato un errore di Run Time.

G48 defines a depth axis different to axis chose automatically by Isous

Ex:

G48 A // A is depth axis

24.15 MILD MODE – EDGE SMOOTHING

Isous can use a special algorithm for EDGE SMOOTHING

With the PARAMETERS MILD_ (MILD_X – MILD_Y etc.) you can Smooth the edge with various value.

The MILD MODE can be activated on single Axis.


The MILD_ set of value can be used from 200 to 20 (estimated values)

The G49 function, manages the MILD MODE.

Following you can see a MILD MODE example values

The MILD function, works for EDGE under the parameters **SGLP_MILD** for 2D or **SGL3D_MILD_** for 3D (G65)

Edges, above these values aren't SMOOTHED by MILD



24.15.1 G49 MILD MODE Managing

Syntax

G49 Axes Name where enable MILD MODE – None Axis, MILD MODE DISABLED ON ALL AXES

G49.0 Suspends MILD MODE

G49.1 Resumes MILD MODE on the Axes indicated in previous G49

Function type

Immediate – Disabled on PROGRAM STOP

Parameters

Axes Name Name of Axes where enable Mild Mode: ex: G49 XYZ
 $(QX, QY, QZ, QA, QB, QC, QU, QV, QW)$

Description

G49 manages ENABLE/DISABLE MILD MODE.

G49 with Axes Name (ex. G49 XY) enabled MILD MODE on the Axes indicated.

G49 Without parameters DISABLES MILD MODE on the ALL AXES.

G49.0 Without parameters **SUSPENDS MILD MODE**


G49.1 Without parameters **RESUMES MILD MODE** if it was activated by **G49**.

Ex:

```

G60
F15
G0 Z3
G49 XY // ENABLED MILD MODE ON XY
G0X63.7738 Y160.6052
F10
G01 Z0
X70.9693 Y140.2459 F15
X92.5556 Y139.694
X75.4163 Y126.5593
X81.5619 Y105.8589
X63.7738 Y118.1006
X45.9857 Y105.8589
X52.1313 Y126.5593
X34.992 Y139.694
X56.5783 Y140.2459
X63.7738 Y160.6052
G49 // DISABLED MILD MODE ON ALL AXES
G0 Z3
G0 X56.5783 Y140.2459

```



24.16 PARALLEL TASKS

IsoUs can execute two Gcode parallel Tasks besides the main Gcode

This allows to execute functions in asynchronous mode to increase the machine performances.

The parallel tasks **TASK1** and **TASK2** can't manage all main gcode functions (see single instructions)

24.16.1 USTASK-ENDUSTASK

These two instructions define the Gcode that is load in the TASK1 automatically from the compilator.
USTASK and ENDUSTASK MUST BE Write in the Main Gcode

USTASK

LOOP 1000

```
$[O1]=1
G4F1
$[O1]=0
G4F1
```

END_LOOP

ENDUSTASK

TASK.RUN 1 // FOM MAIN PROCESS RUN TASK1 CODE

LOOP 1000

```
G1X100Y100F5
G4F1
X0Y0
G4F1
```

END_LOOP

The gcode enclosed in USTASK ENDUSTASK will be load in the TASK1 but it is not execute during the RUN the Main Gcode. For execute it must be used **TASK.RUN**.

The Gcode external to USTASK ENDUSTASK will be execute in the Main Process during the RUN

24.16.2 TASK.RUN

Starts the execution the code in TASK

Syntax

TASK.RUN Ntask

Ntask TASK number where:

- 0 Task Main (not used)
- 1 TASK1
- 2 TASK2

One task can't run itself

24.16.3 TASK.STOP

Stop the execution the code in TASK

Syntax

TASK.STOP Ntask

Ntask TASK number where:

- 0 Task Main (not used)
- 1 TASK1
- 2 TASK2

One task can't stop itself

24.16.4 TASK.PAUSE

Pause the execution the code in TASK

*Syntax***TASK.PAUSE Ntask**

Ntask TASK number where:

- 0** Task Main (not used)
- 1** TASK1
- 2** TASK2

One task can't pause itself

24.16.5 TASK.READVAR

Read a Variable by Address in the Task

*Syntax***TASK.READVAR Ntask AddrVar \$VarDest**

Ntask TASK number where:

- 0** Task Main
- 1** TASK1
- 2** TASK2

AddrVar Variable Address to Read

\$VarDest Destination Variable

Ex:

TASK.READVAR 1 2000 \$VAR // READ THE VARIABLE 2000 FROM TASK 1 AND STOR IN VAR

24.16.6 TASK.WRITEVAR

Write a Variable by Address in the Task

*Syntax***TASK.WRITEVAR Ntask AddrVar \$VarSource**

Ntask TASK number where:

- 0** Task Main
- 1** TASK1
- 2** TASK2

AddrVar Variable Address to Write

\$VarSource Source Variable

Ex:

TASK.WRITE 1 2000 \$VAR // WRITE \$VAR IN THE VARIABLE 2000 OF TASK 1

24.16.7 TASK.STATUS

Read the Task status

*Syntax***TASK.STATUS Ntask \$VAR**

Ntask TASK number where:

- 0** Task Main (not used)
- 1** TASK1
- 2** TASK2

\$VAR Status Destination Variable

- 0 - Task Stop
- 1 – Task Run
- 2 – Task Pause

Ex:

TASK.STATUS 1 \$VAR // READ TASK 1 STATUS IN \$VAR

24.16.8 TASK.LOADCMD

Load a CMD FILE in the Task

The CMD file Must be created by PlugIn MHM

The CMD isn't executed but is necessary to use TASK.RUN

Syntax

TASK.LOADCMD Ntask "CMDNAME"

Ntask TASK number where:

- 0** Task Main (not used)
- 1** TASK1
- 2** TASK2

"CMDNAME" CMD Name (in quotes and without extension) to load in the TASK

Ex:

TASK.LOADCMD 1 "TESTCMD" // LOAD TH CMD TESTCMD IN TASK1

24.16.9 TASK.PRIORITY

Set Task Priority

Syntax

TASK.PRIORITY Ntask Pval

Ntask TASK number where:

- 0** Task Main
- 1** TASK1
- 2** TASK2

Pval Priority from 0 to 100

0 High Priority (default)

Ex:

TASK. PRIORITY 1 2 // TASK 1 PRIORITY 2

24.17 MAIN MACHINE PARAMETERS

In this chapter are explained the MAIN machine parameters to be set in Isous to configure the machine. MAIN MACHINE PARAMETERS are always present on any application, however it's possible that applications share more PARAMETERS. Indeed Isous allows to customize parameters to adjust Isous for any type of machine.

NOTE TO CALCULATE ACCELERATION IN Mt/sec²

In Isous acceleration is expressed in increase for CN sample, to obtain the value in Mt/sec² this is the calculation to do:

$$\text{ACC} = \text{ACC_xx} / \text{TAU}^2$$

TAU = Sample time set on CN in msec

ACC_xx = value of acceleration parameter

If for example we set an ACC_xx=100 and a sample of TAU=5 msec, we obtain:

$$\text{ACC}=100/(5*5)=4 \text{ Mt/sec}^2$$

24.17.1 Generic parameters

24.17.1.1 FEEDMAX

It defines the maximum **FEED** of the system. The unit of measure depends by system resolution (typically mm/min). If it's set a **F** at speed greater than this, it is limited at **FEEDMAX**.

This parameter is affected by unit of measure set. Working with resolution of 0.0001 (instead of typycal 0.001) this parameter must be expressed in tenth of mm/min.

24.17.1.2 FEEDMIN

It defines the minimum **FEED** of the system. The unit of measure depends by system resolution (typically mm/min). If it's set a **F** at speed less than this, it is limited at **FEEDMIN**.

This parameter is affected by unit of measure set. Working with resolution of 0.0001 (instead of typycal 0.001) this parameter must be expressed in tenth of mm/min.

24.17.1.3 FEEDDEF

It defines the default **FEED** set by the system at start-up. The unit of measure depends by system resolution (typically mm/min).

This parameter is affected by unit of measure set. Working with resolution of 0.0001 (instead of typycal 0.001) this parameter must be expressed in tenth of mm/min.

24.17.1.4 FEEDRES

It defines the resolution of the speed set by F.

1	mm/min	ex: F1500 = 1,5 Mt/min
1000	mt/min	ex: F1.5 = 1.5 Mt/min

24.17.1.5 SPEEDMAX

It defines the maximum speed (**S**) of the system. The unit of measure depends by system resolution. If it's set a **S** at speed greater than this, it is limited at **SPEEDMAX**.

24.17.1.6 SPEEDMIN

It defines the minimum speed (**S**) of the system. The unit of measure depends by system resolution. If it's set a **S** at speed less than this, it is limited at **SPEEDMIN**.

24.17.1.7 SPEEDDEF

It defines the default speed (**S**) set by the system at start-up. The unit of measure depends by system resolution.

24.17.1.8 VMAXG0

It defines the maximum speed for the positioning with G0. It is in percent of the speed calculated by system based to maximum speed of each axis.

Value can be from 0 to 100 %.

[This parameter is affected by unit of measure set. Working with resolution of 0.0001 \(instead of typcal 0.001\) this parameter must be expressed in tenth of mm/min.](#)

24.17.1.9 ACC_G0

It defines the acceleration for positioning with G0. See the above note to detail for unit of measure.

24.17.1.10 ACC_G0.1

It defines the private acceleration for positioning with G0.1

24.17.1.11 ACC_MAX

It defines the max acceleration for single used in the function G66 X-100 for Adaptive Feed Control.

24.17.1.12 ACC_LAV

It defines the acceleration for interpolation with G1, G2 and G3. See the above note to detail for unit of measure.

24.17.1.13 ACC_QSTOP

It defines the acceleration for quick-stop when the position limit is reached. See the above note to detail for unit of measure.

24.17.1.14 VEL_GO_LINE_RETRACE

It defines the speed for positioning “GO LINE” during RETRACE function. The unit of measure depends by system resolution (typically mm/min).

[This parameter is affected by unit of measure set. Working with resolution of 0.0001 \(instead of typcal 0.001\) this parameter must be expressed in tenth of mm/min.](#)

24.17.1.15 ACC_RAGGIO_MAX

It defines the centrifuge acceleration to auto-reducing speed on circular interpolation. It must be set after machine test. Normally this parameter is set with values from 1 to 15

Small values defines a greater feed reduction when the radius are small. If the minimum value 1 is not sufficient to reduction your desired feed, is necessary use the decimal part in the following mode (this function is enabled only in the ComSynk rev: 2.0.5.22 or greater):

Insert the parameter ACC_RAGGIO_MAX with value greater to 100, the effective value is:

ACC_RAGGIO_MAX_EFFECTIVE=(ACC_RAGGIO_MAX-100)/10

So:

109 = 0,9

108 = 0,8

Etc.

24.17.1.16 VRIPOSO

It defines the speed for re-positioning in start after PAUSE. The unit of measure depends by system resolution (typically mm/min). This speed acts only if axis are moved in PAUSE state and they aren't repositioned in the exact point when restarted.

24.17.1.17 SGLP

Threshold in tenth of degree (default 200 = 20 degree) to stop axis on edge when CN works in FAST INTERPOLATION. Threshold acts only on work plane axis. CN stop automatically the axis when on work plane it recognizes an angle greater than SGLP (edge found).

24.17.1.18 SGLP_RED

Percentage of SGLP to begin the gradual slowdown in the proportion of the edge. If SGLP_RED = 0 parameter is disabled and is done only stop on the corner SGLP, otherwise the percentage set, the CNC starts slowing down (see examples below). When SGLP_RED is set to a value greater than 0, it would be necessary to increase the value of SGLP.

24.17.1.19 MAX_RED

Maximum percentage reduction in speed caused by the parameter SGLP_RED. This is always limited to a value below 100% (to avoid that the speed goes to ZERO) (see examples below)


Example Parameter SGLP_RED and MAX_RED

If SGLP_RED is disabled (value set to ZERO) work only parameter SGLP or SGL3D in the following mode:

Corner less to SGLP or SGL3D the CNC not commands the stop axes


Corner greater to SGLP or SGL3D the CNC decelerates and commands the STOP Axes

Ex: SGLP=200 (20 degrees) , SGLP_RED=0



Ex: SGLP=450 (45 degrees) , SGLP_RED=10 (10% of 45 degrees – at 4,5 degrees start the slowdown)

MAX_RED=85



24.17.1.20 SGLR

Threshold to signal an error for circular interpolation.

In circular interpolation CN computer radium in start point and in end point, if the difference is greater than SGLR program is stopped showing an error. That happens when arc is made by center positions I,J with value not accurate.

The unit of measure depends by system resolution (typically 0.001 mm, default 10 thousandths). Ex:

Unit of measure 0.001 mm

10 = 10 thousandths of mm

Unit of measure 0.0001 mm

100= 10 thousandths of mm

24.17.1.21 ACQ_MODE

It define the acquisition mode for searching of the **SENSOR** with **G102** function and for **StartAcqSens** method of Framework. Actually not in use, reserved for future expansion.

24.17.1.22 ACQ_VEL

It defines the axis speed for acquisition sensor cycle.

Contrary to other speed parameters this is NOT affected by unit of measure and must be expressed always in mm/min

24.17.1.23 RESQUOTE

Resolution for axis position. It depends by DSOF-axis parameter.

It defines the minimum unit for axis position:

10 → Tenth of mm

100 → Hundredths of mm

1000 → Thousandths of mm

10000 → 0.1 Thousandths of mm

100000 → 0.01 Thousandths of mm

24.17.1.24 VISUAREAL

Enable or disable showing of axis ACTUAL positions

-1 = Disable reading of actual position

0 = Enable by INTERFACE

1 = Enable reading of ACTUAL positions

2 = Enable reading of ACTUAL FOLLOWING ERROR position

24.17.1.25 ENABLE_OW_G0

Enable or disable override potentiometer on G0

NO = Potentiometer disabled

YES = Potentiometer enabled

NO G0 ACK = Potentiometer disabled with Acknowledged on CN

YES G0 ACK = Potentiometer enabled with Acknowledged on CN

24.17.2 Axis parameters**24.17.2.1 VMAX_**

It defines the maximum speed of the single axis for positioning with G0. The unit of measure depends by system resolution (typically mm/min).

This parameter is affected by unit of measure set. Working with resolution of 0.0001 (instead of typcal 0.001) this parameter must be expressed in tenth of mm/min.

24.17.2.2 VMAX_Pn

It defines the maximum speed of the positioner number

24.17.2.3 VJOG_

It defines the speed of the single axis manual positioning (jogging). The unit of measure depends by system resolution (typically mm/min).

Contrary to other speed parameters this is NOT affected by unit of measure and must be expressed always in mm/min

24.17.2.4 ACC_JOG_

Acceleration for JOGGING positioning. See the above note to detail for unit of measure.

24.17.2.5 RZERO_MODE

This parameter defines the mode of homing procedure. These are the value accepted:

RZERO_MODE=0 - Backward (negative), sensor ACTIVATED

- 1) Fast backward to zero-sensor with **F=RZERO_VEL**
- 2) Slow forward to exit from zero-sensor with **F=RZERO_VELF**
- 3) Slow backward to zero-sensor with **F=RZERO_VELF**
- 4) Move axis to offset position (**RZERO_OFFSET**) with **F=RZERO_VEL**
- 5) Preset position at **RZERO_PRESET**

RZERO_MODE=1 - Forward (positive), sensor ACTIVATED

- 1) Fast forward to zero-sensor with **F=RZERO_VEL**
- 2) Slow backward to exit from zero-sensor with **F=RZERO_VELF**
- 3) Slow forward to zero-sensor with **F=RZERO_VELF**
- 4) Move axis to offset position (**RZERO_OFFSET**) with **F=RZERO_VEL**
- 5) Preset position at **RZERO_PRESET**

RZERO_MODE=2 - Backward (negative), sensor ACTIVATED with encoder INDEX

- 1) Fast backward to zero-sensor with **F=RZERO_VEL**
- 2) Slow forward to exit from zero-sensor with **F=RZERO_VELF**
- 3) Slow backward to zero-sensor with **F=RZERO_VELF**
- 4) Continue to first encoder INDEX always with **F=RZERO_VELF**
- 5) Move axis to offset position (**RZERO_OFFSET**) with **F=RZERO_VEL**
- 6) Preset position at **RZERO_PRESET**

RZERO_MODE=3 - Forward (positive), sensor ACTIVATED with encoder INDEX

- 1) Fast forward to zero-sensor with **F=RZERO_VEL**
- 2) Slow backward to exit from zero-sensor with **F=RZERO_VELF**
- 3) Slow forward to zero-sensor with **F=RZERO_VELF**
- 4) Continue to first encoder INDEX always with **F=RZERO_VELF**
- 5) Move axis to offset position (**RZERO_OFFSET**) with **F=RZERO_VEL**
- 6) Preset position at **RZERO_PRESET**

RZERO_MODE=4 - Backward (negative), sensor DISACTIVATED

- 1) Fast backward to zero-sensor with **F=RZERO_VEL**
- 2) Slow forward to exit from zero-sensor with **F=RZERO_VELF**
- 3) Move axis to offset position (**RZERO_OFFSET**) with **F=RZERO_VEL**
- 4) Preset position at **RZERO_PRESET**

RZERO_MODE=5 - Forward (positive), sensor DISACTIVATED

- 1) Fast forward to zero-sensor with **F=RZERO_VEL**
- 2) Slow backward to exit from zero-sensor with **F=RZERO_VELF**
- 3) Move axis to offset position (**RZERO_OFFSET**) with **F=RZERO_VEL**
- 4) Preset position at **RZERO_PRESET**

RZERO_MODE=6 - Backward (negative), sensor DISACTIVATED with encoder INDEX

- 1) Fast backward to zero-sensor with **F=RZERO_VEL**
- 2) Slow forward to exit from zero-sensor with **F=RZERO_VELF**
- 3) Continue to first encoder INDEX always with **F=RZERO_VELF**
- 4) Move axis to offset position (**RZERO_OFFSET**) with **F=RZERO_VEL**
- 5) Preset position at **RZERO_PRESET**

RZERO_MODE=7 - Forward (positive), sensor DISACTIVATED with encoder INDEX

- 1) Fast forward to zero-sensor with **F=RZERO_VEL**
- 2) Slow backward to exit from zero-sensor with **F=RZERO_VELF**
- 3) Continue to first encoder INDEX always with **F=RZERO_VELF**
- 4) Move axis to offset position (**RZERO_OFFSET**) with **F=RZERO_VEL**
- 5) Preset position at **RZERO_PRESET**

RZERO_MODE=8 – Backward to encoder INDEX (no sensor)

- 1) Slow backward to first encoder INDEX with **F=RZERO_VELF**
- 2) Move axis to offset position (**RZERO_OFFSET**) with **F=RZERO_VEL**
- 3) Preset position at **RZERO_PRESET**

RZERO_MODE=9 – Forward to encoder INDEX (no sensor)

- 1) Slow forward to first encoder INDEX with **F=RZERO_VELF**
- 2) Move axis to offset position (**RZERO_OFFSET**) with **F=RZERO_VEL**
- 3) Preset position at **RZERO_PRESET**

RZERO_MODE=32 – No searching, HOME position on ENABLE DRIVE**RZERO_MODE=64 – No searching, position from ABSOLUTE ENCODER****RZERO_MODE=128+HOME_MODEx256 – CanOpen DS402 mode of HOMING procedure****24.17.2.6 LIMITE_N_**

Primary Negative limit of axis position **SOFTWARE-LIMIT**. The unit of measure depends by system resolution (typically 0.001 mm, for ex. -10000 = -10mm).

24.17.2.7 LIMITE_P_

Primary Positive limit of axis position **SOFTWARE-LIMIT**. The unit of measure depends by system resolution (typically 0.001 mm, for ex. 2000000 = 2000mm).

24.17.2.8 2ND_LIMITE_N_

Secondary Negative limit of axis position **SOFTWARE-LIMIT**. The unit of measure depends by system resolution (typically 0.001 mm, for ex. -10000 = -10mm).

24.17.2.9 2ND_LIMITE_P_

Secondary Positive limit of axis position **SOFTWARE-LIMIT**. The unit of measure depends by system resolution (typically 0.001 mm, for ex. 2000000 = 2000mm).

24.17.2.10 LIMITE_N_Pn

Negative limit positioner

24.17.2.11 LIMITE_P_Pn

Positive limit of positioner

24.17.2.12 DSOFV

Software divider for the position of electronic manual hand-wheel. It reduces or increases its resolution. A negative value reverse the direction.

It is strictly related to VTB application, for ex:

Encoder Pulse = 100 pulse/rev.

SCALA=1 (VTB application parameter)

FILTRO=10 (VTB application parameter)

DSOFV=10000 (pulse x filtro x 10 thousandths)

Working with default resolution of 0.001mm we obtain a hundreds for each encoder pulse.

24.17.2.13 RZERO_OFFSET

Value of axis positioning after homing procedure (see RZERO_MODE parameter for details). The unit of measure depends by system resolution (typically um).

24.17.2.14 RZERO_PRESET

Value of preset position after homing procedure (see RZERO_MODE parameter for details). The unit of measure depends by system resolution (typically um).

24.17.2.15 RZERO_VEL

Fast speed for homing procedure (see RZERO_MODE parameter for details).

The unit of measure depends by system resolution (typically mm/min).

24.17.2.16 RZERO_VELF

Slow speed for homing procedure (see RZERO_MODE parameter for details).

The unit of measure depends by system resolution (typically mm/min).

24.17.2.17 RZERO_ACC

Acceleration for all movement of homing procedure. See the above note to detail for unit of measure.

24.17.2.18 MSOF_

It defines the number of pulse of one shaft revolution. If incremental encoder are connected to CN the pulse number must be multiplied for 4 to adjust hardware decoder. It works strictly related with DSOF, indeed the ratio MSOF/DSOF is used to transform unit from pulse to millimetres.

24.17.2.19 DSOF_

It defines the envelope one shaft revolution. It works strictly related with DSOF, indeed the ratio MSOF/DSOF is used to transform unit from pulse to millimetres.

This value determines the unit of measure of the system. Typically it's put a value in thousandths of mm. Accordingly it must set **RESQUOTE** parameter properly.

10 → *Tenth of mm*

100 → *Hundredths of mm*

1000 → *Thousandths of mm*

10000 → *0.1 Thousandths of mm*

100000 → *0.01 Thousandths of mm*

24.17.2.20 GANTRY

It defines the index to which axis get the position value. This function can be used to enable GANTRY function. This is the relationship from index and axis name:

0	→ AXIS X
1	→ AXIS Y
2	→ AXIS Z
3	→ AXIS A
4	→ AXIS B
5	→ AXIS C
6	→ AXIS U
7	→ AXIS V
8	→ AXIS W

To enable GANTRY function:

<i>GANTRY_X</i> → 0=disabled or index of axis master
<i>GANTRY_Y</i> → 1=disabled or index of axis master
<i>GANTRY_Z</i> → 2=disabled or index of axis master
<i>GANTRY_A</i> → 3=disabled or index of axis master
<i>GANTRY_B</i> → 4=disabled or index of axis master
<i>GANTRY_C</i> → 5=disabled or index of axis master
<i>GANTRY_U</i> → 6=disabled or index of axis master
<i>GANTRY_V</i> → 7=disabled or index of axis master
<i>GANTRY_W</i> → 8=disabled or index of axis master

ATTENTION!!!

To enable GANTRY function it must be supported by VTB application on CN.

24.17.2.21 SGL3D

It defines the threshold to detection of **EDGE** in 3D interpolations. This is used by **G65 G67** or by **AFC** filter **G66**. The value is approximatively expressed in tenth of degree. The proper value must be found from dynamics of the machine. In **G65** or **G67** interpolation when an axis overcomes this threshold axis are stopped.

Reference value for SGL3D

THRESHOLD in DEGREES	VALUE OF SGL3D (min-max)
5	60-90
10	125-175
20	250-350
30	300-500
45	400-700

24.17.2.22 SGLAFC

It defines the threshold for **AFC G66** to automatic reduction of the speed. This value determines the maximum speed change of each axis tolerates. When in the path are found values higher than SGLAFC speed is reduced. The value depends by dynamic of machine.

24.17.2.23 MILD

It Defines the MILD MODE value ([see G49 functions](#))

Estimated values from 200 to 20

0 or 1000 DISABLED

24.17.2.24 SGLP_MILD

It Defines the threshold 2D **ABOVE THIS VALUE THE MILD MODE Doesn't Works**

24.17.2.25 SGL3D_MILD_

It Defines the threshold 3D **ABOVE THIS VALUE THE MILD MODE Doesn't Works**
(see **SGL3D** for degrees references)

24.17.2.26 BACKLASH

Parameter for BACKLASH compensation. The unit of measure depends by system resolution (typically 0.001 mm, for ex. -10 = 0.01mm).

24.17.2.27 TBCK

It define a time to achieve the BACKLASH recovery. If Se TBCK>=BACKLASH it is recovered in a single CN sample, else it is divided in more samples The number of samples will be: **BACKLASH / TBCK**
With the result rounded-up.

Ex:

```
BACKLASH=100
TBCK=80
N.SAMPLES=1.25 → 2 samples
```

Sample is defined in the VTB application on CN (typically 2 msec).

It's recommended to distribute the BACKLASH recovery in more sample when it is high (over 3-4 hundredths).

24.17.2.28 TSHF

It define a time to achieve the SetShiftAxis recovery.

This value indicate the increment xTAU

Ex:

```
TAU=2 Ms
ValShift=100
TSHF_=10
```

The entire position is reached in 20 Ms

24.17.2.29 WR_SPD9

It define automatic write SPEED "S" to variable USER GENERIC 10 to NC.

WR_SPD=0 Automatic write disabled

WR_SPD=1 Automatic write Enabled

If WR_SPD=1 when the S value of PartProgram is automatically writing to NC Variable User Generic 10

24.17.2.30 RFG

It define automatic limitation FEED in G1-G2-G3

RFG=0 Whitout limitation

RFG=1 If the velocity exceeds that of the single axis (VMAX_), it is limited

24.17.2.31 JERK

It define the value of JERK for S Ramp.

If the value is ZERO the S ramp is disabled (use trapezoidal ramp)

Value > 0 enable S ramp.

Max value 100

24.17.2.32 CR_LIMIT

Enables or disables the prior control of axis limits

If enabled, each START, PART PROGRAM is not performed if the axes exceed the limits set machine

CR_LIMIT=0 Disable

CR_LIMIT=1 Preventive control G0-G1 activated only on the final point of G2-G3

CR_LIMIT=2 Preventive control activated G0-G1-G2-G3 (with explosion of ARCS)

CR_LIMIT=3 Preventive control activated G0-G1-G2-G3 only in run time, before executed the block (G2-G3 Only final point is controlled)

24.17.2.33 ARC_REL

Enables or disables the center of arc I,J in relative mode

ARC_REL=0 The center I,J is in absolute mode (if set G90)

ARC_REL=1 The center I,J is in relative mode (if set G90)

24.17.2.34 NO_SHORT

Enables or disables the CNC to remove the short segments

NO_SHORT=0 Function disactivated

NO_SHORT=1 short segment are removed by CNC. This facilitates the machining of complex contours

NO_SHORT=2 Only Warning message is displayed if the short segment is worked

24.17.2.35 USE_G60

If the value is >0, enabled default mode G60 and not G61

24.17.2.36 TIME_OUT_CMD

TimeOut Commands invoked on CNC. Value in Ms (default 5000)

24.17.2.37 TIME_OUT_M

TimeOut M invoked on CNC.. Value in Ms (default 5000)

24.17.2.38 G62_TO_G40

If it is set to 1 (YES) will be add a **G62** After **G40** (end tool offset).

This allows to empty the movements buffer

24.17.2.39 LIMIT_G41G42

If it is set to 1 (YES) the previous limits, or simulation limits will be check only in the **G41** or **G42** phase, and not in **G40** phase (center of tool).

WARNING

In this case, could be that the center of tools is inside the machine limits, and the external of tools is outside of machine limits

24.17.2.40 INVERT_G2G3

If it is set to 1 (YES) the **G2** (CW circular interpolation) is inverted with **G3** (CCW circular interpolation) when is set the Work Plane **G18 XZ**

24.17.2.41 STANDARD_IJ

If it is set to 1 (YES) uses the standard convention for parameters I,J,K

24.17.2.42 ACC_VMODE_X,Y,Z,A,B,C,U,V,W

Acceleration for the axis in SPEED MODE, G108.4 Function

24.17.2.43 ENABLE_RFEED

If ON (1) enables the events generation and display of Real Axes Feed

Available on **ComSynk** 3.0.0.500 or greater and **IsoVirtual** 2.5.0 or greater

24.17.2.44 NEW_ORIGINS

If ON (1) enables the Origins file management. The file “Zeri.val” will be renamed “Origins_n.val” where **n** is the IsoUs process.

Now all Origins are separated for each process

24.17.2.45 USE_G80_CYCLES

If ON (1) enables the migrations of codes:

G1080 → G80
G1081 → G81
G1082 → G82
G1083 → G83
G1084 → G84
G1028 → G28

And vice versa

24.17.2.46 G28_HOME_

Defines the Home position for single Axis for the **G1028 (G28)** function
The unit of measure depends by system resolution (typically um).

24.17.2.47 DIVACC

Defines the acceleration divisor for interpolator MSL.

Typical value 10, higher values define lower accelerations

24.17.2.48 AXES_Z

Defines **AXIS Z** index (depth) for canned cycles G81,82,83,84

24.17.2.49 AXES_G84

Defines **AXIS Tapping** index for canned cycle G84

Only for INTERPOLATE MODE

24.17.2.50 MODE_G84

G84 Mode

NORMAL (0) for **NON INTERPOLATE AXIS** (normal Spindle)

INTERPOLATE (1) for Interpolate Axis Spindle

The Tapping Step is calculated from **S** and **F** set

24.17.2.51 ROT_G84

Rotation direction for INTERPOLATE Tapping Axis

POSITIVE (0)

NEGATIVE (1)

24.17.2.52 MOLT_G84

Feed multiplier for tapping Axis G84

24.17.2.53 DELTA_G83

D parameter for function [G1083](#) (G83)

24.17.2.54 PRIORITY_TASK1 – PRIORITY_TASK2

Set the priority for the TASK1 and TASK2. That indicate the interval time for execution task.

Value=0 (default) Max priority

Set value from 0 to 100

24.18 PID PARAMETERS

The PID Parameters are used for the analogical Axes velocity control with Encoder Loop.

Usually, these Axes are controlled by +/- 10 Analog Outputs.

These Parameters are inserted by Isous configurator “Machine Parameters→Default Par PID”:



24.18.1.1 PID_KP

Proportional Gain

24.18.1.2 PID_KI

Integrative Gain

24.18.1.3 PID_KV

Feed Forward Gain.

For a correct setting You have to use the following method:

- 1) Set to ZERO (0) the PID_KP and PID_KI
- 2) Insert a PID_KV value
- 3) Move the axes and check if the real position is near to target (+/- 5 %)
- 4) Insert the PID_KP and PID_KI

WARNING

This operation must be did with Axis disconnected from mechanical part

24.18.1.4 PID_I_LIMIT

Integrative Limit

24.18.1.5 PID_DIV

PID parameters Magnitude. Increase this parameter for Increase the PID parameter resolution:

Ex: PID_DIV=10 PID_KP=1

It Is the same

PID_DIV=100 PID_KP=10

24.18.1.6 PID_SERVO

Maximum following error (micron).

If the Axis exceeds this value, an alarm is invoked

(must be exceeds this value for a PID_TIME_SERVO time)

24.18.1.7 PID_TIME_SERVO

If the Axis exceeds the PID_SERVO for a time lower of PID_TIME_SERVO (Millisecond)

The ERROR isn't invoked

24.18.1.8 PID_DIR

Analog Outputs Direction (0 or 1)

Set this parameter for tuning the Axis direction with Analog Output

WARNING

For change the Axis direction (ex: CW in CCW) is necessary Change this Parameter and also change the SIGN of MSOF parameter (ex: 5000 to -5000)

24.18.1.9 PID_OFFSET_ANA

Reset the analog output Offset.

With all PID parameters (KP,KI) set to ZERO, set this parameter until the axis is stationary (when it is enabled)

24.19 SPINDLE PARAMETERS

Parameters for SPINDLE

24.19.1.1 SPEEDMAXSPINDLE

Max rpm for SPINDLE when the analog output is 10V

24.19.1.2 ANALOG_BIT_RES

Analog resolution for the set Channel (see [Chapr. 12.8](#))

24.19.1.3 SPEED_ANALOG_CH

Analog Channel for SPINDLE (see [Chapr. 12.8](#))

24.19.1.4 ENABLE_OF_SPEED

Manage the override for spindle

<i>DISABLE</i>	No Override
<i>EXTERNAL</i>	External Override managed by VTB application
<i>INTERNAL VIRTUAL</i>	Enable the virtual override by Plugin USSPINDLEMANAGER (IsoUs)

24.19.1.5 SPEED_OW_MIN

Minimum value in percentage for override refer to current SPEED set (0-100%)

24.19.1.6 SPEED_OW_MAX

Maximum value in percentage for override refer to current SPEED set (0-100%)

Index

2.1	BLOCK.....	3
2.2	LINE NUMBER OR BLOCK NUMBER.....	3
2.3	PROGRAM RUNNING.....	3
2.4	AXIS NAME	3
2.5	HOMING.....	3
2.6	WORK ORIGIN	3
2.7	WORK OFFSET	4
2.8	HEADS	4
2.9	MODAL FUNCTIONS.....	4
2.10	RECOGNIZED CODES.....	4
2.11	NUMERIC VALUES SETTING	4
2.12	PROGRAM REMARKS	4
3.1	RECOGNIZED G CODES.....	5
4	OTHERS RECOGNIZED CODES.....	8
4.1	PROGRAM FLOW INSTRUCTIONS.....	10
4.2	MULTI TASK INSTRUCTIONS	10
4.3	GENERIC INSTRUCTIONS	11
4.4	MATH AND LOGICAL OPERATORS	12
4.5	MATH FUNCTIONS	13
4.6	VARIABLES AND CONSTANTS	14
4.7	PREDEFINED VARIABLES	14
4.8	NSFORMS INSTRUCTIONS	15
4.9	COMPILATOR SWITCH AND DIRECTIVE.....	16
4.10	INSTRUCTIONS FOR REMOTE CONTROLS.....	17
4.11	INSTRUCTIONS FOR MULTI PROCESS CONTROL.....	18
5.1	IF-ELSE-END_IF.....	19
5.2	LOOP - END_LOOP	19
5.3	GOTO	20
5.4	GOSUB – RETURN	20
5.5	LABEL.....	21
5.6	END_PROGRAM.....	21
5.7	WAIT_INPUT	21
5.8	ERROR	22
5.9	RESUME_T	22
5.10	SAVE_T.....	22

6.1	SDO_DL	23
6.2	SDO_UL	23
6.3	GET.....	23
6.4	READ_PARMAC.....	25
6.5	WRITE_PARMAC.....	25
6.6	OPT.....	25
6.7	PAUSE_MODE.....	26
6.8	IMPORT	26
6.9	END_IMPORT	26
6.10	STOP_MODE	27
6.11	DEBUG_INFO.....	27
7.1	LIB.HMESSAGE.....	29
8.1	LIB.MESSAGE	30
8.2	LIB.SHOWFORM	32
8.3	LIB.CLOSEFORM	32
8.4	LIB.FORMPROP	32
8.5	LIB.FORMTEXT	33
8.6	LIB.ADDLABEL.....	33
8.7	LIB.LABELPROP	33
8.8	LIB.LABELTEXT	34
8.9	LIB.LABELPRINT	35
8.10	LIB.ADDBUTTON	35
8.11	LIB.BUTTONPROP	35
8.12	LIB.BUTTONTEXT	37
8.13	LIB.BUTTONPRINT	37
8.14	LIB.ADDINPUT.....	37
8.15	LIB.INPUTPROP	38
8.16	LIB.INPUTSETVALUE	39
8.17	COLOR TABLE	40
9.1	IFDEF	42
9.2	ELSEDEF	42
9.3	ENDIFDEF.....	42
9.4	NOAXESREADY.....	43
9.5	ONERROR	43
9.6	ONSTOP.....	43
9.7	ENDON	43
9.8	USET	43

9.9	USEH	43
10.1	SIN	44
10.2	COS	44
10.3	LOG	44
10.4	EXP	44
10.5	INT	44
10.6	FIX.....	45
10.7	ABS	45
10.8	DRG.....	45
10.9	RAD.....	45
10.10	SQR.....	45
10.11	TAN	45
10.12	ATAN	46
10.13	ASIN	46
10.14	ACOS.....	46
I.	ISTRUZIONI PER IL CONTROLLO MULTIPROCESSO	47
11.1	CNC.LOAD	48
11.2	CNC.RUN.....	48
11.3	CNC.PREVIEW	48
11.4	CNC.STOP.....	49
11.5	CNC.PAUSE.....	49
11.6	CNC.STATUS	49
11.7	CNC.STATUSBIT	50
11.8	CNC.INFO	50
11.9	CNC.AXIS.....	50
11.10	CNC.GROUP	51
11.11	CNC.READVARADDR.....	51
11.12	CNC.READVARNAME.....	52
11.13	CNC.WRITEVARADDR	52
11.14	CNC.WRITEVARNAME	52
11.15	CNC.READPARMAC.....	52
11.16	CNC.WRITEPARMAC	52
11.17	CNC.ENABLEAXIS.....	53
11.18	CNC.HOMEAXIS.....	53
11.19	CNC.READGENERIC.....	53
11.20	CNC.WRITEGENERIC	53
12.1	REMOTE LOAD	55

12.2	REMOTE.RUN	55
12.3	REMOTE.STOP	55
12.4	REMOTE.PAUSE	56
12.5	REMOTE.STATUS	56
12.6	REMOTE.MOVE	56
12.7	REMOTE.INFO	57
12.8	REMOTE.AXIS.....	57
12.9	REMOTE.GROUP	58
12.10	REMOTE.READISOVAR.....	58
12.11	REMOTE.READVARNAME	58
12.12	REMOTE.WRITEISOVAR	59
12.13	REMOTE.WRITENAMEVAR	59
12.14	REMOTE.READCNVAR	59
12.15	REMOTE.WRITECNVAR	60
12.16	REMOTE.READINPUT	60
12.17	REMOTE.READOUTPUT	60
12.18	REMOTE.WRITEOUTPUT.....	61
14.1	ROUND BRACKETS ()	64
14.2	ISO EXPRESSIONS AND SQUARE BRACKETS [].....	64
14.3	VARIABLE TEST	64
14.4	BIT CONTROL	65
15.1	NUMERIC CONSTANTS	65
15.2	GENERIC VARIABLES "\$"	65
15.3	AXIS POSITION VARIABLES	66
15.4	DIGITAL INPUT/OUTPUT VARIABLES.....	66
15.5	TIMER VARIABLES	67
15.6	TOOL TABLE VARIABLES.....	68
15.7	HEAD TABLE VARIABLES	69
15.8	AXIS COUNTER VARIABLES	69
16	LIMIT AXIS VARIABLES	70
17	PREVIEW PARAMETERS	71
17.1	GLOBAL VARIABLE.....	73
17.2	M FUNCTION VARIABLES (FOR CN).....	73
17.3	SPECIAL PARAMETERS VARIABLES	73
17.4	WORK ORIGIN AND OFFSET VARIABLES	75
17.5	USER GENERIC VARIABLES.....	75
17.6	ARRAY VARIABLES - DIM	75

17.7	MARKER VARIABLES.....	76
17.8	VARIABLE FOR ANALOG SPINDLE OUTPUT	77
17.9	MACRO MANAGEMENT	78
19	PA-PD(N,PAR)ESPR SET ABSOLUTE POSITION	80
20	PF(N)ESPR SET POSITIONER FEED.....	80
21	PS(N) STOP POSITIONER	80
22	_PM(N,PAR) READ STATUS POSITIONER	80
23.1	DEFINITION OF AXIS POSITIONS	82
23.1.1	<i>Axis definition for Channel Address.....</i>	82
23.1.2	<i>G90 – PROGRAMMING WITH ABSOLUTE POSITIONS.....</i>	83
23.1.3	<i>G91 - PROGRAMMING WITH INCREMENTAL POSITIONS</i>	83
23.1.4	<i>Definition of absolute and incremental positions.....</i>	84
23.2	WORK ORIGIN.....	84
23.2.1	<i>Work origin By INDEX.....</i>	84
23.2.2	<i>G94 – Work origin at position defined with parameter.....</i>	86
23.2.3	<i>G54, G55, G56, G57, G58, G59 - Work origin from memory file</i>	87
23.2.4	<i>G92 – Work origin in current axis position</i>	88
23.2.5	<i>G82 – Work origin in current axis position with sensor offset.....</i>	88
23.2.6	<i>G98 – G53 - Suspend work origin</i>	88
23.2.7	<i>G99 – Restore work origin</i>	88
23.2.8	<i>G940 MOVE axes excluding WORK ORIGIN only in the actual block</i>	90
23.2.9	<i>USER_ZERO – Index of WORK ORIGIN LIST</i>	90
23.3	WORK OFFSET	91
23.3.1	<i>G93 - Work offset at position defined with parameter</i>	91
23.3.2	<i>G95 - Work offset in current axis position</i>	91
23.3.3	<i>G85 - Work offset in current axis position with sensor offset.....</i>	91
23.3.4	<i>G86 - Hardware preset axis on module 360 degrees</i>	92
23.3.5	<i>G96 - Suspend work offset.....</i>	92
23.3.6	<i>G97 - Restore work origin</i>	92
23.3.7	<i>USER_OFFSET - Index of WORK OFFSET LIST</i>	92
23.4	WORK HEAD SELECTION – H FUNCTION	94
23.4.1	<i>Hn – Select head.....</i>	94
23.4.2	<i>G87 – Suspend head offset.....</i>	94
23.4.3	<i>G88 – Restore head offset</i>	94
23.5	ROTATIVE AXIS	95
23.5.1	<i>G36 – Rotative axis definition.....</i>	95
23.6	HARDWARE PRESET OF AXIS	96
23.6.1	<i>G89 – Hardware preset of axis position</i>	96
23.7	HARDWARE PRESET OF AXIS	96
23.7.1	<i>G84 – Preset Axes counters</i>	96
23.7.2	<i>G83 – Preset CPU 1 counters</i>	96
23.8	CANNED CYCLES	97
23.8.1	<i>G1080 – Disabled Canned Cycles.....</i>	97
23.8.2	<i>G1081 – Drilling Cycle</i>	97

23.8.3	<i>G1082 – Drilling Cycle</i>	98
23.8.4	<i>G1083 – Drilling Cycle</i>	99
23.8.5	<i>G1084 – Tapping Cycle</i>	100
23.9	SELECT WORK PLANE	101
23.9.1	<i>G17 – Select work plane on X-Y</i>	101
23.9.2	<i>G18 - Select work plane on X-Z.....</i>	101
23.9.3	<i>G18.1 - Select work plane on X-Z but not in PREVIEW.....</i>	101
23.9.4	<i>G19 - Select work plane on Y-Z.....</i>	101
23.9.5	<i>G19.1 - Select work plane on Y-Z but not in PREVIEW.....</i>	101
23.9.6	<i>G70 - Select work plane on axis by parameters</i>	102
23.10	START SEARCH OF HOME POSITION	103
23.10.1	<i>G71 – Start Homing cycle</i>	103
23.10.2	<i>G71.1 Enable Axis</i>	103
23.10.3	<i>G71.2 Disable Axis.....</i>	103
23.11	AXIS MOVEMENT FUNCTIONS.....	104
23.11.1	<i>G0 – Rapid positioning</i>	104
23.11.2	<i>G0.1 – Rapid positioning with private Acceleration</i>	104
23.11.3	<i>G1 – Linear interpolation a programmed F speed.....</i>	105
23.11.4	<i>G1.1 – G1-G2-G3 Suspension and Set G0</i>	105
23.11.5	<i>G1.2 – Resume Gx saved with G1.1</i>	105
23.11.6	<i>G2/G3 - Circular interpolation a programmed F speed.....</i>	106
23.11.7	<i>G30 - Enable automatic insert of fillet on edges</i>	107
G31 – SUSPEND OF AUTOMATIC INSERT OF FILLET	108	
23.11.8	<i>G32 - Restore of automatic insert of fillet</i>	108
23.11.9	<i>G33 - Enable automatic insert of bevel on edges.....</i>	109
23.11.10	<i>G34 - Suspend of automatic insert of bevel.....</i>	110
23.11.11	<i>G35- Restore of automatic insert of bevel.....</i>	110
23.11.12	<i>G102 – Start searching sensor position</i>	111
23.12	PROGRAMMING AXIS INTERPOLATION SPEED	112
23.12.1	<i>F – Speed of axis interpolation</i>	112
23.12.2	<i>ARC speed auto-reduction.....</i>	112
23.13	WORK PLANE TRANSFORMATION	113
23.13.1	<i>G120 – Vertical mirror</i>	113
23.13.2	<i>G121 – Disable vertical mirror.....</i>	113
23.13.3	<i>G24 – Horizontal mirror.....</i>	114
23.13.4	<i>G25 – Disable horizontal mirror</i>	114
23.13.5	<i>G22 – Exchange axis of work plane.....</i>	114
23.13.6	<i>G23 – Restore axis of work plane</i>	115
23.13.7	<i>G26 – Exchange axis by parameter</i>	115
23.13.8	<i>G27 – Suspend G26</i>	115
23.13.9	<i>G28 – Restore G26.....</i>	115
23.13.10	<i>G1028 – Return to Home.....</i>	116
23.13.11	<i>G51 – Suspend work plane rotation</i>	116
23.13.12	<i>G52 – Restore work plane rotation.....</i>	116
23.13.13	<i>G50 - Work plane rotation.....</i>	117
23.13.14	<i>G1050 – Disable Scaling</i>	119
23.13.15	<i>G1051 – Enable Scaling</i>	119
23.13.16	<i>G103 – Set RTCP parameters.....</i>	121
23.13.17	<i>G104 – Enable/restore RTCP.....</i>	121
23.13.18	<i>G105 – Disable RTCP</i>	121

24 TOOL RADIUS COMPENSATION	122
24.1.1 <i>G41/G42 – Enable left/right radius tool compensation</i>	122
24.1.2 <i>G40 – Disable radius tool compensation.....</i>	122
24.1.3 <i>D – Tool diameter</i>	123
24.1.4 <i>G47 – Set tool entry mode.....</i>	124
24.2 TOOL LENGTH COMPENSATION.....	125
24.2.1 <i>G43 – Enable tool length compensation from parameter.....</i>	125
24.2.2 <i>G44 – Disable tool length compensation G43</i>	126
24.2.3 <i>G44.1 (2) – Suspend/Resume G43</i>	126
24.2.4 <i>G45 – Enable tool length compensation from tool table T</i>	126
24.2.5 <i>G46 – – Disable tool length compensation G45</i>	127
24.3 INTERPOLATION MODES	128
24.3.1 <i>G60 – Enable FAST interpolation without stop on segments.....</i>	128
24.3.2 <i>G61 – Enable interpolation with stop on segments.....</i>	128
24.3.3 <i>G62 – Wait for stop axis</i>	128
24.3.4 <i>G63 – Interpolation outside work plane (PX_MOVETO)</i>	129
24.3.5 <i>G64 – Interpolation on work plane (default).....</i>	129
24.3.6 <i>G65 – Enable 3D interpolation PX_MOVETO with calculated stop on edge by parameters.....</i>	130
24.3.7 <i>G75 – Enable G64 for movement inside the work plane , G65 for movement outside the work plane 130</i>	
24.3.8 <i>G66 – AFC – Adaptive Feed Control.....</i>	131
24.3.9 <i>G66 X-100 – NEW AFC – Adaptive Feed Control.....</i>	132
24.3.10 <i>G67 – Px_Moveto for movement outside plane and Px_Linetto for inside one</i>	135
24.3.11 <i>G68 – Always using of PX_LINETO in G1 “TRANSPORTED AXIS” (with possibility to combine with PX_MOVETO).....</i>	135
24.3.12 <i>G69 – LHK – Buffer look ahead depth.....</i>	136
24.4 ISOUS FILTERS	137
24.4.1 <i>G72 – N.U.R.B.S (Non Uniform Rational Bspline) (2D 3D)</i>	138
24.4.2 <i>G73 – NOISE (2D-3D).....</i>	141
24.4.3 <i>G74 – RLS Remove Len Segment (2D 3D)</i>	143
24.4.4 <i>G106 – Smoothing (2D 3D).....</i>	144
24.5 INTERRUPT MACRO.....	147
24.5.1 <i>G107 – Management Interrupt Macro.....</i>	147
24.6 EMERGENCY MACRO M60000 IN STOP MODE	150
24.7 G108 MANAGEMENT SPECIAL AXES	151
24.7.1 <i>G108.0 G108.1 G108.2 G108.3 - Master Slaves Axes</i>	151
24.7.2 <i>G108.4 G108.5 G108.6 SPEED MODE AXIS</i>	152
24.7.3 <i>G108.7 G108.8 G108.9 Physical exchange Axes</i>	152
24.8 VIRTUAL AXIS	153
24.8.1 <i>G100 – Comando sincrono per asse virtuale</i>	153
24.9 OTHER GENERIC G FUNCTIONS.....	154
24.9.1 <i>G4 – Timed pause.....</i>	154
24.9.2 <i>G4.1 – Time Add on Calc Time.....</i>	154
24.9.3 <i>G10 – Enable external OVERRIDE potentiometer</i>	154
24.9.4 <i>G11 – Disable external OVERRIDE potentiometer</i>	154
24.9.5 <i>G101 – Axis Stop command.....</i>	156
24.9.6 <i>G80 – Forced pause by code.....</i>	156

24.9.7	<i>G81 – Management secondary axes LIMITS</i>	157
24.9.8	<i>G20 – Axes Values in Inch</i>	157
24.9.9	<i>G21 – Axes Values in Millimeters.....</i>	157
24.10	VARIABLE MANAGEMENT FUNCTIONS.....	158
24.10.1	<i>LOAD_VAR – load a variables file in current list</i>	158
24.10.2	<i>GET_VAR – Read a value from the loaded list and store it in a variable</i>	158
24.10.3	<i>WRITE_VAR – Write a value in the loaded list getting it from a variable</i>	159
24.10.4	<i>SAVE_VAR – save a variables file with current list.....</i>	159
24.10.5	<i>FILE_EXISTS – test if a file exists</i>	159
24.10.6	<i>ADD_VAR – Add a value to current list.....</i>	160
24.10.7	<i>REMOVE_VAR – Remove a value from current list</i>	160
24.10.8	<i>CLEAR_VAR – Remove all values from the current list.....</i>	160
24.10.9	<i>DIM_VAR – Size current list to a specific number of elements</i>	161
24.10.10	<i>COUNT_VAR – Get the number of elements in the current list.....</i>	161
24.11	HM FUNCTIONS	162
24.11.1	<i>Call of HM functions</i>	162
24.11.2	<i>Building of a HM function</i>	163
24.12	M FUNCTIONS.....	164
24.12.1	<i>M functions inside CN.....</i>	164
24.12.2	<i>M function inside PC.....</i>	165
24.13	ESSENTIAL M FUNCTIONS	166
24.13.1	<i>START M</i>	166
24.13.2	<i>END M</i>	166
24.13.3	<i>STOP M</i>	166
24.13.4	<i>PAUSE M</i>	166
24.13.5	<i>RESUME PAUSE M</i>	167
24.13.6	<i>GO BLOCK M</i>	167
24.13.7	<i>GO RETRACE M</i>	167
24.14	DEFINING DEPTH AXIS.....	168
24.14.1	<i>G48 Define Depth axis</i>	168
24.15	MILD MODE – EDGE SMOOTHING	169
24.15.1	<i>G49 MILD MODE Managing</i>	169
24.16	PARALLEL TASKS.....	171
24.16.1	<i>USTASK-ENDTASK</i>	171
24.16.2	<i>TASK.RUN</i>	171
24.16.3	<i>TASK.STOP</i>	171
24.16.4	<i>TASK.PAUSE</i>	172
24.16.5	<i>TASK.READVAR</i>	172
24.16.6	<i>TASK.WRITEVAR</i>	172
24.16.7	<i>TASK.STATUS</i>	172
24.16.8	<i>TASK.LOADCMD</i>	173
24.16.9	<i>TASK.PRIORITY.....</i>	173
24.17	MAIN MACHINE PARAMETERS	174
24.17.1	<i>Generic parameters</i>	174
24.17.2	<i>Axis parameters.....</i>	177
24.18	PID PARAMETERS	185

24.19 SPINDLE PARAMETERS	186
---------------------------------------	------------