

IsoUs – Ultimate Step
Framework for .NET

www.promax.it



The contained information in this handbook are only informative and they can be changed without warning and they must not be understood with some engagement from Promax srl. Promax srl does not assume responsibility or obligates for errors or inaccuracies that can be found in this handbook. Except how much granted from the license, no part of this publication can be reproduced, saved in a recording system or transmitted in whatever form or with any means, electronic, mechanical or recording system or otherwise without Promax srl authorization.

Any reference to names of society or products have only demonstrative scope and it does not allude to some real organization.

Rev. 1.0.7 © Promax srl

1 PREFAZIONE

This manual, describes the IsoUs Framework for .NET application.
The framework is contained in the **UsWork.dll**.

1.1 Before Start

The use of UsWork.DLL provides that there is the configuration file "**IsoUs.cfg**" already installed in the same folder.
The configuration file contains all the informations necessary to component for the proper functioning and adaptation to the CNC in use.

In the same folder UsWork.DLL must be the following DLL:

Compiler.DLL

ComSynk.DLL

These are directly allocated by the component itself and therefore only require their presence.

The component is loaded in the development environment like all other components of the framework running the standard usage.

First you must assign the address of the property SetIsoUsCnC CN (usually 0)

```
const String KeyName = "HKEY_CURRENT_USER\Software\Promax\ISONS\InstallPathUs";
UsWork.IsoUs MyUsIso = new UsWork.IsoUs();

// Run Application
private void StartIsoUs()
{
    // Reg Application
    Microsoft.Win32.Registry.SetValue (KeyName, "ISONS", Environment.CurrentDirectory); //WPF
    Microsoft.Win32.Registry.SetValue(KeyName, "ISONS", Application.StartupPath); //Windows Form
    MyUsIso.SetIsoUsCnC(CncIndex, "IsoUs.cfg");
}
```

2 Events

2.1 AbsRelChanged

Event occurs to change the state of NC by absolute or relative. Generated as a result of an instruction manual functions G90 or G91.

False indicate Absolute Motion

True indicate Relative Motion

Example c#:

```
private void AbsRelChanged(object sender, UsWork.BoolArgs e)
{
    if (e.Value == false)
        ... Absolute
    else
        ... Relative
}
```

2.2 AcquisitionExecuteChanged

Event occurs to change the bit of a statusword “**probe acquisition**”.

Boolean value that indicates the status of acquisition

True acquisition terminated

False acquisition in RUN

Example c#:

```
private void AcqExecute(object sender, Boolean e)
{
    if(e..Value==True) // Acq Terminated
    else // Acq Run
}
```

2.3 AllAxesReadyChanged

Event occurs to change the Axes Status (homing or Enable)

Boolean value that indicates the axes sttus

True All Axes Reday (Homing e Enable)

False One o more Axis not ready (Homing e Enable)

2.4 AxesDemandValueChanged

Event occurs to change the demand position of Axes

FormatRealValue	contains an array of string formatted values of the absolute reference positions axes to machine zero
FormatSpaceErr	contains an array of string formatted values of the axes of space errors (difference between the theoretical position and current position)
Format	Contains an array of string formatted values of the axes positions These are referred to the axis and Zero Offset
RealValue	contains an array of Int32 values of the coordinates axes to machine zero absolute reference
Value	contains an array of Int32 values of the positions These are referred to the axis and Zero Offset
Mask	Int32 Bit mapped that indicates which axis has changed positions Bit 0 Axis X - Bit 1 Axis Y etc. .. The bit is not enabled, the event did not generate

Example c#:

```
private void AxesDemandValueChanged(object sender, UsWork.AxesValueArg e)
{
    Int32 P = 1;
    for (int n = 0; n < e.FormatValue.Length; n++)
    {
        if ((Mask & P) == P) // value changed
        {
            MyQuoteAbs[n].Text = FormatRealValue[n];
            MyQuoteRel[n].Text = FormatValue[n];
        }
        P <<= 1;
    }
}
```

2.5 AxesMoveChanged

Event occurs to change the Axes movement

True Axis movement
False Axis stop

Example c#:

```
private void MoveChanged(object sender, NsWork.BoolArgs e)
{
    if (e.Value == false)
        axis stop
    else
        axis movement
}
```

2.6 AxesOffsetValueChanged

Event occurs to change the offset axes following a G93 statement

Format containing a value formatted string
Index index of the axis
Value containing the integer value of the offset axis

Example c#:

```
private void AxesOffsetValueChanged(object sender, UsWork.OffsetArgs e)
{
    labelval.Text = e.Format;
    Int32 Value = e.Value;
    Double ValZero = e.Value;
    ValZero /= MyUsIso.UsAxesValue.AxesResolution;
}
```

2.7 AxesOriginChanged

Event occurs to change the axis zeros following a G94 statement

Format String position formatted value
Index Axis index
Value Int32 offset axis

Example c#:

```
private void AxesOriginChanged (object sender, UsWork.OffsetArgs e)
{
    labelval.Text = e.Format;
    Int32 Value = e.Value;
    Double ValZero = e.Value;
    ValZero /= MyUsIso.UsAxesValue.AxesResolution;
}
```

2.8 AxesDemandValueChanged

Event occurs to change the real position of Axes	
FormatRealValue	contains an array of string formatted values of the absolute reference positions axes to machine zero
FormatSpaceErr	contains an array of string formatted values of the axes of space errors (difference between the theoretical position and current position)
Format	Contains an array of string formatted values of the axes positions These are referred to the axis and Zero Offset
RealValue	contains an array of Int32 values of the coordinates axes to machine zero absolute reference
Value	contains an array of Int32 values of the positions These are referred to the axis and Zero Offset
Mask	Int32 Bit mapped that indicates which axis has changed positions Bit 0 Axis X - Bit 1 Axis Y etc. ... The bit is not enabled, the event did not generate

2.9 AxisEnabledChanged

Event occurs to change the enabled status of the driver of an axis	
Value	contains the status
True	Axis enabled
False	Axis disabled
IndexAxis	contains the index of axis (0-1-2) eg X, Y, Z

Example c#:

```
private void AxisEnabledChanged (object sender, UsWork.HomingEnableArgs e)
{
    if (e.Value == false)
        e.IndexAxis... //Disable
    else
        e.IndexAxis... // Enable
}
```

2.10 AxisHomeChanged

Event that occurs when an axis has finished homing function	
Value	contains the status of Home
True	Axis homing OK
False	Axis not homing
IndexAxis	contains the index of the axis (0-1-2) eg X, Y, Z

Example c#:

```
private void AxisHomeChanged (object sender, UsWork.HomingEnableArgs e)
{
    if (e.Value == false)
        e.IndexAxis... // no homing
    else
        e.IndexAxis... // homing
}
```

2.11 DigitalInputChanged

Event occurs to change the status of a digital input.	
The digital inputs enabled the generation of events must first be configured in the file IsoUs.cfg in the following mode:	
<EventsData UserGeneric="" DigitalInputs=" inputn,inputn1,inputn2 etc " />	
Where Inputn1,Inputn2 ecc. are the NC real digital inputs	
Ex:	
<EventsData UserGeneric="" DigitalInputs=" 1,5,32 " />	

Example c#:

```

private void DigitalInputChanged(object sender, UsWork.DigitalInputArgs e)
{
    for(int n=0;n<e.DigitalInput.Length;n++)
    {
        // e.DigitalInput is a integer vector that contains the digital inputs changed
        // ex: e.DigitalInput[0]=digital input 1 changed
        // e.DigitalState is a boolean vector that contains the state of relative input
        // e:x e.DigitalState[0]=false Input 1 false
        // test input 1
        if(e.DigitalInput[n]==1)
        {
            if(e.DigitalState[n]==true)
            {
                if(IsoNs .IsStatusRun==true) // if run
                    IsoNs.ProgramRun.PauseProg();
            }
        }
    }
}

```

2.12 EnableExtOverrideChanged

Event occurs to change the enabled status of the external potentiometer override

True external override enbled

False external override disabled

Example c#:

```

private void EnableExtOverrideChanged (object sender, UsWork.BoolArgs e)
{
    if (e.Value == false)
        ....Disable
    else
        .... Enable
}

```

2.13 EndImportChanged

Event occurs when the last IMPORT file is terminated

e.FileName NULL

e.FileImportPath Path file that has terminated the execution

2.14 ExtPauseRequestChanged

Event that occurs at the change of external input **PAUSE** program
 The input is defined in the CN application VTB
True request from external **PAUSE**

Example c#:

```
private void ExtPauseRequestChanged (object sender, UsWork.BoolArgs e)
{
    if (e.Value == true)
        MyUsIso.UsGcodeRun.PauseGcode();
}
```

2.15 ExtRunRequestChanged

Event that occurs at the change of external input **RUN** program
 The input is defined in the CN application VTB
True request from external **RUN**

Example c#:

```
private void ExtRunRequestChanged(object sender, UsWork.BoolArgs e)
{
    if (e.Value == true)
        MyUsIso.UsGcodeRun.ExecuteGcode(LineStart); // Run Prog
}
```

2.16 ExtStopRequestChanged

Event that occurs at the change of external input **STOP** program
 The input is defined in the CN application VTB
True request from external **STOP**

Example c#:

```
private void ExtStopRequestChanged(object sender, UsWork.BoolArgs e)
{
    if (e.Value == true)
        MyUsIso.UsGcodeRun.StopGcode();
}
```

2.17 FeedAxesChanged

Event occurs to change the set F
 The event is generated by F instructions or manual functions
 Contains an integer value of F
 Format contains a string formatted to units of measurement set

Example c#:

```
private void FeedAxesChanged(object sender, UsWork.FeedArgs e)
{
    LedFeed.Level = e.Value;
    LblFeed.Text = e.Format;
}
```

2.18 RealFeedAxesChanged

Event occurs to change the Real Axes Feed calculate in the CNC
Must be enabled the parameter ENABLE_RFEED
 Contains an integer value of F
 Format contains a string formatted to units of measurement set

Esempio c#:

```
private void RealFeedAxesChanged(object sender, UsWork.FeedArgs e)
{
    LedFeed.Level = e.Value;
    LblFeed.Text = e.Format;
}
```

2.19 HeadOffsetValueChanged

Event occurs to change the offset head following a **Hn** command
Format containing a value formatted string
Index index of the axis
Value containing the integer value of the offset axis

Example c#:

```
private void HeadOffsetValueChanged (object sender, UsWork.OffsetArgs e)
{
    labelval.Text = e.Format;
    Int32 Value = e.Value;
    Double ValZero = e.Value;
    ValZero /= MyUsIso.UsAxesValue.AxesResolution;;
```

2.20 MachineParametersUpdate

Event occurs when one or more machine parameters are changed by browser.

2.21 MulHandWheelChanged

Event occurs to change the multiplier value software for electronic handwheel. This event is generated even if the multiplier varies from application through VTB switch.
Value Int32 Contains the multiplier value

Example c#:

```
private void MulHandWheelChanged (object sender, UsWork.GenArgs e)
{
    Label1.Text=e.Value.ToString();
```

2.22 M_CnC_ExecuteChanged

Event that occurs at the end of a **M** function internal to the NC
True M in RUN
False M terminated

Example c#:

```
private void M_CnC_ExecuteChanged (object sender, UsWork.BoolArgs e)
{
    if(e.Value==true)
        // M START
    else
        // M terminated
}
```

2.23 OnCloseComRequest

Event occurs to end communication to NC

2.24 OverrideValueChanged

Event occurs to change the value of the Override Percentage FEED velocity axis.
Value Int32 analog input value (0-1023)
PercValue Percentage

Example c#:

```
private void OverrideValueChanged (object sender, UsWork.OverrideArgs e)
{
    LedOverride.Level = e.Value;
    LblOw.Text = e.PercValue + " %";
```

2.25 PauseChanged

Event occurs to change the pause state of NC
True NC in pause
False resume from pause

Example c#:

```
private void PauseChanged(object sender, UsWork.PauseArgs e)
{
    if (e.Value == false)
        // Resume
    else
        // PAUSE
}
```

2.26 RemoveMarkLineChanged

Event application required by simulation that enables an application to remove the marker line ISO. This event has a specific use is enabled only if the simulation with the file **Simulation.dll**. This file may take to the main interface to remove the marker line after an event **RequestMarkLineChanged**

2.27 RequestMarkLineChanged

Event application required by simulation that enables an application to mark a line in the Gcode ISO This event has a specific use is enabled only if the simulation with the file **Simulation.dll**. This file may take to mark a main interface ISO line to highlight it

2.28 RunStopChanged

Event that occurs at the change of state of the NC STOP RUN
True NC in RUN
False NC in STOP

Example c#:

```
private void RunStopChanged(object sender, UsWork.BoolArgs e)
{
    ProgInRun = e.Value;
    if (e.Value == false)
        // from RUN to STOP
    else
        // from STOP to RUN
}
```

2.29 RunStopChangedWithType

Event that occurs at the change of state of the NC STOP RUN with RUN type
True NC in RUN
False NC in STOP

Example c#:

```
private void RunStopChangedWithType (object sender, UsWork.TypeRunArgs e)
{
    // TypeRun=0 Normal Run
    // TypeRun=1 Preview Run
    // TypeRun=2 Resume from Block Run
    // TypeRun=3 Retrace Run
    // TypeRun=4 Execution Time Calc Run
}
```

2.30 ScriptChanged

Event that occurs at the RUN / STOP ISONS script code that is invoked when the method IsoNs.ProgramRun.ExecuteScript
True Script RUN
False Script terminated

Example c#:

```
private void ScriptChanged(object sender, UsWork.BoolArgs e)
{
    if (e.Value == false)
        .. Terminated
    else
        .. in esecuzione
}
```

2.31 SelectAxisJogChanged

Event occurs to change the value of the selected axis to jog.
e.value axis selected

0 → Axis X	1 → Axis Y	2 → Axis Z
3 → Axis A	4 → Axis B	5 → Axis C
6 → Axis U	7 → Axis V	8 → Axis W

Example c#:

```
private void SelectAxisJogChanged (object sender, UsWork.GenArgs e)
{
    Label1.Text=e.Value.ToString();
}
```

2.32 SpeedSpindleChanged

Event occurs to change the spindle speed in response to an instruction **S** from Gcode
Value Int32 **S** value
Format String formatted value
PercValue Double percentage of maxvalue (maxvaluesetted in isous.cfg)

Example c#:

```
private void SpeedSpindleChanged(object sender, UsWork.FeedArgs e)
{
    LedSpeed.Level = e.Value;
    LblSpeed.Text = e.Format;
    LblPerc.Text=e.PercValue.ToString();
}
```

2.33 StartImportChanged

Event occurs when IMPORT instruction is executed
e.FileName Text of imported file.
e.FileImportPath File of imported file

2.34 StepModeChanged

Event occurs to change the state of NC by way of execution STEP by STEP (line by line) to the continuous play mode.

True Step Mode

False Normal mode

Example c#:

```
private void StepModeChanged(object sender, UsWork.BoolArgs e)
{
    if (e.Value == false)
        BtnStepMode.ImageIndex = 0;
    else
        BtnStepMode.ImageIndex = 1;
}
```

2.35 TabUtChanged

Event occurs to change the selected value of the tool table.

ISO function **Tn**

Value Int32 **T** number selected

Example c#:

```
private void TabUtChanged(object sender, UsWork.GenArgs e)
{
    Label1.Text=e.Value.ToString();
}
```

2.36 ToolDiameterChanged

Event occurs to change the settings of the tool diameter.

Created in response to an instruction of the **D** Gcode. The value is contained in an integer and represents the thousandths of a millimeter in diameter tool.

Example c#:

```
private void ToolDiameterChanged (object sender, UsWork.GenArgs e)
{
    m_ActDiam = e.Value;
}
```

2.37 ToolLengthChanged

Event occurs to change the tool length set by the Gcode

Value contains the value in thousandths of a millimeter of the tool length

Example c#:

```
private void ToolLengthChanged (object sender, UsWork.GenArgs e)
{
    m_ActLenUt=e.Value;
}
```

2.38 UsFatalError

If this event is allocated, IsoUs does'nt manage the fatal Errors by notify the external application can get the events from Fatal Errors

```
void MyUsIso_UsFatalError(object sender, UsWork.UsFatalErr e)
{
    MessageBox.Show("ERROR CN :" + e.UsCnNumber.ToString() + "\n" + e.UsErrorMessage);
}
```

2.39 UsNotifyChanged

System Notify
Type:
CNC ALARM Alarm on CNC
CNC WARNING Warning on CN
DEFINE ERROR Defined Error by user (ERROR Gcode Function)
GCODE ERROR Error in Gcode
INFORMAZIONI Info

Example c#:

```
private void MyUsIso_UsNotifyChanged(object sender, UsWork.UsNotify e)
{
    switch(e.NotifyType)
    {
        case UsWork.IsoUs.UsNotifyType.UsCncAlarm:
            // CNC in Alarm
            MessageBox.Show("CNC ALARM : " + e.NotifyDescription);
            break;
        case UsWork.IsoUs.UsNotifyType.UsCncWarning:
            // CNC in Warning
            MessageBox.Show("CNC WARNING : " + e.NotifyDescription);
            break;
        case UsWork.IsoUs.UsNotifyType.UsGcodeDefineError:
            // Error define by User
            MessageBox.Show("CNC ERROR DEFINE BY USER : " + e.NotifyDescription);
            break;
        case UsWork.IsoUs.UsNotifyType.UsGcodeError:
            // Error in Gcode
            MessageBox.Show("ERROR IN GCODE : " + e.NotifyDescription);
            break;
        case UsWork.IsoUs.UsNotifyType.UsInfo:
            // Information
            MessageBox.Show("INFO : " + e.NotifyDescription);
            break;
    }
}
```

2.40 VariableUserChanged

Event that occurs at the change of a variable USER GENERIC IsoUs.cfg configured.
 GENERIC USER variables can be used for data exchange between NC and PC (since these are manageable by applying the CN VTB)
Value Int32 Array that contains the value of USER changed
Mask Bit mapped indicate which USER is changed
 Bit 0 User configured 1
 Bit 1 User configured 2 etc.
 Only those with bit 1 are changed

Example c#:

```
private void VariableUserChanged(object sender, UsWork.UserGeneric e)
{
    Int32 P=1;
    for(int n=0;n<e.Value.Length;n++) // check variable changed
    {
        if((e.Mask & P)==P) // variable changed
            LblUser.Text = e.Value[n].ToString();
        P <<= 1; // shift bit
    }
}
```

2.41 WorkLineDemandChanged

Event occurs to change the number of demand lines running
Value contains an integer number of demand line running

Example c#:

```
private void WorkLineDemandChanged (object sender, UsWork.GenArgs e)
{
    Label1.Text=e.Value.ToString();
}
```

2.42 WorkLineRealChanged

Event occurs to change line number REAL running on CN
 This line number may differ from the demand.
Value contains an integer number of CURRENT line running

Example c#:

```
private void WorkLineRealChanged (object sender, NsWork.GenArgs e)
{
    Label1.Text=e.Value.ToString();
}
```

2.43 WorkPlaneSetChanged

Event occurs to change the work plan as a result of the NC **G17 G18 G19 G70** instructions
WorkPlaneSet contains an array of string with the names of the two axes

Example c#:

```
private void PianoChanged(object sender, UsWork.WorkPlaneArgs e)
{
    LblPiano1.Text = e.WorkPlaneSet0];
    LblPiano2.Text = e.WorkPlaneSet0[1];
}
```

2.44 UsCompiler.CodeLoaded

Event occurs when the compiled code is loaded in the IsoUs memory
Now is ready to work

2.45 G43Changed

Event occurs when the G43 changes its state
Value **True** G43 Enabled
 False G43 Disabled

2.46 Us2ndLimitsChanged

Event occurs when the 2nd limits are changed
Value
 True 2nd Limits Activated
 False 2nd Limits Deactivated

3 Methods and Properties of UsWork

3.1 Double AxisValueToDoubleUs (Int32 AxisIntValue)

Return a double value of an Integer Axis Value.
The return value considers the Axes Resolution

3.2 Void PutNotify(String NotifyText)

Sends a notify to Notify Manager.
Follows an event UsNotifyChanged
The notify is also put in the IsoUs_x.log file

3.3 Void EndSession()

Close all communications

3.4 Void ForceEventAxesValue()

Force the Events
AxesDemandValueChanged
AxesRealValueChanged
AxesOriginsChanged
AxesOffsetChanged

3.5 Void SetIsoUsCnC (Int32 IndexCn, String CfgName)

Init the CnC session
IndexCn Index of CNC from 0 to 7 (multiprocess)
CfgName Name of configuration file (normally "IsoUs.cfg")
Before to call **SetIsoUsCnC** the keys that indicate the location and configuration to be loaded must be registered
The CNC can't be connected to PC. This means the the IsoUs is in DEMO MODE.
Read **IsoUsModeRun**. If **False** the CNC is in DEMO MODE

3.6 Bool IsoUsModeRun

Property Read
True CNC in NORMAL MODE
False CNC in DEMO MODE

3.7 Int32[] GetIndexCnC

Property Read
Get the CnC Index setted by **SetIsoUsCnC**

3.8 Int32[] WorkPlaneSet

Property Read Write
Work plane setted
Array of Int32[2]:
Int32[0] Index of the first Axis of Work Plane
Int32[1] Index of the second Axis of Work Plane

```
Int32[] _Plane = new Int32[2];
Plane[0] = 0; //X
Plane[1] = 2; //Z
MyUsIso.WorkPlaneSet = _Plane;
```

3.9 String *GetNameConfigIsoUs*

Property Read

Return the name of configuration file

3.10 String *GetPathIsoUs*

Property Read

Return the Path of configuration file

4 Classi di UsWork

4.1 *MyMaster*

Do not use

4.2 UsAxesHomingEnable

It contains all the methods that manage the Property **HOMING** and **ENABLE** of the axes

4.2.1 bool AllAxesReady

Property Read

True All Axes Reday – Homing and Enable performed

False All Axes not ready

4.2.2 Int32[] GetAxesHomingSequence

Property Read

Returns the axes sequence homing configured

Ex:

AXES CONFIGURED X,Y,Z

Sequence configured 2,1 (0 not homing)

Return GetSeqHoming Int32 array:

Int32[0]=2

Int32[1]=1

Int32[0]=0

The first axis is Z

The second axis is Y

The third axis is X

4.2.3 Void EnableAxis(Int32 AxisIndex, bool State)

Enable/Disable Axis

AxisIndex Index of axis

State **True** Enable

False Disable

The number of axis refers to the index of axes configured (0=X – 1=Y 2=Z etc.)

At this stage you can manage the parameter **TIMEOUTENABLE**

4.2.4 Void PresetAbsoluteEncoder(Int32 AxisIndex)

Method that executes the preset ZERO for multi-turn absolute encoder type.

This method sets the current position of the CN as ZERO. The method should be used when you want to fix the ABSOLUTE ZERO for the first time.

AxisIndex Index of axis

4.2.5 Int32 ReadEncoderIndexShift(Int32 AxisIndex)

Method that reads the phase shift in the pulse encoder zero mark in relation to micro-homing.

The value is updated after searching the zero axis.

This method is valid only for boards that are connected encoder with zero mark on the CN

AxisIndex Index of axis

4.2.6 bool ResetAxesHoming(bool[] Axes)

Reset the Homing

Axes Array of bool. The position with **True** indicate, the reset bit of axis

4.2.7 Void StartHomingAxis(Int32 AxisIndex)

Run start axis homing procedure

The number of axis refers to the index of axes configured (0=X – 1=Y 2=Z etc.)

At this stage you can manage the parameter TIMEOUTHOME

AxisIndex Index of Axis

4.2.8 Void StopHomingAxis()

Stop homing sequence. The axis that is making the homing is stopped.

4.3 UsAxesManualJog

Manual movimentation Axes

4.3.1 Bool AbsoluteRelativeJog

Property Read Write

Get or Set absolute/relative movimentation

False Absolute

True Relative

4.3.2 Bool ExternalJogActivated

Property Read Write

False External Axes selector Disabled

True External Axes selector Enabled

4.3.3 Int HandWheelMultiplier

Property Read Write

Handwheel multiplier read or set x1 x10 x100 x1000

4.3.4 Int SelectAxisForJog

Property Read Write

Read or set the axis for **MoveSelectAxisJog()**

4.3.5 Void MoveAxisJog(int AxisIndex,bool Direction)

JOG Axis to direction. The axis is selected by **AxisIndex**.

AxisIndex Index of Axis

Direction **True/False** Direction

WARNING!!!

Use **StopMove()** for stop movimentation

Example c#:

```
// Button down
private void button1_MouseDown(object sender, MouseEventArgs e)
{
    IsoNs.JogAxis.Jog(0,true);
}

// Button Up
private void button1_MouseUp(object sender, MouseEventArgs e)
{
    IsoNs.JogAxis.StopMove();
}
```

4.3.6 Void MoveAxisToTarget(double Target, Int32 AxisIndex)

Method that moves the axis to the position shown in Axis Target passed as doubles.

The unit of measurement of target position is set in the configuration.

If the CNC is in RELATIVE MOTION **AbsoluteRealtiveJog = True** target position is considered as the distance traveled from the point where it is the axis.

If the CNC is in ABSOLUTE MOTION **AbsoluteRealtiveJog = False** Target position is considered by the machine zero set for the axis movement

Target Axis target position

AxisIndex Index of Axis to be moved

WARNING!!!

Use **StopMove()** for stop movimentation

4.3.7 Void MoveSelectAxisJog(bool Direction)

JOG Axis to direction. The axis is selected **SelectAxisForJog**

Direction True/False Direction

WARNING!!!

Use **StopMove()** for stop movimentation

4.3.8 Int32 ReadHandWheelMultiplier()

Return the Handwheel muliplier selected

4.3.9 Void SelectAxisHandMult(Int32 AxisIndex,Int32 HandWheelMultValue)

Select the HandWheel multiplier

AxisIndex Index of Axis

HandWheelMultValue Mulpilier value

The multiplier must have the following values

1	→	x1
10	→	x1
100	→	x100
1000	→	x1000

WARNING!!!

If you are using an electronic hand wheel with gearbox software, you should always use this method instead of the Property **SelectAxisForJog**.

4.3.10 Void SetPositionAxisShift(Int32 AxisIndex,double ShiftValue)

This method, moves the axis in Shift mode. The value **ShiftValue** is added at actual axis position (also if the axis is in moving). The entire position is reached during a time depending by parameter **TSHF_**...This value indicate the increment xTAU

AxisIndex Index of Axis

ShiftValue Value of Shift

Ex:

TAU=2 Ms

ShiftValue=100

TSHF_=10

The entire position is reached in 20 Ms

4.3.11 Void StopAllMove()

Stop all manual movements

4.4 UsAxesValue

Axes value

4.4.1 Int32 AxesResolution

Property Read
Axes value resolution setted in IsoUs.cfg

4.4.2 double CncTaskTime

Property Read
CNC sample time setting (millisecond)

4.4.3 Int32 FeedResolution

Property Read
Feed value resolution setted in IsoUs.cfg

4.4.4 double ReadDemandPosition(Int32 AxisIndex)

Reads the Demand position
AxisIndex Index of Axis

4.4.5 double ReadRealPosition(Int32 AxisIndex)

Reads the Real position
AxisIndex Index of Axis

4.4.6 double ReadRelativeDemandPosition(Int32 AxisIndex)

Reads the Relative (without offset) Demand position
AxisIndex Index of Axis

4.4.7 double ReadRelativeRealPosition(Int32 AxisIndex)

Reads the Relative (without offset) Real position
AxisIndex Index of Axis

4.5 UsBreakPoints

It contains all the methods and properties to insert breakpoints. Breakpoints allow you to terminate the program at a desired point.

Once the program execution reaches the breakpoint that stops going to PAUSE.

4.5.1 Int32[] GetAllBreakPoint()

Return Array of Int32 containing all linee number of breakpoints inserted

4.5.2 Int32 InsertBreakPoint(Int32 LineNumber)

Insert a break point

LineNumber Gcode Line Number

Return:

0 Break Point Ok

1 Break Point All ready inserted

2 Debug not activated

4.5.3 Bool IsBreakPoint(Int32 LineNumber)

Check if there is a Break point

LineNumber Gcode Line Number

Return:

True There is a BreakPoint

False There is not a BreakPoint

4.5.4 Void RemoveAllBreakPoints()

Remove all break Points

4.5.5 Void RemoveBreakPoint(Int32 LineNumber)

LineNumber Gcode Line Number

Return:

0 Break Point not inserted at line number

1 Break Point removed ok

2 Debug not activated

4.6 UsCalcTime

Manages all function for Gcode execution time calcolation

4.6.1 TimeSpan GetTotalTime

Property Read

Returns the time in second for Gcode execution

4.6.2 bool ExecuteCalcTime()

Start the cala time funtion

It is finished with event RunStop

Ritorna:

True Start Ok

False CNC not ready

GetTotalTime contains the timespan

4.7 *UsCnErrors*

It contains all the methods and properties to handle errors at the NC following an event
NotifyChanged

4.7.1 **bool GetErrors(*out String[] CnErrors*,*out String[] UsErrors*)**

Return:

False no errors

True Errors

CnErrors array string of CNC errors(null none CNC errors)

UsErrors array string of IsoUs Errors (null none IsoUs errors)

4.7.2 **void ResetCnCAlarms()**

Reste the CNC alarms

4.8 UsCnCMemory

Cnc Memory management.

4.8.1 Byte[] ReadArrayByteMemory(Int32 MemoryAddress, Int32 Length)

Reads an array of Bytes from CNC

MemoryAddress Start memory Addres on CNC

Length Number of bytes to read

Return:

Array of bytes

4.8.2 Int16[] ReadArrayInt16Memory(Int32 MemoryAddress, Int32 Length)

Reads an array of Ont16 from CNC

MemoryAddress Start memory Addres on CNC

Length Number of Int16 to read

Return:

Array of Int16

4.8.3 Int32[] ReadArrayInt32Memory(Int32 MemoryAddress, Int32 Length)

Reads an array of Int32 from CNC

MemoryAddress Start memory Addres on CNC

Length Number of Int32 to read

Return:

Array of Int32

4.8.4 void WriteArrayByteMemory(Int32 MemoryAddress, Byte[] DataValues)

Wrtite an array of Bytes in CNC memory

MemoryAddress Start memory Addres on CNC

DataValues Array of bytes to write

4.8.5 void WriteArrayInt16Memory(Int32 MemoryAddress, Int16[] DataValues)

Wrtite an array of Int16 in CNC memory

MemoryAddress Start memory Addres on CNC

DataValues Array of Int16 to write

4.8.6 void WriteArrayInt32Memory(Int32 MemoryAddress, Int32[] DataValues)

Wrtite an array of In32 in CNC memory

MemoryAddress Start memory Addres on CNC

DataValues Array of Int32 to write

4.9 UsCncMFunctions

It contains all the methods to execute the M in the CNC

4.9.1 Void Break_M_Function()

Break all M in execution on the CNC

The VTB Application must stop all M in execution

This method sets only the flag

ISOV1_STATUS_M_STOP

4.9.2 bool Execute_M_Cnc(Int32 Code_M_Function, Int32[] ParametersValue)

Run M On NC.

Code_M_Function M code

ParametersValue Int32 Array M paramters (max number for parameters is defined IsoUs.cfg – default 10)

Return:

True M Run

False M not configured

Example c#:

```
private void GoM()
{
    Int32[] Param=new Int32[3]; // 3 parameters
    // assign the parameters values
    Param[0]=10;
    Param[1]=20;
    Param[2]=30;
    // Start M100
    if(MyIsoUs.UsCncMFunctions.Execute_M_Cnc(100, Param)==false)
        // error
}
```

4.9.3 Int32 ReadCnC_M_Parameters(Int32 ParameterNumber)

Read the M parameter on NC .This feature allows a complete interaction between the NC and the functions M PC application. If a function M activated the CN values must communicate to the PC is possible via this function

ParameterNumber Parameter number on NC (0 to 10)

Return

Parameter value

4.9.4 bool WriteCnC_M_Parameters(Int32 ParameterNumber,Int32 ParameterValue)

Write a M par on NC

ParameterNumber Parameter number

ParameterValue Value

Return

True ok

False error

This method can also be used to write the variables defined by the compiler ... \$ _PARAM1

4.10 UsCnCStatusWord

Questa classe contiene tutte le Property realtive allo stato del CN.

4.10.1 bool IsAbsoluteRealtiveMotion

Property Read

Absolute/relative motion

True Relative Motion

False Absolute motion (refrence to ZERO MACHINE)

4.10.2 bool IsStatusAxesMove

Property Read

Indicates the axes status movements

True Axes Moviment

False Axes stop

4.10.3 bool[] IsStatusEnableAxes

Property Read

Axes enable status.

Return a boolean array to length axes number

The relative array index contains the status enabled axis

True Axis enabled

False Axis disabled

4.10.4 bool IsStatusError

Property Read

Status NC error

True NC in error

False NC OK

4.10.5 bool IsStatusExternalOverride

Property Read

Indicates the exetral override status

True External Override Enabled

False External Override Disabled

4.10.6 bool[] IsStatuHomingAxes

Property Read

Axes homing status

Return a boolean array to length axes number

The relative array index contains the status homing axis

True Axis homing OK

False Axis homing NOT OK

4.10.7 bool IsStatusPause

Property Read

Indicates NC Stautus PAUSE

True PAUSA NC

False PAUSA terminated

4.10.8 bool IsStatusProbe

Property Read

Indicates the acquisition state (test after StartAcq())

True Acquisition terminated

False Acquisition in RUN

4.10.9 bool IsStatusRun Property di tipo Boolean- Read Only

Property Read

Indicates the NC status RUN STOP

True NC in RUN or PAUSE (check **IsStatusPause**)

False NC in STOP

4.10.10 bool IsStatusStepMode

Property Read

Indicates the NC mode execution Gcode STEP MODE or NORMAL MODE

True STEP MODE

False NORMAL MODE

4.10.11 bool IsStatus_M_Execution

Property Read

Indicates if M to NC is in RUN

True M in RUN

False M Terminated

4.11 UsCompiler

Manages the Gcode Compilation

4.11.1 List<Compiler.MarkerCs> GetMarker

Property Read
Returns the LIST of marker defined in Gcode

4.11.2 List<Compiler.DimaArray> GetUsArray

Property Read
Returns the LIST of array defined in Gcode

4.11.3 List<string[]> GetUsDefine

Property Read
Returns the LIST of “define” defined in Gcode

4.11.4 List<string> GetUsFixedVariables

Reserved

4.11.5 List<string> GetUsVariables

Property Read
Returns the LIST of \$ Variables defined in Gcode

4.11.6 string LastFileCompiled

Property Read
Returns the path of last file compilated

4.11.7 Int32 LastTotalCodeLoaded

Property Read
Returns the number of bytes loaded last time

4.11.8 Int32 TotalLinesCompiled

Property Read
Returns the number of lines compiled

4.11.9 UsWork.IsoUs.UsErrorCompiler[] CompileGcode(string Gcode,bool CanLoadCode, out Int32 TotalLines)

Compile Gcode from Text
Gcode Text of Gcode (must be UPPERCASE)
CanLoadCode True automatic load in memory
TotalLines Returns the number of lines compiled
Return:
Array UsErrorCmpiler, or **null** if none errors

4.11.10 UsWork.IsoUs.UsErrorCompiler[] CompileGcodeFromBlock(string GcodePathFile,bool CanLoadCode, out Int32 TotalLines)

Compile Gcode from Block Execution
GcodePathFile Path Gcode
CanLoadCode True automatic load in memory
TotalLines Returns the number of lines compiled
Return:
Array UsErrorCmpiler, or **null** if none errors

4.11.11 UsWork.IsoUs.UsErrorCompiler[] CompileGcodeFromFile(string** GcodePathFile,**bool** CanLoadCode, **out Int32** TotalLines)**

Compile Gcode from file
GcodePathFile Gcode Path
CanLoadCode True automatic load in memory
TotalLines Returns the number of lines compiled

Return:

Array UsErrorCmpiler, or **null** if none errors

WARNING This Function is Deprectaed Use **CompileGcodeFromPathFile**

4.11.12 UsWork.IsoUs.UsErrorCompiler[] CompileGcodeFromPathFile(string** GcodePathFile,**bool** CanLoadCode, **out Int32** TotalLines)**

Compile Gcode from file
GcodePathFile Gcode Path
CanLoadCode True automatic load in memory
TotalLines Returns the number of lines compiled **or -1 if file not found**

Return:

Array UsErrorCmpiler, or **null** if none errors

4.11.13 **bool LoadCode()**

Load in the memory the Gcode compiled

Return:

True Ok

False Error

4.12 *UsConfig*

It contains all the methods and properties that manage the configuration of the NC.
The configuration is read from the file IsoUs.cfg.

4.13 UsGcodeRun

This class manages the execution of the ISO program

4.13.1 double Feed

Property Read Write

Reads or Set the Gcode FEED

Normally the **FEED** is setted by Gcode **F** function

4.13.2 bool SelectStepMode

Property Read Write

Get/Set the run STEP MODE Gcode

True Step Mode enabled

False Normal run

4.13.3 bool BackupCode()

BackUp the last code compiled.

This can be recovered by **RestoreGcode()**

BackUp avoids to recompile a Gcode file

Return:

True Ok

False BackUp non effettuato

4.13.4 bool ExecuteGcode(Int32 NlineStart)

Executes the Gcode loaded

NlineStart Number of Line of Start

if **NlineStart >0**, it means RESUME FROM BLOCK and the **MGOBLOCK** is performed

Return:

True Ok

False Error

4.13.5 Void ExecuteGcodeFromMarker(Int32[] AddressMarker, Double[] ValuesMarker)

Executes the Gcode when the conditions of the indicated marker.

MARKER

Markers are placed in the part of the normal variables.

IsoNs Gcode can resume when these variables have reached a certain value.

In advanced programming with the use of VARIABLES and LOOP CYCLE, the recovery from the number of lines is not sufficient, since the positions axes can be increased from the value of variables that are determinate a loop LOOP. Using markers, you can resume the Gcode by the value of one of these and not by line number, so it is possible to discriminate the resumption of cycles inside LOOP. **AddressMarker** Array di Int32 che contiene l' indirizzo fisico in memoria delle variabili MARKER recuperabile con la Property **GetMarker**, la quale ritorna un Lista di tipo Compiler.MarkerCs

AddressMarker Array of Int32 that contains the memory address of Markers get by Compiler.MarkerCs

ValuesMarker Value must have each marker so that the restart condition is satisfied

Ex:

In the following example defines a variable Marker named \$INC.

MARKER \$INC NUMBER OF LOOP

\$VAR=0

\$INC=0

```

F5
G1X0Y0
LOOP 10
    $INC=$INC+1
    G1X200
    $VAR=$VAR+50
    G0X0Y[$VAR]
END_LOOP

```

You can then enable the resumption of the Gcode when the variable \$ INC (the MARKER) assumes a certain value.

```

private void GoMarker()
{
    List<Compiler.MarkerCs> MyMarker = MyUsIso.UsCompiler.GetMarker; // Read Markers
    Int32[] AddrMarker = new Int32[MyMarker.Count];
    for (int n = 0; n < MyMarker.Count; n++) // Copy address
        AddrMarker[n] = MyMarker[n].AddrVar;
    Int32[] ValMarker = new Int32[1]; // insert the marker value ($INC)
    ValMarker[0] = 5; // recovery after 5 cycles
    MyUsIso.UsGocodeRun.ExecuteGcodeFromMarker(AddrMarker, ValMarker); // Start
}

```

4.13.6 Void ExecuteGcodeFromMarkerAndLine(Int32[] AddressMarker,Double[] ValuesMarker,Int32 LineNumber)

Equal to **ExecuteGcodeFromMarker** but the LineNumber condition must be satisfied
LineNumber Number of line

4.13.7 bool ExecuteGcodeScript(String GcodeScript, out UsWork.IsoUs.UsErrorCompiler[] Errors)

Execute Script code
A script behaves differently from a normal Gcode, as this does not handle a full movement of the axes but only G0 and G1 and can also be run at when the CN is in a state of PAUSE
GcodeScript Text of IsoUs Gcode Script
Errors UsWork.IsoUs.UsErrorCompiler[] Errors
Return:
True Ok
False Error

Example C#

```

private void Script()
{
    UsWork.IsoUs.UsErrorCompiler[] _Errors;
    if(!MyUsIso.UsGocodeRun.ExecuteGcodeScript("F5G1X100Y100,Z100\nG4F2\nX0Y0Z0", out _Errors))
    {
        if(Errors!=null)
        {
            for (int n = 0; n < Errors.Length; n++) // check errors
                Label1.Text += "E:" + Errors [n].Nline + " " + Errors [n].ErrorType;
        }
        else
            // execution Error
    }
    // Ok
}

```

4.13.8 Void PauseGcode()

Pause Gcode

Is performed **MPAUSE** configured

From a state of PAUSE you can share the exact point where it stopped working by invoking the method **ExecuteGcode(0)**.

Is performed **MGOPAUSE** configured

4.13.9 bool RestoreGcode()

Recovery the code saved with **BackUpGcode()**

This is loaded in memory ready to work

Return:

True Ok

False Restore Error

4.13.10 Void StopGcode()

Force STOP Gcode

Is performed **MSTOP** configured

4.13.11 Int32 WorkLineReal()

Read Real line in execution. Can also use event **WorkLineRealChanged**

It can be used when the CN is in STOP after an alarm to get the precise line of interruption of the Gcode.

4.14 UsGcodeVariables

This class provides access to the read and write variables ISONS Gcode.

Variables accessible are those of general type \$.

It is necessary that the Gcode has been compiled.

The following variables are always at a fixed address

Name	Address	Name	Address
\$_PARM_1	0	\$_PARM_6	5
\$_PARM_2	1	\$_PARM_7	6
\$_PARM_3	2	\$_PARM_8	7
\$_PARM_4	3	\$_PARM_9	8
\$_PARM_5	4	\$_PARM_10	9

The above variables can be read and written also before the Gcode compilation

The possibility of writing the variables of the Gcode allows you to configure the processing cycle in a parametric mode.

4.14.1 List<string> GetAllVariablesName

Property Read

Get all Variable configured

Return:

The list of string with Variables Name without \$

4.14.2 Int32 GetVariableAddress(String VariableName)

Get variable Address

VariableName Variable name without \$

Return:

>=0 Variable Address

-1 Variable not found

4.14.3 String GetVariableName(Int32 VariableAddress)

Get variable Name

VariableAddress Variable Address

Return:

Name Variable name without \$

"" Variable not found

4.14.4 double ReadVariableByAddress(Int32 VariableAddress)

Read Variable by Address

VariableAddress Variable Address

Return:

Value double

Exception variable not found

4.14.5 double ReadVariableByName(string VariableName)

Read Variable by Name

VariableName Variable name without \$

Retrun:

Value double

Exception variable not found

4.14.6 bool WriteVariableByAddress(Int32 VariableAddress,double VariableValue)

Write Variable by Address

VariableAddress Variable Address

VariableValue Value

Return:

True Ok

False Variable not found

4.14.7 bool WriteVariableByName(string VariableName,double VariableValue)

Write Variable by Name

VariableName Variable name without \$

VariableValue Value

Return:

True Ok

False Variable not found

4.15 UsInputOutput

It contains all the methods and properties to manage all the resources of the NC Input Output. The management of these resources depends on the type of CN used and the hardware configuration.

4.15.1 bool ReadDigitalInput(Int32 InputNumber)

Read Digital Input

InputNumber Digital Input from 0 to 255

Return:

True ON

False OFF

4.15.2 bool ReadDigitalOutput(Int32 OutputNumber)

Read Digital Output

OutputNumber Digital Output from 0 to 255

Return:

True ON

False OFF

4.15.3 Int32 ReadGroupDigitalInputs(Int32 Group)

Read a Group of Digital Inputs

Group Group from 0 to 7 (0 first 32 digital inputs)

Return:

32 bit Digital Inputs

Bit Set ON

Bit Reset OFF

Example c#:

```
private void TestInput()
{
    // Read first group
    Int32 Group = MyUsIso.UsInputOutput.ReadGroupDigitalInputsg(0);
    // Test input1 and 5
    if((Group & 1)==1 && (Group & 16)==16)
        // ON
}
```

4.15.4 Int32 ReadGroupDigitalOutputs(Int32 Group)

Read a Group of Digital Outputs

Group Group from 0 to 7 (0 first 32 digital outputs)

Return:

32 bit Digital Outputs

Bit Set ON

Bit Reset OFF

4.15.5 void WriteDigitalOutputs(Int32 OutputNumber,bool OutputState)

Write a Digital Outputs

OutputNumber Digital Output from 0 to 255

OutputState State **1** ON **0** OFF

4.16 *UsLogFile*

Log file management

4.16.1 `string PathUsLog`

Property Read Write

Set or Get the Path of Log file

4.17 UsMachineParameters

This class manages all parameters of CN.

All machine parameters are stored in the file and must be IsoUs.cfg

4.17.1 UsWork.UsMachineParametersCs.AxesVisType AxesValueMode

Property Read Write

Get or Set the type of read axes values:

DEMAND_POSITION Demand Position

DEVIATION_POSITION Following error

DISABLE only DEMAND_POSITION

REAL_POSITION Real Position

4.17.2 List<ComSynk.ParametriMacchina> MyParameterList

Property Read

Return the List of machine parameters

4.17.3 Int32 NumberOfParameters

Property Read

Return the number of machine parameters

4.17.4 String[] ParametersGroups

Property Read

Return the GROUP configured (ex: General,Axis X etc.)

4.17.5 String PathUsCfg

Property Read

Return the IsoUs.cfg Path

4.17.6 Void DownLoadParamaters()

Reads all the configuration parameters IsoUs.cfg and saves them in preparing an internal list to read the other of these methods.

This should be in every case the first method to be invoked before the management parameters.

4.17.7 bool GetParameterDataByIndex(Int32 ParameterIndex, out String ParameterName,out String ParameterDescr,out String ParameterGroup,out Int32 ParameterValue,out Int32 ParameterAddress)

Get a parameter from Index

ParameterIndex Index of parameter in the internal List

ParameterName Return Parameter Name

ParameterDescr Return Parameter Description

ParameterGroup Return Parameter Group

ParameterValue Return Parameter Value

ParameterAddress Return Parameter Address on CNC

Return:

True Ok

False Paramater not found or **DownLoadPara()** not performed

4.17.8 bool GetParameterDataByName (String ParameterName, out Int32 ParameterIndex,out String ParameterDescr,out String ParameterGroup,out Int32 ParameterValue,out Int32 ParameterAddress)

Get a parameter from Name
ParameterName Parameter Name (CASE Sensitive)
ParameterIndex Return Parameter Index
ParameterDescr Return Parameter Description
ParameterGroup Return Parameter Group
ParameterValue Return Parameter Value
ParameterAddress Return Parameter Address on CNC
 Return:
True Ok
False Paramater not found or **DownLoadPara()** not performed

4.17.9 bool GetParameterExtendedData(Int32 ParameterIndex, out Int32 Transform,out Int32 MinValue,out Int32 MaxValue,out Int32 PassWordLevel,out Int32 Family, out Int32 AxisIndex, out List<ComSynk.EnumCs> Enums)

Get a parameter extend data from Index
ParameterIndex Index of parameter in the internal List
Transform Return Parameter Transform
MinValue Return Parameter Minimum Value
MaxValue Return Parameter Maximum Value
PassWordLevel Return Parameter Password Level
Family Return Parameter Family
AxisIndex Return Parameter Axis Index (-1 none Axis)
Enums Return Parameter ENUMERATIVE DESCRIPTION (if present)
 Return:
True Ok
False Paramater not found or **DownLoadPara()** not performed

4.17.10 bool GetParameterValueByIndex(Int32 ParameterIndex,out Int32 ParameterValue)

Get a parameter from Index
ParameterIndex Index of parameter in the internal List
ParameterValue Return Parameter Value
 Return:
True Ok
False Paramater not found or **DownLoadPara()** not performed

4.17.11 bool GetParameterValueByName (String ParameterName,out Int32 ParameterValue)

Get a parameter from Name
ParameterName Parameter Name (CASE Sensitive)
ParameterValue Return Parameter Value
 Return:
True Ok
False Paramater not found or **DownLoadPara()** not performed

4.17.12 bool RestoreUsCfgBackUp()

Restore thyne BackUp copy
 Return:
True Restore Ok
False Error

4.17.13 Void SaveUsCfg()

Save in the **IsoUs.cfg** the parameter internal list
 Before, a copy of backup is made (use **RestoreUsCfgBackUp()**)

4.17.14 Void SendAllParameters()

Send all Parameters to CNC
 Some parameters are available only after **UpdateParameters()**

4.17.15 Void UpdateParameters()

Update the parameters
 Call it after **SendAllParameters()**

4.17.16 bool WriteParametersByIndex(Int32 ParameterIndex, Int32 ParameterValue, bool WriteInCnC)

Write a parameter by Index
ParameterIndex Index of parameter in the internal List
ParameterValue Parameter Value
WriteInCnC if **True** the Parameter is send to CNC (the **UpdateParameters()** is not called)
 Return:
True Ok
False Error

4.17.17 bool WriteParametersByName(string ParameterName, Int32 ParameterValue, bool WriteInCnC)

Write a parameter by Name
ParameterName Parameter Name
ParameterValue Parameter Value
WriteInCnC if **True** the Parameter is send to CNC (the **UpdateParameters()** is not called)
 Return:
True Ok
False Error

4.18 UsMHMfunctions

It contains all the methods that handle the compilation and Property of M and HM, which are run at a PC (not inside the CN)
These can then be retrieved by the method ExecuteMtoCn.GoMtoCn (....)

4.18.1 bool GenerateHMFunction (Int32 HMFunctionNumebr, String GCode,out UsWork.IsoUs.UsErrorCompiler[] Errors)

4.18.2 bool GenerateMFunction (Int32 MFunctionNumebr, String GCode,out UsWork.IsoUs.UsErrorCompiler[] Errors)

This method allows you to fill out a HM or M function and save it automatically in the configuration folder.

..FunctionNumber M or HM number

GCode String Code ISO

Errors Array Error compiler

Return:

True M/HM Ok

False Error

4.19 UsOffsetAndOrigins

This class manages the capabilities of the MANUAL WORK ORIGIN.
 IsoUs manipulate an array of 256 different positions for WORK ORIGIN. The positions are indexed by GCODE instruction **USER_ZERO Index Value**.
 This function is the same of GCODE G94

4.19.1 List<ComSynk.FileZeri> GetAllOriginsByFile

Property Read
 Get all origins setted in the default file
 Return:
 List of 9 string position that contains the values of origin for single Axis
The List position is the Index of Origin

4.19.2 bool HeadOffsetSuspend

Property Read Write
 Suspend or Resume the Heads Offset selected by **Hn**
False Suspend (As G87)
True Resume (As G88)

4.19.3 Int32 IndexOffset

Property Read Write
 Get or Set the Index OFFSET
 Value from 0 to 255

4.19.4 Int32 IndexOrigin

Property Read Write
 Get or Set the Index ORIGINS
 Value from 0 to 255

4.19.5 bool IsOffset

Property Read
 Read if the OFFSET is activated
False Disabled
True Enabled

4.19.6 bool IsOrigins

Property Read
 Read if the ORIGINS are activated
False Disabled
True Enabled

4.19.7 bool OffsetSuspend

Property Read Write
 Suspend or Resume the Offset selected by **G93**
False Suspend (As G96)
True Resume (As G97)

4.19.8 bool OriginsSuspend

Property Read Write
 Suspend or Resume the Origins selected by **G94**
False Suspend (As G98)
True Resume (As G99)

4.19.9 Int32[] SingleAxisIndexOrigins

Property Read Write

Get or Set the index origin fo the single Axis

Array Int32 that contains the Index Origins for Axis**4.19.10 Void ActivateOriginFile()**

Activates the Origins by file ZERI.VAL (default File)

4.19.11 Int32 AxesOffsetDisable(Int32 Index)

Disable the Offset at Index

Index Offset Index

Return:

1 Error**0** Ok**4.19.12 Int32 AxesOriginDisable(Int32 Index)**

Disable the Origin at Index

Index Origin Index

Return:

1 Error**0** Ok**4.19.13 double[] GetCurrentOffset(Int32 Index)**

Get the Current offset at Index

Index Offset Index

Return:

Array of Axes Offset position

4.19.14 double[] GetCurrentOffsetSetted()

Get the Offset at current Index

Return:

Array of Axes Offset position

4.19.15 double[] GetCurrentOrigins(Int32 Index)

Get the Current Origin at Index

Index Origin Index

Return:

Array of Axes Origin position

4.19.16 double[] GetCurrentOriginsSetted()

Get the Origin at current Index

Return:

Array of Axes Origin position

4.19.17 double[] GetOriginsFromUsFile(Int32 Index)

Get the Origins at Index from default file ZERI.VAL

Index Origin Index

Return:

Array of Axes Origin position

4.19.18 Int32 SetAxesOffsetToCurrentPosition(Int32 OffsetIndex)

Set the OFFSET at Index to current axes position

OffsetIndex Offset Index

The OFFSET is automatically enabled

Return:

1 Error

0 Ok

4.19.19 Int32 SetAxesOffsetToPosition(double[] OffsetValue, Int32 OffsetIndex)

Set the OFFSET at Index by values

OffsetValue array of Offset Values for Axis

OffsetIndex Offset Index

The OFFSET is automatically enabled

Return:

1 Error

0 Ok

4.19.20 Int32 SetAxesOriginsToCurrentPosition(Int32 OriginIndex)

Set the ORIGIN at Index to current axes position

OriginIndex Origin Index

The ORIGIN is automatically enabled

Return:

1 Error

0 Ok

4.19.21 Int32 SetAxesOriginsToPosition(double[] OriginsValue, Int32 OringinIndex)

Set the ORIGIN at Index by values

OriginsValue array of Origin Values for Axis

OriginIndex Origin Index

The ORIGIN is automatically enabled

Return:

1 Errore

0 Ok

4.19.22 Int32 SetAxisOffsetToCurrentPosition(Int32 OffsetIndex, Int32 AxisIndex)

Set the OFFSET at Index by current position for single Axis

OffsetIndex Offset Index

AxisIndex Axis Index

The OFFSET is automatically enabled

Return:

1 Error

0 Ok

4.19.23 Int32 SetAxisOffsetToPosition(double OffsetValue, Int32 OffsetIndex, Int32 AxisIndex)

Set the OFFSET at Index by value for single Axis

OffsetValue Offset Value

OffsetIndex Offset Index

AxisIndex Axis Index

The OFFSET is automatically enabled

Return:

1 Error

0 Ok

4.19.24 Int32 SetAxisOriginToCurrentPosition(Int32 OriginIndex, Int32 AxisIndex)

Set the ORIGIN at Index by current position for single Axis

OriginIndex Origin Index

AxisIndex Axis Index

The ORIGIN is automatically enabled

Return:

1 Error

0 Ok

4.19.25 Int32 SetAxisOriginToPosition(double OriginValue, Int32 OriginIndex, Int32 AxisIndex)

Set the ORIGIN at Index by value for single Axis

OriginValue Origin Value

OriginIndex Origin Index

AxisIndex Axis Index

The ORIGIN is automatically enabled

Return:

1 Error

0 Ok

0 Ok

4.19.26 bool IsoG43FromTable(Int32 Kmode, Int32 Axis, bool Direction)

Enable G43 from Tool Table

Kmode See the K parameter G43 function

Axis Axis Index

Direction Correction direction (**false** Negative – **true** Positive)

Return:

True Ok

False Error (CNC in Run or Axis not configured)

4.19.27 bool IsoG43FromLen(Double ToolLen, Int32 Kmode, Int32 Axis, bool Direction)

Enable G43 from Tool Len

ToolLen Tool Len

Kmode See the K parameter G43 function

Axis Axis Index

Direction Correction direction (**false** Negative – **true** Positive)

Return:

True Ok

False Error (CNC in Run or Axis not configured)

4.19.28 bool IsoG44(Int32 G44Ext)

Disable G43

G44Ext See command **G43.0 G43.1**

Return:

True Ok

False Error (CNC in Run or Axis not configured)

4.19.29 bool IsoG43State()

Read the G43 state

Return:

True G43 Enabled

False G43 Disabled

4.20 UsOverrideFeed

This class manages the OVERRIDE FEED

4.20.1 bool ExternalOverrideFeed

Property Read Write

Enable/Disable External Override

True Enabled

False Disabled

4.20.2 Int32 OverrideFeedAxes

Property Read Write

Get or Set the internal override value

Value from 0 to 100 %

4.21 UsPassWordManagement

IsoUs PassWord managaement

4.21.1 bool ResetUsPassWord(Int32 PassWordLevel)

Reset the current PassWord to defualt value

PassWordLevel PassWord level to Reset from 0 to 2

Defualt value:

Level 0 → 684618

Level 1 → 684619

Level 2 → 684620

Return:

True Ok

False Error

4.21.2 bool SetUsNewPassWord(String NewPassWord,Int32 PassWordLevel)

Set the new PassWord at level

NewPassWord New Password

PassWordLevel PassWord level to Set from 0 to 2

Return:

True Ok

False Error

4.21.3 bool TestUsLevelPassWordBlock(Int32 PassWordLevel)

Check the PassWord level if locked or Unlocked

PassWordLevel PassWord level to check from 0 to 2

Return:

True Unlocked

False Locked

4.21.4 bool TestUsPassWord(String PassWord,Int32 PassWordLevel)

Check the PassWord at level

PassWord PassWord to check

PassWordLevel PassWord level to Check from 0 to 2

Return:

True PassWord Ok

False PassWord Error

4.22 UsPositioners

Positioners class manager
The positioners must be enabled in VTB application

4.22.1 bool AllAxesPositionerReady

Property Read
Return the state of all positioners (Homing and Enable)
True Ready
False Not Ready

4.22.2 Int32 NumberOfPositioners

Property Read
Return the number of positioners declared in VTB application

4.22.3 bool EnablePositioner(Int32 PositionerIndex,bool EnableState)

Enable/Disable Positioner
PositionerIndex Positioner Index
EnableState **True** Enable **False** Disable
Return:
True Ok
False Positioner Error

4.22.4 bool IsAlarm(Int32 PositionerIndex,out bool Status)

Reads the Alarm status
PositionerIndex Positioner Index
Status **True** Alarm **False** Ok
Return:
True Ok
False Positioner Error

4.22.5 bool IsEnabled(Int32 PositionerIndex,out bool Status)

Reads the Enable status
PositionerIndex Positioner Index
Status **True** Enabled **False** Disabled
Return:
True Ok
False Positioner Error

4.22.6 bool IsHoming(Int32 PositionerIndex,out bool Status)

Reads the Homing status
PositionerIndex Positioner Index
Status **True** Homing Ok **False** Homing not made
Return:
True Ok
False Positioner Error

4.22.7 bool IsMoving(Int32 PositionerIndex,out bool Status)

Reads the Movement status
PositionerIndex Positioner Index
Status **True** Movement **False** Stop
Return:
True Ok
False Positioner Error

4.22.8 bool Preset(Int32 PositionerIndex, Int32 PresetValue, out bool Status)

Preset Axis value
PositionerIndex Positioner Index
PresetValue Preset Value
Status True Preset Ok False Preset Error
 Return:
True Ok
False Positioner Error

4.22.9 bool ReadDemandPosition(Int32 PositionerIndex, out Int32 PositionValue)

Reads Demand Position
PositionerIndex Positioner Index
PositionValue Demand Position value
 Return:
True Ok
False Positioner Error

4.22.10 bool ReadRealPosition(Int32 PositionerIndex, out Int32 PositionValue)

Reads Real Position
PositionerIndex Positioner Index
PositionValue Real Position value
 Return:
True Ok
False Positioner Error

4.22.11 bool SetOffsetValue(Int32 PositionerIndex, Int32 OffsetValue)

Set OFFSET position
PositionerIndex Positioner Index
OffsetValue OFFSET value
 Return:
True Ok
False Positioner Error

4.22.12 bool SetVelocity(Int32 PositionerIndex, Int32 VelocityValue)

Set FEED
PositionerIndex Positioner Index
VelocityValue FEED value
 Return:
True Ok
False Positioner Error

4.22.13 bool StartHoming(Int32 PositionerIndex)

Start homing
 Read StatusWord for check end Homing
PositionerIndex Positioner Index
 Return:
True Ok
False Positioner Error

4.22.14 bool StartPositionTarget(Int32 PositionerIndex, Int32 PositionValue, bool AbsoluteValue)

Start positioner at Target

PositionerIndex Positioner Index

PositionValue Target Value

AbsoluteValue True Target Absolute Value False Target Realtive Value

Return:

True Ok

False Positioner Error

4.22.15 bool StatusWord(Int32 PositionerIndex, Out Int32 Status)

Reads StatusWord

PositionerIndex Positioner Index

Status StatusWord bit mapped (bit 1 setted):

Bit 0 → Enable

Bit 1 → Homing

Bit 2 → Move

Bit 3 → Allarm

Return:

True Ok

False Positioner Error

4.22.16 bool Stop(Int32 PositionerIndex)

Stop the Positioner

PositionerIndex Positioner Index

Return:

True Ok

False Positioner Error

4.23 UsRetrace

This class handles all the logic functionality of IsoNs Retrace.

The retrace and a mode useful for some types of machines. In practice, it scrolls the tool path on the piece with a kind of simulation, but with axes in motion. The path of the sliding mode occurs in both forward and reverse JOG. This allows you to choose how to RESTART POINT OF VIEW of any section even though this is not a starting point or end of an element. you can make a fresh start from any point of an arc or a straight line. With axes in motion, can have a real vision on the machine POINT OF RESTART.

Is performed **MGORETRACE** configured

Before using the functions of retrace, you must call the method InitRetrace()

4.23.1 Int32 GetLineRetrace

Property Read

Return the Gcode Line currently in execution in retrace mode.

4.23.2 Void ExecuteProg()

Start the Gcode from the current point where the axes are on the profile.

This method is invoked when the operator decided the point of restart of the profile.

Is performed **MGORETRACE** configured

4.23.3 bool GetPosAxisAtLine(out Int32 PosX, out Int32 Posy, Int32 Nline)

Reads the axes position at line number

PosX Axis X Position

PosY Axis Y Position

NLine Gcode Line number

Return:

True Ok

False Line not found

4.23.4 Void GoLine(Int32 Nline)

Move axes to block the line indicated.

Need to skip parts of the tool path.

Nline Gcode Line number to jump

4.23.5 Void InitRetrace()

Enable the feature RETRACE. This method must be called before using any of the Property and the other class methods retraced.

In practice prepares a list of all the Gcode simulation.

4.23.6 Void JogDown()

Move axis in the negative direction on the path PIECE.

The jog speed is set in the Gcode

For STOP Axes use **StopJog ()**

4.23.7 Void JogUp()

Move axis in the positive direction on the path PIECE.

The jog speed is set in the Gcode

For STOP Axes use **StopJog ()**

4.23.8 Void StopJog()

Stop Axes **JogUp()** or **JogDown()**

4.24 *UsSimulation*

Simulation Gcode

4.24.1 *Void ExecuteSimulation()*

The current Gcode loaded, will be simulated in the preview window

4.25 UsSpindleManager

This Class allows to manage all functions for Analog 0-10V Spindle Output.

The Spindle Output is configured in IsoUs by Machine Parameters Spindle Table
(See [IsoUs Documentation](#))

4.25.1 Void WriteSpindleSpeed(Int32 _Val)

Write the value `_Val` in the Analog Output configured for Spindle

`_Val` is in **BIT**, therefore for an output of **10V** on the Channels **0-15** the value must be **2047**,
for the Channel **NGMEVO PWM 255** (max)

4.25.2 Int32 ReadSpindleSpeed()

Read the last value write with `WriteSpindleSpeed()`

Return 0-2047 for the channels 0-15

0-255 for the channel NGMEVO PWM

4.25.3 Void WriteSpindleOw(Int32 _Val)

Write the Override value for the Analog Output configured for Spindle

The value is between **0** (0%) and **1024** (100%).

WARNING

For this function, must be enabled the parameter **ENABLE_OW_SPEED** on **INTERNAL VIRTUAL**

The Minimum and Maximum value is restrained by parameter:

SPEED_OW_MIN Minimum Value of Override

SPEED_OW_MAX Maximum Value of Override

4.25.4 Int32 ReadSpindleOw()

Read the Overide value set

Return 0-1024

4.25.5 Int32 SpindleOwState

Property Read

Return the mode set of Spindle Override

0 Disable

1 Managed by VTB

2 Managed by `WriteSpindleOw()`

4.25.6 Int32 SpindleAnalogBitRes

Property Read

Return the BIT resolution set for the Spindle Analog Output

2048 Channels 0-15

255 (max) Channel NGMEVO PWM

4.26 UsStaticVariables

This class handles files of variables saved in permanent memory. IsoNs allows you to save the contents of variables in a file so that it can be reloaded later. These files are also manageable Gcode. Le PERMANENT are all variables of type DOUBLE, and are included in a list. `Ilist<Double>`.

The file are saved in internal path of

4.26.1 String GetPathStaticFile

Property Read

Return the path of permanents variables.

4.26.2 List<double> GetStaticVariables

Property Read

Get the values of static variables.

Necessary use `LoadStaticFile` before

4.26.3 bool LoadStaticFile(String StaticFileName)

Load in memory the static file

StaticFileName File name (Use `GetPathStaticFile` for get the Path)

Return:

True Ok

False File not found

4.26.4 Void SaveFile(String StaticFileName)

Save in the file the current LIST get from `GetStaticVariables`.

StaticFileName File Name (only name)

4.27 UsToolInfo

Tool informations

4.27.1 Int32 GetIndexAxisLengthEnabled

Property Read

Get the Index Axis where is enabled the Length correction

-1 No Axis

4.27.2 double GetToolDiameterSet

Property Read

Get the current Tool Diameter setted

4.27.3 bool GetToolDirection

Property Read

Get the Tool Length correction direction

True Positive

False Negative

4.27.4 double GetToolLengthSet

Property Read

Get the Length correction value

4.27.5 bool IsToolLengthActivated

Property Read

Get if enabled Tool Length correction

True Enabled

False Disabled

4.28 UsToolsHeadsTable

It contains all the methods and properties related to the management of the tool **HEADS** and the parameters of the **TOOLS** table.

4.28.1 Int32 GetNumberOfHeads

Property Read
Get the number of Heads configured

4.28.2 Int32 GetNumberOfToolsTable

Property Read
Get the number of Tools configured

4.28.3 Int32 SelectHHead

Property Read Write
Get or Set an **HEAD**.
The value of SET must be between 0 and the maximum number of HEAD included in the configuration. An exception is generated if the value is not within this range.
Returns -1 if no **HEAD** is selected
This function is equal to **Hn** in Gcode

4.28.4 Int32 SelectToolTable

Property Read Write
Get or Set a **TOOL TABLE**.
The value of SET must be between 0 and the maximum number of TABLES included in the configuration tool. An exception is generated if the value is not within this range.
Returns -1 if no TABLE is selected
This function is equal to **Tn** in Gcode

4.28.5 double GetHeadParameter(Int32 ParameterIndex)

Reads the parameter specified in **ParameterIndex** from the **HEAD** table selected.
ParameterIndex Index of parameter to selected head
Return:
Parameter Value

4.28.6 double GetToolParamater(Int32 ParameterIndex)

Reads the parameter specified in **ParameterIndex** from the **TOOL** table selected.
ParameterIndex Index of parameter to selected Tool
Return:
Parameter Value

4.28.7 Void SaveToolTableParameters()

Save the parameters of the tool table in memory (written with **WriteParTab**) in the configuration on disk permanently

4.28.8 Void WriteHeadParameter(double Value,Int32 HeadIndex, Int32 ParameterIndex)

Write a parameter to Head
Value Parameter value
HeadIndex Head Index
ParameterIndex Parameter index

4.28.9 Void WriteToolParameter(double Value,Int32 TableIndex, Int32 ParameterIndex)

Write a parameter to Tool
Value Parameter value
TableIndex Tool Index
ParameterIndex Parameter index

4.29 *UsGenericVariables*

This class handles variables UserGenric for data exchange with the NC.

These variables are of type Int32, and can be used to read / write values of using them for general data exchange between PC applicazione CN VTB.

The number of variables is 30

4.29.1 **Int32 ReadUserCnCVariable(Int32 UserAddress)**

Reads a User Generic Variable from CNC

UserAddress User Address from 0 to 29

Return:

User Value

4.29.2 **Void WriteUserCnCVariable(Int32 UserAddress,Int32 UserValue)**

Writes a User Generic Variable in the CNC

UserAddress User Address from 0 to 29

UserValue User Value

4.30 Us2ndLimitsManager

Racchiude tutti i metodi e proprietà che gestiscono i secondi limiti assi

4.30.1 bool Is2ndLimits

Property Read

Return:

True 2nd Limits activated

False Primary Limits activated

4.30.2 bool Activated2ndLimits()

Activate the **2nd** Software Limits

Return:

True – Ok

False – CnC in Run

4.30.3 bool Reset2ndLimits()

Deactivates the **2nd** Limits and activates the **PRIMARY** software Limits


Ritorna:

True – Ok

False – CnC in Run

4.31 UsProbe

This class manages the capabilities of Acquisitions sensor boards. Acquisitions by The sensor requires that the axes are moved to a position up and be detected by this sensor.
The axes can be moved at one time, however, can move only one axis in the direction of the probe Acquisition .



4.31.1 Double[] GetAxesValue

Property Read
Read acquisition positions axes
After acquisition executed you can use this property for read all positions axes
Return:
Double[] Array axes positions at sensor

4.31.2 bool StartProbeAcquisition(double[] AxesValue)

Start Acquisition at position
When the sensor detected the piece, the **AcquisitionExecuteChanged** event is performed.
Otherwise **NotifyChanged** event is performed if axes reach the position target.
Is possible test StatusCn **IsStatusProbe**.
AxesValue Array for Target positions.
Return:
True Acquisition Started
False Error Axes position array

WARNING

Before run **StartProbeAcquisition** you must set the RUN NC by following instructions

MyMaster.GetCommand.RunProg();

At end (normal end or error) **StartProbeAcquisition** you must set the STOP NC by following instructions

MyMaster.GetCommand.StopProg();

Index

1	PREFAZIONE	3
1.1	Before Start.....	3
2	Events.....	4
2.1	AbsRelChanged.....	4
2.2	AcquisitionExecuteChanged	4
2.3	AllAxesReadyChanged	4
2.4	AxesDemandValueChanged.....	4
2.5	AxesMoveChanged	5
2.6	AxesOffsetValueChanged	5
2.7	AxesOriginChanged	5
2.8	AxesDemandValueChanged.....	6
2.9	AxisEnabledChanged	6
2.10	AxisHomeChanged.....	6
2.11	DigitalInputChanged	6
2.12	EnableExtOverrideChanged	7
2.13	EndImportChanged.....	7
2.14	ExtPauseRequestChanged	8
2.15	ExtRunRequestChanged	8
2.16	ExtStopRequestChanged	8
2.17	FeedAxesChanged	8
2.18	RealFeedAxesChanged.....	8
2.19	HeadOffsetValueChanged.....	9
2.20	MachineParametersUpdate	9
2.21	MulHandWheelChanged	9
2.22	M_CnC_ExecuteChanged	9
2.23	OnCloseComRequest.....	9
2.24	OverrideValueChanged.....	9
2.25	PauseChanged.....	10
2.26	RemoveMarkLineChanged.....	10
2.27	RequestMarkLineChanged	10
2.28	RunStopChanged	10
2.29	RunStopChangedWithType	10
2.30	ScriptChanged.....	11
2.31	SelectAxisJogChanged	11
2.32	SpeedSpindleChanged	11

2.33	StartImportChanged	11
2.34	StepModeChanged	12
2.35	TabUtChanged	12
2.36	ToolDiameterChanged	12
2.37	ToolLengthChanged	12
2.38	UsFatalError	12
2.39	UsNotifyChanged	13
2.40	VariableUserChanged	14
2.41	WorkLineDemandChanged	14
2.42	WorkLineRealChanged	14
2.43	WorkPlaneSetChanged	14
2.44	UsCompiler.CodeLoaded	15
2.45	G43Changed	15
2.46	Us2ndLimitsChanged	15
3	Methods and Properties of UsWork	16
3.1	Double AxisValueToDoubleUs (Int32 AxisIntValue)	16
3.2	Void PutNotify(String NotifyText)	16
3.3	Void EndSession()	16
3.4	Void ForceEventAxesValue()	16
3.5	Void SetIsoUsCnC (Int32 IndexCn, String CfgName)	16
3.6	Bool IsoUsModeRun	16
3.7	Int32[] GetIndexCnC	16
3.8	Int32[] WorkPlaneSet	16
3.9	String GetNameConfigIsoUs	17
3.10	String GetPathIsoUs	17
4	Classi di UsWork	18
4.1	MyMaster	18
4.2	UsAxesHomingEnable	19
4.2.1	<i>bool</i> AllAxesRedy	19
4.2.2	Int32[] GetAxesHomingSequence	19
4.2.3	Void EnableAxis(Int32 AxisIndex, <i>bool</i> State)	19
4.2.4	Void PresetAbsoluteEncoder(Int32 AxisIndex)	19
4.2.5	Int32 ReadEncoderIndexShift(Int32 AxisIndex)	19
4.2.6	<i>bool</i> ResetAxesHoming(<i>bool</i> [] Axes)	19
4.2.7	Void StartHomingAxis(Int32 AxisIndex)	20
4.2.8	Void StopHomingAxis()	20
4.3	UsAxesManualJog	21

4.3.1	Bool AbsoluteRelativeJog.....	21
4.3.2	Bool ExternalJogActivated	21
4.3.3	Int HandWheelMultiplier.....	21
4.3.4	Int SelectAxisForJog.....	21
4.3.5	Void MoveAxisJog(int AxisIndex,bool Direction)	21
4.3.6	Void MoveAxisToTarget(double Target, Int32 AxisIndex).....	22
4.3.7	Void MoveSelectAxisJog(bool Direction)	22
4.3.8	Int32 ReadHandWheelMultiplier()	22
4.3.9	Void SelectAxisHandMult(Int32 AxisIndex,Int32 HandWheelMultValue)	22
4.3.10	Void SetPositionAxisShift(Int32 AxisIndex,double ShiftValue)	22
4.3.11	Void StopAllMove().....	22
4.4	UsAxesValue	23
4.4.1	Int32 AxesResolution.....	23
4.4.2	double CncTaskTime.....	23
4.4.3	Int32 FeedResolution	23
4.4.4	double ReadDemandPosition(Int32 AxisIndex)	23
4.4.5	double ReadRealPosition(Int32 AxisIndex).....	23
4.4.6	double ReadRelativeDemandPosition(Int32 AxisIndex)	23
4.4.7	double ReadRelativeRealPosition(Int32 AxisIndex)	23
4.5	UsBreaKPoints	24
4.5.1	Int32[] GetAllBreakPoint()	24
4.5.2	Int32 InsertBreakPoint(Int32 LineNumber).....	24
4.5.3	Bool IsBreakPoint(Int32 LineNumber)	24
4.5.4	Void RemoveAllBreakPoints()	24
4.5.5	Void RemoveBreakPoint(Int32 LineNumber)	24
4.6	UsCalcTime	25
4.6.1	TimeSpan GetTotalTime.....	25
4.6.2	bool ExecuteCalcTime()	25
4.7	UsCnErrors	26
4.7.1	bool GetErrors(out String[] CnErrors,out String[] UsErrors)	26
4.7.2	void ResetCnCAlarms()	26
4.8	UsCnCMemory	27
4.8.1	Byte[] ReadArrayByteMemory(Int32 MemoryAddress,Int32 Length)	27
4.8.2	Int16[] ReadArrayInt16Memory(Int32 MemoryAddress,Int32 Length)	27
4.8.3	Int32[] ReadArrayInt32Memory(Int32 MemoryAddress,Int32 Length)	27
4.8.4	void WriteArrayByteMemory(Int32 MemoryAddress, Byte[] DataValues).....	27
4.8.5	void WriteArrayInt16Memory(Int32 MemoryAddress, Int16[] DataValues).....	27

4.8.6	void WriteArrayInt32Memory(Int32 MemoryAddress, Int32[] DataValues).....	27
4.9	UsCncMFunctions.....	28
4.9.1	Void Break_M_Function()	28
4.9.2	bool Execute_M_Cnc(Int32 Code_M_Function, Int32[] ParametersValue)	28
4.9.3	Int32 ReadCnC_M_Parameters(Int32 ParameterNumber)	28
4.9.4	bool WriteCnC_M_Parameters(Int32 ParameterNumber,Int32 ParameterValue).....	28
4.10	UsCnCStatusWord.....	29
4.10.1	bool IsAbsoluteRealtiveMotion	29
4.10.2	bool IsStatusAxesMove	29
4.10.3	bool[] IsStatusEnableAxes	29
4.10.4	bool IsStatusError	29
4.10.5	bool IsStatusExternalOverride	29
4.10.6	bool[] IsStatuHomingAxes	29
4.10.7	bool IsStatusPause.....	29
4.10.8	bool IsStatusProbe.....	29
4.10.9	bool IsStatusRun Property di tipo Boolean- Read Only	30
4.10.10	bool IsStatusStepMode.....	30
4.10.11	bool IsStatus_M_Execution	30
4.11	UsCompiler	31
4.11.1	List<Compiler.MarkerCs> GetMarker	31
4.11.2	List<Compiler.DimaArray> GetUsArray	31
4.11.3	List<string[]> GetUsDefine	31
4.11.4	List<string> GetUsFixedVariables.....	31
4.11.5	List<string> GetUsVariables.....	31
4.11.6	string LastFileCompiled.....	31
4.11.7	Int32 LastTotalCodeLoaded.....	31
4.11.8	Int32 TotalLinesCompiled	31
4.11.9	UsWork.IsoUs.UsErrorCompiler[] CompileGcode(string Gcode,bool CanLoadCode, out Int32 TotalLines).....	31
4.11.10	UsWork.IsoUs.UsErrorCompiler[] CompileGcodeFromBlock(string GcodePathFile,bool CanLoadCode, out Int32 TotalLines).....	31
4.11.11	UsWork.IsoUs.UsErrorCompiler[] CompileGcodeFromFile(string GcodePathFile,bool CanLoadCode, out Int32 TotalLines).....	32
4.11.12	UsWork.IsoUs.UsErrorCompiler[] CompileGcodeFromPathFile(string GcodePathFile,bool CanLoadCode, out Int32 TotalLines).....	32
4.11.13	bool LoadCode()	32
4.12	UsConfig.....	33
4.13	UsGcodeRun	34

4.13.1	double Feed	34
4.13.2	bool SelectStepMode	34
4.13.3	bool BackupCode()	34
4.13.4	bool ExecuteGcode(Int32 NlineStart).....	34
4.13.5	Void ExecuteGcodeFromMarker(Int32[] AddressMarker,Double[] ValuesMarker) ..	34
4.13.6	Void ExecuteGcodeFromMarkerAndLine(Int32[] AddressMarker,Double[] ValuesMarker,Int32 LineNumber)	35
4.13.7	bool ExecuteGcodeScript(String GcodeScript, out UsWork.IsoUs.UsErrorCompiler[] Errors)	35
4.13.8	Void PauseGcode().....	36
4.13.9	bool RestoreGcode()	36
4.13.10	Void StopGcode()	36
4.13.11	Int32 WorkLineReal()	36
4.14	UsGcodeVariables.....	37
4.14.1	List<string> GetAllVariablesName	37
4.14.2	Int32 GetVariableAddress(String VariableName).....	37
4.14.3	String GetVariableName(Int32 VariableAddress).....	37
4.14.4	double ReadVariableByAddress(Int32 VariableAddress)	37
4.14.5	double ReadVariableByName(string VariableName)	37
4.14.6	bool WriteVariableByAddress(Int32 VariableAddress,double VariableValue).....	38
4.14.7	bool WriteVariableByName(string VariableName,double VariableValue)	38
4.15	UsInputOutput	39
4.15.1	bool ReadDigitalInput(Int32 InputNumber)	39
4.15.2	bool ReadDigitalOutput(Int32 OutputNumber)	39
4.15.3	Int32 ReadGroupDigitalInputs(Int32 Group)	39
4.15.4	Int32 ReadGroupDigitalOutputs(Int32 Group).....	39
4.15.5	void WriteDigitalOutputs(Int32 OutputNumber,bool OutputState)	39
4.16	UsLogFile	40
4.16.1	string PathUsLog.....	40
4.17	UsMachineParameters	41
4.17.1	UsWork.UsMachineParametersCs.AxesVisType AxesValueMode.....	41
4.17.2	List<ComSynk.ParametriMacchina> MyParameterList	41
4.17.3	Int32 NumberOfParameters	41
4.17.4	String[] ParametersGroups.....	41
4.17.5	String PathUsCfg	41
4.17.6	Void DownLoadParamaters()	41
4.17.7	bool GetParameterDataByIndex(Int32 ParameterIndex, out String	

ParameterName,out String ParameterDescr,out String ParameterGroup,out Int32 ParameterValue,out Int32 ParameterAddress)	41
4.17.8 bool GetParameterDataByName (String ParameterName, out Int32 ParameterIndex,out String ParameterDescr,out String ParameterGroup,out Int32 ParameterValue,out Int32 ParameterAddress)	42
4.17.9 bool GetParameterExtendedData(Int32 ParameterIndex, out Int32 Transform,out Int32 MinValue,out Int32 MaxValue,out Int32 PassWordLevel,out Int32 Familiy, out Int32 AxisIndex, out List<ComSynk.EnumCs> Enums)	42
4.17.10 bool GetParameterValueByIndex(Int32 ParameterIndex,out Int32 ParameterValue) 42	
4.17.11 bool GetParameterValueByName (String ParameterName,out Int32 ParameterValue)	42
4.17.12 bool RestoreUsCfgBackUp()	43
4.17.13 Void SaveUsCfg().....	43
4.17.14 Void SendAllParameters()	43
4.17.15 Void UpdateParameters().....	43
4.17.16 bool WriteParametersByIndex(Int32 ParameterIndex, Int32 ParameterValue, bool WriteInCnC).....	43
4.17.17 bool WriteParametersByName(string ParameterName, Int32 ParameterValue, bool WriteInCnC).....	43
4.18 UsMHMfunctions	44
4.18.1 bool GenerateHMFuction (Int32 HMFunctionNumebr, String GCode,out UsWork.IsoUs.UsErrorCompiler[] Errors)	44
4.18.2 bool GenerateMFunction (Int32 MFunctionNumebr, String GCode,out UsWork.IsoUs.UsErrorCompiler[] Errors)	44
4.19 UsOffsetAndOrigins	45
4.19.1 List<ComSynk.FileZeri> GetAllOriginsByFile	45
4.19.2 bool HeadOffsetSuspend.....	45
4.19.3 Int32 IndexOffset	45
4.19.4 Int32 IndexOrigin.....	45
4.19.5 bool IsOffset.....	45
4.19.6 bool IsOrigins.....	45
4.19.7 bool OffsetSuspend	45
4.19.8 bool OriginsSuspend	45
4.19.9 Int32[] SingleAxisIndexOrigins.....	46
4.19.10 Void ActivateOriginFile()	46
4.19.11 Int32 AxesOffsetDisable(Int32 Index)	46
4.19.12 Int32 AxesOriginDisable(Int32 Index).....	46
4.19.13 double[] GetCurrentOffset(Int32 Index)	46

4.19.14	double[] GetCurrentOffsetSetted()	46
4.19.15	double[] GetCurrentOrigins(Int32 Index)	46
4.19.16	double[] GetCurrentOriginsSetted()	46
4.19.17	double[] GetOriginsFromUsFile(Int32 Index)	46
4.19.18	Int32 SetAxesOffsetToCurrentPosition(Int32 OffsetIndex)	47
4.19.19	Int32 SetAxesOffsetToPosition(double[] OffsetValue, Int32 OffsetIndex)	47
4.19.20	Int32 SetAxesOriginsToCurrentPosition(Int32 OriginIndex)	47
4.19.21	Int32 SetAxesOriginsToPosition(double[] Origins Value, Int32 OringinIndex)	47
4.19.22	Int32 SetAxisOffsetToCurrentPosition(Int32 OffsetIndex, Int32 AxisIndex)	47
4.19.23	Int32 SetAxisOffsetToPosition(double OffsetValue, Int32 OffsetIndex, Int32 AxisIndex)	47
4.19.24	Int32 SetAxisOriginToCurrentPosition(Int32 OriginIndex, Int32 AxisIndex)	48
4.19.25	Int32 SetAxisOriginToPosition(double OriginValue, Int32 OriginIndex, Int32 AxisIndex)	48
4.19.26	bool IsoG43FromTable(Int32 Kmode, Int32 Axis, bool Direction)	48
4.19.27	bool IsoG43FromLen(Double ToolLen, Int32 Kmode, Int32 Axis, bool Direction)	48
4.19.28	bool IsoG44(Int32 G44Ext)	48
4.19.29	bool IsoG43State()	48
4.20	UsOverrideFeed	49
4.20.1	bool ExternalOverrideFeed	49
4.20.2	Int32 OverrideFeedAxes	49
4.21	UsPassWordManagement	50
4.21.1	bool ResetUsPassWord(Int32 PassWordLevel)	50
4.21.2	bool SetUsNewPassWord(String NewPassWord, Int32 PassWordLevel)	50
4.21.3	bool TestUsLevelPassWordBlock(Int32 PassWordLevel)	50
4.21.4	bool TestUsPassWord(String PassWord, Int32 PassWordLevel)	50
4.22	UsPositioners	51
4.22.1	bool AllAxesPositionerReady	51
4.22.2	Int32 NumberOfPositioners	51
4.22.3	bool EnablePositioner(Int32 PositionerIndex, bool EnableState)	51
4.22.4	bool IsAlarm(Int32 PositionerIndex, out bool Status)	51
4.22.5	bool IsEnabled(Int32 PositionerIndex, out bool Status)	51
4.22.6	bool IsHoming(Int32 PositionerIndex, out bool Status)	51
4.22.7	bool IsMoving(Int32 PositionerIndex, out bool Status)	51
4.22.8	bool Preset(Int32 PositionerIndex, Int32 PresetValue, out bool Status)	52
4.22.9	bool ReadDemandPosition(Int32 PositionerIndex, out Int32 PositionValue)	52
4.22.10	bool ReadRealPosition(Int32 PositionerIndex, out Int32 PositionValue)	52

4.22.11	bool SetOffsetValue(Int32 PositionerIndex, Int32 OffsetValue)	52
4.22.12	bool SetVelocity(Int32 PositionerIndex, Int32 VelocityValue)	52
4.22.13	bool StartHoming(Int32 PositionerIndex).....	52
4.22.14	bool StartPositionTarget(Int32 PositionerIndex, Int32 PositionValue, bool AbsoluteValue).....	53
4.22.15	bool StatusWord(Int32 PositionerIndex, Out Int32 Status).....	53
4.22.16	bool Stop(Int32 PositionerIndex)	53
4.23	UsRetrace.....	54
4.23.1	Int32 GetLineRetrace	54
4.23.2	Void ExecuteProg()	54
4.23.3	bool GetPosAxisAtLine(out Int32 PosX, out Int32 Posy, Int32 Nline).....	54
4.23.4	Void GoLine(Int32 Nline)	54
4.23.5	Void InitRetrace().....	54
4.23.6	Void JogDown()	54
4.23.7	Void JogUp()	54
4.23.8	Void StopJog().....	54
4.24	UsSimulation	55
4.24.1	Void ExecuteSimulation()	55
4.25	UsSpindleManager	56
4.25.1	Void WriteSpindleSpeed(Int32 _Val).....	56
4.25.2	Int32 ReadSpindleSpeed()	56
4.25.3	Void WriteSpindleOw(Int32 _Val).....	56
4.25.4	Int32 ReadSpindleOw()	56
4.25.5	Int32 SpindleOwState	56
4.25.6	Int32 SpindleAnalogBitRes	56
4.26	UsStaticVariables	57
4.26.1	String GetPathStaticFile.....	57
4.26.2	List<double> GetStaticVariables	57
4.26.3	bool LoadStaticFile(String StaticFileName).....	57
4.26.4	Void SaveFile(String StaticFileName)	57
4.27	UsToolInfo	58
4.27.1	Int32 GetIndexAxisLengthEnabled	58
4.27.2	double GetToolDiameterSet.....	58
4.27.3	bool GetToolDirection	58
4.27.4	double GetToolLengthSet	58
4.27.5	bool IsToolLengthActivated	58
4.28	UsToolsHeadsTable	59

4.28.1	Int32 GetNumberOfHeads	59
4.28.2	Int32 GetNumberOfToolsTable	59
4.28.3	Int32 SelectHEad	59
4.28.4	Int32 SelectTollTable	59
4.28.5	double GetHeadParameter(Int32 ParameterIndex)	59
4.28.6	double GetToolParamater(Int32 ParameterIndex)	59
4.28.7	Void SaveToolTabelParameters()	59
4.28.8	Void WriteHeadParameter(double Value,Int32 HeadIndex, Int32 ParameterIndex) ...	59
4.28.9	Void WriteToolParameter(double Value,Int32 TableIndex, Int32 ParameterIndex)	59
4.29	UsGenericVariables	60
4.29.1	Int32 ReadUserCnCVariable(Int32 UserAddress)	60
4.29.2	Void WriteUserCnCVariable(Int32 UserAddress,Int32 UserValue)	60
4.30	Us2ndLimitsManager	61
4.30.1	bool Is2ndLimits	61
4.30.2	bool Activated2ndLimits()	61
4.30.3	bool Reset2ndLimits().....	61
4.31	UsProbe.....	62
4.31.1	Double[] GetAxesValue	62
4.31.2	bool StartProbeAcquisition(double[] AxesValue).....	62