

ESTUN-Trio Products & Solution's Technical

iranieg
02165612812

ESTUN Servo Systems
TRIO Motion Controller
PROMAX Srl CNC Controller
A MEMBER OF THE **ESTUN** GROUP

TRIO
MOTION TECHNOLOGY

ESTUN
AUTOMATION



THE MOTION SPECIALIST

Motion Perfect Editor

Motion Perfect Editor V5


Design, Develop, Test, Deploy and Secure

Motion Perfect provides the user with an easy-to-understand interface for rapid application development, including configuration and setup of drives, controllers and HMI.

A fully featured IDE for program development and debugging in all Motion-iX languages, multi-page HMI screen development and diagnostic tools for machine commission. *Motion Perfect* allows complete machine setup from a single software package.



Ethernet connection



Ethernet connection



**Fixed IP Address
192.168.0.250**


SWITCH




**Needs Fixed IP Address
e.g. 192.168.0.97**



Set a Fixed IP Address



Motion Coordinator address



Operation Modes

Disconnected

Not connected to a controller. **All tools are closed**, and no communications ports are open.

Direct Mode

A direct connection is made to a controller **allowing a Terminal tool** to be used for direct interaction with the command line on the controller.

Tool Mode

A multichannel connection is made to a controller allowing the monitoring tools within *Motion* Perfect to be used. This mode allows the user **to see a list of the programs** on the controller (so that they can be **started and stopped**) but does **not allow editing** of any of the programs.

Sync Mode

A multichannel connection is made to a controller and a local project on the PC is opened. The contents of the controller and the project are synchronized so that the local copy of all programs matches those on the controller. All of *Motion* Perfect's **tools are available** and programs **can be edited**. The **synchronization process** can involve deleting programs or copying them from the controller to the PC of vice versa.

BASIC Program

STARTUP X

```
0 'Start Ethernet port section
1 IP_ADDRESS = 192.168.0.250
2
3 WA(5000) ' 5 sec delay-warm up
4 ETHERCAT(0,0) 'ethercat running command
5
6 'RUN "CLEAR_UNIT_ERROR" 'calling sub routine
7
8 WA(500) ' 0.5 sec
9
10 '(1) - ADDRESS
11 IF CO_READ(0,1,$6860,0,2) <> 8 THEN
12   CO_WRITE(0,1,$6860,0,2,-1,8)
13 ENDIF
14
15 WA(500) ' 0.5 sec
16
```

Full function program Editor

Auto-indent help to highlight program flow

RUN, Step, Breakpoint operations for debug

Tailored color template

Motion Perfect v5.2 Options

(Type text to search for)

General

Editing

- ☒ Long variable name warnings
- ☒ Auto-suggest
- ☒ Enable Snippets
- ☒ Parameter assist
- ☒ Text matching

Layout

- ☒ Show sidebar
- ☒ Show line numbers
- ☒ Enable code collapsing
- ☐ Collapse All By Default

Fold on

- ☒ IF
- ☒ SELECT-CASE
- ☒ FOR
- ☒ Functions & Subs
- ☒ WHILE
- ☒ START
- ☒ REPEAT
- ☒ Comment


Preview

```
0 ' Sample code in TrioBASIC
1 PRINT "Hello World!"
2
3 PRINT "Break point!"
4
5 WDOG=1 ' Controller variable
6
7 a = 5
8
9 _loop: ' Label
10
11 FOR i=0 TO 10
12   VP_SPEED=i*100
13   a = a + PLC_AR * Constant
14 NEXT
15
16 ' Modified line
17 VR(2)=0: VR(3)=0: VR(4)=0
18
19 GOTO _loop
20
21 PRINT "Error" ' Compiler error
22
23 Compile error
24
25 long_variable_names_are_underlined_wit
26
```

Reset to Defaults Undo Changes OK Apply Cancel



Backup manager



Automatic and Manual
project backup

The screenshot shows the 'Controller Directory - Ethernet, 192.168.0.245' window. It contains a table with the following data:



Program	Code Type	Storage	Source	Code	Run Type	Edit
CAMLIB	CAM library	Internal	667		Manual	[Edit]
LIB1	BASIC Lib	Internal	91	36	Manual	[Edit]
MC_CONFIG	MC Config file	Internal	15	12	Manual	[Edit]
MAIN	BASIC	Internal	60	39	Auto(1)	[Edit]
STARTUP	BASIC	Internal	789	640	Manual	[Edit]
HOME	BASIC	Internal	1009	490	Manual	[Edit]
MOTION1	BASIC	Internal	4404	1545	Manual	[Edit]
MOTION2	BASIC	Internal	462	469	Manual	[Edit]
VAR_DEFS	BASIC	Internal	68	13	Manual	[Edit]

The Source code is stored in Flash memory

A copy is automatically saved to the PC project folder



Project Synchronization



Local Variables


Simple case, just name the variables as you use them

X = 123 `create a variable called x and give it value
Offset = 12 `create another variable
Y = 30 * x + Offset

Or define your variable name and type before use

DIM flow_rate AS INTEGER
DIM calibration_factor AS FLOAT

Flow_rate = 24
Calibration_factor = 5.614 * PI



Each program keeps its own list of variables


Local variables are not known to other programs
1024 local variables for each program

Global VR memory


- Motion PLC & MC403,MC404,MC405
VR(0) to VR(4095)
Except MCS50
VR(0) to VR(8191)
- Motion control & MC508, MC6N, Flex-X
VR(0) to VR(16383)
- Motion control (high performance) & MC664(X)
VR(0) to VR(65535)

Syntax:

VR(index) = value
value = VR(index)



Non-volatile; automatic Flash store.



Address	Value	Description
Range: [0-10]		
0	0	
1	3397	
2	1	
3	300	
4	34.995	
5	0	
6	0	
7	0	
8	0	
9	0	
10	0	
Range: [4086-4095]		
4086	0	
4087	0	
4088	0	
4089	0	
4090	0	
4091	0	
4092	0	
4093	0	
4094	0	
4095	0	

Global TABLE memory


- All motion Coordinators:
512.000 x 64 bit floating point values.

TABLE(0) to TABLE(511999)

Syntax:

TABLE(index, value1, value2, value3, value4)

value_n = TABLE(index_n)



Define New Range

☐ Use 2D grid

Start address: 50

☒ Count: 50


☐ End address: 99

Description: Range1

Recent: [v]

OK Cancel

Volatile, except MC508 and MC664(X)



Address	Value
▲ Range: [0-10] ✖	
0	0
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
▲ Range: [511990-511999] ✖	
511990	0
511991	0
511992	0
511993	0
511994	0
511995	0
511996	0
511997	0
511998	0
511999	0

Lock Project

Locking the controller will prevent any unauthorized user from viewing or modifying the programs in memory, and also prevent *Motion Perfect* from connecting in Sync mode.

-To Lock the currently connected controller, select "Controller / Lock Controller" from the main menu. For this to be available it must be enabled in the Options Dialog (" [General / Miscellaneous](#) " page) and Motion Perfect must be connected to the controller in Sync mode.

To Lock The Project



Motion Perfect v5.5.4 Options - Miscellaneous

- ☒ Cache static controller data locally
- ☒ Display numbers in tools in neutral format
- ☒ Display help in separate process
- ☒ Enable controller lock tool
- ☒ Show compile results when compiling a program
- ☒ Keep Output Window open after controller reset

Controller Menu

- Connect in Sync Mode
- Connect in Tool Mode
- Connect in Direct Mode
- Disconnect
- Connection Settings...
- Reset Controller...
- Communications...
- Enable Features...
- Memory Card...
- Load Firmware...
- Reprogram FPGA...
- Directory...
- Processes...
- Import values...
- Export values...
- Download All Files ...
- Lock Controller...**
- Unlock Controller...

Controller Lock Dialog

Lock controller

WARNING: Locking the controller will prevent anyone from viewing or editing programs on it until the controller is unlocked. Motion Perfect will run in Tool or Direct mode only.

Code

Enter a numeric code up to 7 numeric digits (at least 5 are recommended)

Re-type code

Enter the code again



Lock Cancel

5 to 7 numeric digits





IEC 61131-3 Bound variables

- IEC variables are Bound to either VR or TABLE
- Any valid data type in IEC program
- Mapped to VR or TABLE as Float 64
- Conversion is automatic




LADDER Programming

IEC 61131-3 LD language is a graphical programming language. **Ladder logic** is a programming language that represents a program by a graphical diagram based on the circuit diagrams of relay logic hardware.




Arrows within the state diagram show the possible state transitions between the states. State transitions due to an issued command are shown by full arrows. Dashed arrows are used for state transitions that occur when a command of an axis has terminated or a system related transition (like error related). The motion commands which transit the axis to the corresponding motion state are listed above the states. These motion commands may also be issued when the axis is already in the according motion state.




MC_Power

Controls the power stage (ON or OFF).





MC_Reset

Resets all internal axis-related errors.




MC_MoveRelative



Commands a controlled motion of a specified distance relative to the position at time of the execution.



Digital I/O Viewer

The digital I/O viewer is used to show the states of the digital inputs and outputs of the controller (both local and remote).

It is possible to change which banks are displayed by clicking on the "Configuration" button  which then displays the configuration dialog.



Analog I/O Viewer

The analogue I/O viewer is used to show the values measured on the analogue inputs and set on the analogue outputs of the controller (both local and remote).

Analogue I/O Status (Inputs: 10, Outputs: 4)

In	Description	Value
<input checked="" type="checkbox"/>	0 P-0	526
<input checked="" type="checkbox"/>	1 P-1	523
<input checked="" type="checkbox"/>	2	524
<input checked="" type="checkbox"/>	3	524
<input checked="" type="checkbox"/>	4	527
<input checked="" type="checkbox"/>	5	524
<input checked="" type="checkbox"/>	6	525
<input checked="" type="checkbox"/>	7	526
<input checked="" type="checkbox"/>	32 J/S-X0	9
<input checked="" type="checkbox"/>	33 J/S-Y0	0

Out	Description	Value
<input checked="" type="checkbox"/>	0 Mon 1	656
<input checked="" type="checkbox"/>	1 Mon 2	-448
<input checked="" type="checkbox"/>	2	-1109
<input checked="" type="checkbox"/>	3	0

Analogue I/O Status (Inputs: 10, Outputs: 4)


In	Value
0	526
1	523
2	524
3	524
4	527
5	524
6	525
7	525
32	10
33	0

Out	Value
0	656
1	-448
2	-1109
3	0

Watch Variables



The "Watch Variables" tool allows the user to look at the values of program internal variables and global variables **while a program is running** or **stepping**. It can be used to display variables of all types from all runnable program types.

Up to 4 different Watch Windows can be displayed if the Watch Tool is started from Motion Perfect's main menu. Other means of starting it will only display a single window.

A screenshot of the 'Watch Variables 1' window. The window has a title bar with a close button and a refresh button. Below the title bar is a table with three columns: 'Name', 'Value', and 'Context'. The table contains several rows of data. A red arrow points from the '1.0' format button in the top left of the window to the 'mon2' row in the table.


Name	Value	Context
ary(0,0,0)	1852	ARRAY
ary(3,2,1)	1974	ARRAY
j	32	OUTGEN
k	19	OUTGEN
m	79	ARRAY
strng	/0123456789;.<=>?@ABCDEFGHIJKL	ARRAY
bb	-1	ARRAY,20
IEC_TASK1\IN10	TRUE	IEC_TASK1
IEC_TASK1\AIN32	TRUE	IEC_TASK1
mon1	5	D3D_1
mon2	3.1	D3D_1

Integer Number Display Format

The  (decimal) or  (hexadecimal) button indicates the current format used to display integer numbers. Clicking on the button brings up a drop-down menu to allow the user to change the format.

OSCILLOSCOPE


- The software oscilloscope can be used to trace many of the variables and parameters on the *Motion* Coordinator, aiding program development and machine commissioning.
- There are up to 8 channels available, each capable of recording at up to 1000 samples/sec, with manual cycling or program linked triggering.



3D Visualization

This is done selecting “*Import 3D geometry...*” from the menu displayed by clicking the visualizer’s “[More](#)” tool button. A machine model can be created from a 3D model exported by a third-party 3D modelling package. The 3D formats currently supported are **OBJ** and **STL**. OBJ is recommended.

Once the 3D data has been imported the machine joints need to be defined by their position in space and orientation (joint axis). The corresponding visual parts from the 3D model need to be bound to a joint so that its movement can be animated.




In association with robot related development, a new TARGET data type has been introduced in the Trio BASIC language. It stores information of position and orientation in 3D space. The TARGET data type represents a set of 6 values:

- X, Y, Z – for the coordinates of the point in 3D space in millimeters
- U, V, W – for the angular orientation in degrees.

An array of 1000 global target ([GTA](#)) points is available for use in all programs. In addition to the 6 coordinates GTAs can have name assigned which can be used to reference them in programs. An Active state flag used to determine whether [GTA](#) point has already been defined and contains valid data

Adding A New Point

There are two methods for entering new points - teaching and typing-in.



Global Targets (GTAs)

#	Name	X	Y	Z	U	V	W
0	pt0	0.000	0.000	0.000	0.00	0.00	0.00
[1..29]							
30	first_dice_up	0.000	0.000	0.000	0.00	0.00	0.00
31	first_dice_down	0.000	0.000	100.000	0.00	0.00	0.00
32	second_dice_up	0.000	65.000	0.000	0.00	0.00	0.00
33	second_dice_down	0.000	65.000	100.000	0.00	0.00	0.00
34	third_dice_up	0.000	130.000	0.000	0.00	0.00	0.00
35	third_dice_down	0.000	130.000	100.000	0.00	0.00	0.00
36	fourth_dice_up	49.000	0.000	0.000	0.00	0.00	0.00
37	fourth_dice_down	49.000	0.000	100.000	0.00	0.00	0.00
38	fifth_dice_up	49.000	65.000	0.000	0.00	0.00	0.00
39	fifth_dice_down	50.000	65.000	100.000	0.00	0.00	0.00
40	sixth_dice_up	49.000	130.000	0.000	0.00	0.00	0.00
41	sixth_dice_down	49.000	130.000	100.000	0.00	0.00	0.00
[42..999]							

Jog robot Robot # 0 T: None (0) OF: None (0) RF: None (0)

Linear jog

Jog joints

Joint	Position	Velocity	Acceleration
R1A1 (1)	0.00°	10.00°/s	
R1A2 (2)	0.00°	10.00°/s	
R1A3 (3)	0.00°	10.00°/s	
R1A4 (4)	0.00°	10.00°/s	
R1A5 (5)	0.00°	10.00°/s	
R1A6 (6)	0.00°	10.00°/s	

Position and orientation

	World	Base	Tool
X	333.0000 mm	333.0000 mm	333.0000 mm → 50.00 mm/s
Y	0.0000 mm	0.0000 mm	0.0000 mm → 50.00 mm/s
Z	515.0000 mm	515.0000 mm	515.0000 mm → 50.00 mm/s
U	0.00°	0.00°	0.00° → 50.00°/s
V	90.00°	90.00°	90.00° → 50.00°/s
W	0.00°	0.00°	0.00° → 50.00°/s

Mode: ☒ World ☐ Base ☐ Tool ☐ Frame

Speed: 100% Accel: 100%

Jog Configuration... Teach point Close

JOG AXIS

The Jog Axes tool allows the user to move the axes on the *Motion* Coordinator.

The 'Jog Axes' window displays a table for configuring three axes. Each axis has an 'Enable Jog' checkbox, a 'Position' field, a 'Jog speed' field, and 'Jog inputs' (minus and plus buttons). Axis (1) is enabled with position 0 and speed 100. Axis (2) is disabled with position 0 and speed 100. Axis (3) is enabled with position 0 and speed 100. A red arrow points from the 'Select axes' button to the 'Show/Hide Axes' window.

Axis name	Enable Jog	Position	Jog speed	Jog inputs
Axis (1)	<input checked="" type="checkbox"/>	0	100	10 13
Axis (2)	<input type="checkbox"/>	0	100	-1 -1
Axis (3)	<input checked="" type="checkbox"/>	0	100	16 18

Select axes

Warnings

This displays an axis selector box which enables the user to select the axis to include in the jog axes display. By default, the physical axes fitted to the controller will be displayed.

The 'Show/Hide Axes' window shows a list of axes with columns for Axis, Type, Slot, and Axis Name. Axis 2 is selected. A 'Selected' table on the right shows the current selection. A red arrow points from the 'Jog Axes' window to this window.

Axis	Type	Slot	Axis Name
0	Virtual	-1	Axis
3	Virtual	-1	Axis
4	Virtual	-1	Axis
5	Virtual	-1	Axis
6	Virtual	-1	Axis
7	Virtual	-1	Axis
8	Virtual	-1	Axis
9	Virtual	-1	Axis
10	Virtual	-1	Axis
11	Virtual	-1	Axis
12	Virtual	-1	Axis
13	Virtual	-1	Axis
14	Virtual	-1	Axis



Selected

Axis	Type	Slot	Axis Name
1	Virtual	-1	Axis
2	Virtual	-1	Axis

Tip: Double-click to add or remove

OK Cancel


Uniplay is Trio Motion Technology's [HMI](#) system for use in coordination with Trio's series 4 *Motion* Coordinators. It allows interaction with the *Motion* Coordinator using a fully customizable, touch-screen interface.



Why Multi-tasking?

Multiple functions

A machine has multiple functions, some operate sequentially and some concurrently.



All running together!

Multi-Tasking: Benefit

Division of Tasks

Smaller, dedicated programs (processes) can be written to handle specific functions of the machine.

Tasks: Work

☐ task 1

☐ task 2

☐ task 3

☐

Error Handling

A process can be dedicated to error trapping.



Concurrency

Each process acts like a virtual controller and operates independently of the others.

Process 1

Process 2

Command Line – Terminal #0

The command line / Motion Perfect Link is always available, even when programs are running.


Channel #0			
Terminal Edit			
PROCESS			
Process	Type	Status	Name
1	Slow	Run	MAIN
20	Fast	Pause	PRINTER
21	Fast	Sleep[2]	MOTION1
22	SYS	Run	Command Line
23	SYS	Run	Protocol Scheduler
24	SYS	Sleep[0]	Background Manager
25	SYS	Sleep[7]	MPE
26	SYS	Suspend	CAN Server
27	SYS	Run	TCP/IP Server
28	SYS	Run	ECAT Async




Process:
Processing slot that runs an IEC task or BASIC program

Each process is allocated a number between 0 and “max process”
Motion Coordinator type determines the max number of processes

Controller	# Processes	
MC403 (Z)	6	0 .. 5
MC405 / Euro404	10	0 .. 9
MC508 / Euro408	22	0 .. 21
MC664(X)	22	0 .. 21
MC4N / MC6N	22	0 .. 9
Flex-6 Nano	22	0 .. 21
MotionPLC	4(12)	0 .. 3



Process Monitor




Proc	Program	Type	Status	Line	Location	CPU %	Time	Core	Call Stack
1	MAIN	B	RUNNING	30	MAIN	100.00	02:29:58.997	2	
20	PRINTER	B	PAUSED	14	PRINTER	00.00	02:28:27.583	3	
21	MOTION1	B	SLEEPING	44	MOTION1	00.00	02:28:58.094	2	

Running: running through the lines of BASIC at "full speed"

Paused: program has been paused by Motion Perfect.

Sleeping: program is in a wait state.


```
WA(time_in_msecs)  
WAIT IDLE  
WAIT LOADED
```




Multi-Tasking: Program priority

Process priority is defined by process number
The 2 highest process numbers are FAST
All others are SLOW

Example: MC664 (P861)




3 processes running




New Project

A new project can be created either as a new project (either empty or from a template) or from the contents of a connected controller.




Select the directory in which to store the project, enter a name for the project then click on the "Create" button. The "Select Project Template" dialog is then displayed.



The RPS Template (for robotic features) just available in Motion Controller
The RPS features **Not supported** by Motion PLCs.


Project Tree



"Flash" Status Indicator

This indicates, by turning **red**, when the controller is writing to its "flash" EEPROM memory.

"Reset MC" Control

This control acts as a status indicator and a reset button. If the MC_CONFIG program on the controller has been created, changed or deleted since the controller was last reset, the control is highlighted, . That means indicating that the controller needs to be reset before programs can be run again. Otherwise, the control appears as a normal button. When in either state, clicking on the control will reset the controller.

"Axis Status" Indicator "System" Status Indicator

"Drives Enable" Button

Clicking on this button toggles the state of the drive enable (watchdog output) on the controller. When drives are enabled the background of the button is colored yellow.

"Motion Stop" Button

Clicking on the "Motion Stop" button stops all currently running programs and empties all the move buffers on the controller causing **all motion to stop**.

"Halt Programs" Button

Clicking on this button halts all currently running programs **but does not stop current or buffered moves**.



Project Tree

Controller: MCS 40 (P620) v2.0334
Axis Status: OK
System: OK
Flash: ●

Motion stop Master enable Halt programs

Project: Untitled

- AXISALARM
- CLEAR_UNIT_ALARM
- COMMAND
- STARTUP
- TEST
- MC_CONFIG

Axes

Max. Axes: 32
Max. Axis Index: 1023
Max. Physical Axes: 4
Max. On-board Axes: 0
Max. Remote Axes: 4
Max. Analogue Axes: 0
Module Axes: 0
Configured Axes: 1
Activated Axes: 1
[Show/hide axes...](#)
[Axes parameters...](#)

Memory

- Programs - 8 / 48
- VR: 4096
- TABLE: 512000
- Local variables
- Free program space: 2686152

Configuration

- EtherCAT (Slot 0)
 - Drive #1 (Estun ED3L)
 - Motor(Axis (0))
- MS-Bus (Slot 1)
 - Slice #0 (P001 MSDI16N)
 - Slice #1 (P003 MSDO16N)

Summary of AXES
(Configured and Virtual)

Show/Hide Axes

(Type text to search for)

Axis	Type	Slot	Axis Name
0	ECAT Pos	0	Axis

Selected

Axis	Type	Slot	Axis Name
------	------	------	-----------

No axes selected

☒ Show Activated Axes Only
Tip: Hold Ctrl or Shift for multiple selection

OK Cancel

Main Unit Memory Capacity
(According to Hardware)

Connected Devices on EtherCAT network
(Slot 0)

Connected IO Expansions Cards on MS-Bus
(Slot 1)






DRIVE_MODE

- value:
- 1: Cyclic Synchronous Position mode (CSP)
 - 2: Cyclic Synchronous Velocity mode (CSV)
 - 3: Cyclic Synchronous Torque mode (CST)
 - 4: Open-loop speed (Inverter drive)
 - 5: Reference Encoder
 - 6: Open loop position (Stepper drive)

**MUST BE RESET
AFTER EDIT**

DRIVE_PROFILE


```
MC_CONFIG x
0 'ignore auto load ethercat in power on
1 AUTO_ETHERCAT = OFF
2
3 '1000 micro second (ethercat update rate) up to 125 micro sec / max is 2 ms
4 SERVO_PERIOD = 1000
5
6 'to mapping ED3L1010 - first axis
7 'in position mode
8 DRIVE_MODE AXIS(0) = 1
9
10 'general mode
11 DRIVE_PROFILE AXIS(0) = 0
12
13 'to mapping ED3L1010 - second axis
14 'in position mode
15 DRIVE_MODE AXIS(1) = 1
16
17 'general mode
18 DRIVE_PROFILE AXIS(1) = 0
19
20 'Estun ED3L mode Position (3)
21 DRIVE_MODE AXIS(2) = 1
22
23 'Estun ED3L profile #3
24 DRIVE_PROFILE AXIS(2) = 3
```



- Axis(2)
Profile No: 3 Ctrl Mode: Position (65)
- RxPDO
- 0: CTRL_WORD, 2 bytes
 - 1: TARGET_POS, 4 bytes
 - 2: TOUCH_PROBE_FUNCTION, 2 bytes
 - 3: PADDING, 3 bytes
 - 4: DOUT, 1 byte
- TxPDO
- 0: STATUS_WORD, 2 bytes
 - 1: ACTUAL_POS, 4 bytes
 - 2: TOUCH_PROBE_STATUS, 2 bytes
 - 3: TOUCH_PROBE1_POS1, 4 bytes
 - 4: TOUCH_PROBE1_POS2, 4 bytes
 - 5: TOUCH_PROBE2_POS1, 4 bytes
 - 6: TOUCH_PROBE2_POS2, 4 bytes
 - 7: ACTUAL_FE, 4 bytes
 - 8: PADDING, 2 bytes
 - 9: DIN, 1 byte
 - 10: PADDING, 1 byte


Name	Modifier	Value	Comment
AUTO_ETHERCAT		OFF	ignore auto load ethercat in power on
SERVO_PERIOD		1000	1000 micro second (ethercat update rate) up to 125
DRIVE_MODE	AXIS(0)	1	to mapping ED3L1010 - first axis in position mode
DRIVE_PROFILE	AXIS(0)	0	general mode
DRIVE_MODE	AXIS(1)	1	to mapping ED3L1010 - second axis in position mode
DRIVE_PROFILE	AXIS(1)	0	general mode
DRIVE_MODE	AXIS(2)	1	Estun ED3L mode Position (3)
DRIVE_PROFILE	AXIS(2)	3	Estun ED3L profile #3
IP_PROTOCOL_CTRL		12	





**TO GET
ED3L-1010AEA EtherCAT
MAPPING FILE**

GET FILE



File structure

The XML format has tags to delineate the various objects that require description.

The Tags' hierarchy is as shown below:

```
<EtherCAT>
  <group_tag>
    <block_tag>
      <Entry_tag>
        <Attribute_tag>Value</Attribute_tag>
        ...
      </Entry_tag>
    </block_tag>
  </group_tag>
</EtherCAT>
```

Vendors And Profiles

Index	Name	Vid	Pid	Rev	Axis Type	DRIVE_PROFILE	Slave Config	Comments
ESTUN AUTOMATION TECHNOLOGY CO.,LTD (0x0000060A)								
0	ED3L_2AXIS_V1.0.0	0x0000060A	0xED310002	0	POSITION	0	0	

Slave Configurations

Index	Slave Type	Axis Count	DIN	DOUT	AIN	AOUT	ESC Config	SDO Init Cmds	RxPDO Config	TxPDO Config	In l
0	SERVO	2	64	0	0	0	0	SDO_ED3L_2AXIS_V1.0.0	RXPDO_PROFILE	TXPDO_PROFILE	0

Slave Config #0

Type: SERVO

Number of Axes: 2

Digital Inputs: 64

Digital Outputs: 0

Analogue Inputs: 0

Analogue Outputs: 0

Enabled Ctrl Word: (Enter value)

Supports Id Reg 134: ☒

MDP PDO increment: (Select Value)

MDP Index increment: (Select Value)

ESC Config: 0

SDO Init Cmds: SDO_ED3L_2AXIS_V1.0.0

RxPDO Config: RXPDO_PROFILE

TxPDO Config: TXPDO_PROFILE

In Use By: 0

Mailbox

Startup Protocol: CoE

Protocols: ☒ CoE ☒ FoE ☐ SoE

Cyclic Data

Axis Type: POSITION

Control Mode: CSP

Use Logical Read/Write: TRUE

Command: LRW

Distributed Clock

Mode: 0x0300

VR

Input Address: (Enter value)

Output Address: (Enter value)

The EC_EXTEND file is an XML format text file containing configuration data for one or more EtherCAT slave devices. The file can be loaded onto a *Motion Coordinator* so that it is able to interact with the EtherCAT devices whose configuration data is contained in the file. The contents of the file is used to extend the *Motion Coordinator's* in-build dictionary of EtherCAT devices.

AXIS INITIALIZE

Controller MCS 40 (P620) v2.0334

Axis Status: OK Reset MC

System: OK Flash: ●

Motion stop Master enable Halt programs

Project: MCS40_3AX_rev002_140406

- ADDAX_NEW
- ALARM
- AXIS3_ENCODER_TEST
- CLEAR_UNIT_ERROR
- FROM_RECIP
- HMI_COMMAND
- 8 Running
- HOME_37_DUAL_AXIS_B
- HOME_37_ED3L
- JOGGING
- MOVE_CIRCLE_DEMO
- MOVING_DEMO
- REGIST
- STARTUP
- WRITE_PARAM_SOFTRESET
- MC_CONFIG
- EC_EXTEND

Axes Memory Configuration EtherCAT (Slot 0) MS-Bus (Slot 1)

```
FOR i = 0 TO 2
  BASE(i)
  'to reverse motor direction (CCW)
  ENCODER_RATIO(-1,1) 'This command allows the incoming encoder count to be scaled by a non integer ratio
  STEP_RATIO(-1,1) 'This command sets up an integer ratio for the axis' demanded position

  UNITS = 2 ^ 20
  SPEED = 10 '600RPM
  JOGSPEED = 5 '300RPM
  ACCEL = 100
  DECEL = ACCEL

  'CREEP = 0.1
  'REP_DIST = 360
  'REP_OPTION = 0
  DRIVE_FE_LIMIT = 100 '100turn - per revolution
  FE_LIMIT = 100 'the maximum following error
  FE_RANGE = 70 ' following error report range - shows in status
  FS_LIMIT = 400000000000
  RS_LIMIT = -400000000000
  AXIS_ENABLE = ON ' enable the axis in controller
  SERVO AXIS(i) = ON 'run the axis in controller
  'DEFPOS(0) ' get zero value
NEXT i
```

Axis parameters need to be mapped only once at controller startup (MC power on).


Axis Parameters

Parameter	Axis (0)	Axis (1)	Axis (2)
ATYPE	ECAT Pos	ECAT Pos	ECAT Pos
UNITS	1048576	1048576	1048576
Velocity profile			
ACCEL	100	100	100
DECEL	100	100	100
SPEED	10	10	10
CREEP	9.53674e-05	9.53674e-05	9.53674e-05
JOJSPEED	5	5	5
MERGE	0	0	0
SRAMP	0	0	0
MSPEED	0	0.00095	0
VP_SPEED	0	0	0
AXIS_SPEED	1000	1000	1000
Limits			
DATUM_IN	-1	-1	-1
DRIVE_FE_LIMIT	100	100	100
FE_LIMIT	100	100	100
FE_RANGE	70	70	70
FHOLD_IN	-1	-1	-1
FWD_IN	-1	-1	-1
REP_DIST	190734.86328	190734.86328	190734.86328
REP_OPTION	0	0	0
REV_IN	-1	-1	-1
FS_LIMIT	400000000000	400000000000	400000000000
RS_LIMIT	-400000000000	-400000000000	-400000000000
Positions			
DPOS	9.25064e-05	-0.00074	-0.00235
ENCODER	99	-780	-2465
ENDMOVE	9.25064e-05	-0.00074	-0.00235



Modify STARTUP Program

The [STARTUP](#) program is a user run TrioBASIC program used to initialize the system on power-up. It is commonly used to set up Axis Parameters, TABLE Areas, VR Variables, some Communications Parameters and Drive Parameters (when intelligent drive support is available). Adding Drive Parameters is handled by the appropriate drive configuration tool, all other data is handled by a common dialog set. When "Modify STARTUP Program..." is selected from the "Project" item in the main menu the user is presented with a list of things which can be added to the STARTUP program.



ED3L Alarm Handler

AXISSTATUS

Bit	Description	Value	char
0	Speed limit active	1	l
1	Following error warning range	2	w
2	Communications error to remote drive	4	a
3	Remote drive error	8	m
29	MOVEADD is being cancelled (CANCEL(5))	536870912	
30	EtherCAT emergency message received from remote drive	1073741824	
31	Not used	2147483648	

ED3L Error Code Address

Error Code (603Fh)

Index	Subindex	Name	Data Type	Access	PDO Mapping	Value
603Fh	0	Error Code	UINT16	RO	TxPDO	0x0000

```

IF AXISSTATUS AXIS(2).30=1 OR AXISSTATUS AXIS(2).3=1 THEN
  VR(2000)=0 ' check if there is any remote Drive Error then read the relevant ADDRESS.
  CO_READ(0,2,$603f,0,6,1000) ' Read the Error Code from Object $603F subindex0 of - in HEX format
  'ED3M drive's (2) Axis.
  VR(1001)= VR(1000) AND $00FF 'separate the low byte to read the Alarm Code and
  'convert it TO decimal TO read in VR(1001).
  WA(50)
  TABLE(90, VR(1001)) 'table 90 to get single axis alarm on HMI in word
  
```

IF TABLE(90) = 80 `decimal
It means A.50 `hex



ED3L PROFILE (GET/SET)

According to the Drive Profile,
Using include mapped properties!

```
MOVE_CIRCLE_DEMO x
0 BASE(0,1) 'select X and Y for circular interpolation
1 SPEED AXIS(0) = 5
2 SPEED AXIS(1) = 5
3
4 WA(2000)
5 MOVECIRC(10,10,-10,10,1)
6 WAIT IDLE
7
8 MOVE(0, 12) 'Move A -> B
9 MOVECIRC(3, 3, 3, 0, 1) 'Move B -> C
10 MOVE(4, 0) 'Move C -> D
11 MOVECIRC(3, -3, 0, -3, 1) 'Move D -> E
12 MOVE(0, -12) 'Move E -> F
13 MOVECIRC(-3, -3, -3, 0, 1) 'Move F -> G
14 MOVE(-4, 0) 'Move G -> H
15 MOVECIRC(-3, 3, 0, 3, 1) 'Move H -> A
16 WAIT IDLE
17
18 SPEED AXIS(0) = 10
19 SPEED AXIS(1) = 10
20 DRIVE_c
    DRIVE_CLEAR
    DRIVE_CONTROL
    DRIVE_CONTROLWORD
    DRIVE_CURRENT
    DRIVE_CW_MODE
    drive_c
```

Axis Parameters		
	Parameter	Axis (2)
<input type="checkbox"/>	SYNC_PAUSE	0
<input type="checkbox"/>	SYNC_WITHDRAW	0
<input type="checkbox"/>	SYNC_TIMER	0
<input checked="" type="checkbox"/>	Drive	
<input type="checkbox"/>	AXIS_ADDRESS	-1
<input type="checkbox"/>	AXIS_ERROR_COUNT	0
<input type="checkbox"/>	DRIVE_CONTROL	0
<input type="checkbox"/>	DRIVE_CONTROLWORD	0
<input type="checkbox"/>	DRIVE_CW_MODE	0
<input checked="" type="checkbox"/>	DRIVE_ENABLE	0
<input type="checkbox"/>	DRIVE_INDEX	0
<input type="checkbox"/>	DRIVE_MODE	1
<input type="checkbox"/>	DRIVE_PARAMETER	0
<input type="checkbox"/>	DRIVE_PROFILE	3
<input type="checkbox"/>	DRIVE_SET_VAL	0
<input type="checkbox"/>	DRIVE_TYPE	0
<input type="checkbox"/>	DRIVE_VALUE	0
<input checked="" type="checkbox"/>	DRIVE_CURRENT	0
<input checked="" type="checkbox"/>	DRIVE_INPUTS	31
<input checked="" type="checkbox"/>	DRIVE_MONITOR	0
<input checked="" type="checkbox"/>	DRIVE_STATUS	592
<input checked="" type="checkbox"/>	DRIVE_TORQUE	0
<input checked="" type="checkbox"/>	DRIVE_VELOCITY	0

Intelligent drives

Slot 0 - EtherCAT Slot 1 - MS-Bus

Diagram

Master state: Operational Diagnostics Disabled

Address: 1 2

EtherCAT Profile Display

Model: Mentor MP (0x00050007)
Vendor: Control Techniques (0x000000F9)
Ctrl Mode: Position (65) Profile No 0

Display Profile

Position (65)
#0
#1
#2

Speed (66)
#0
#1
#2

Torque (67)
#0
#1
#2

PDO Config

RxPDO
0: Status Word, 2 bytes
1: Actual Position, 4 bytes

TxPDO
0: Control Word, 2 bytes
1: Target Position, 4 bytes

SDO Config

CoE written on Pre-Op to Safe-Op
0x1C12:00 (1) = 0x00
0x1C13:00 (1) = 0x00
0x1600:00 (1) = 0x00
0x1600:01 (4) = 0x60400010
0x1600:02 (4) = 0x607A0020
0x1600:00 (1) = 0x02
0x1A00:00 (1) = 0x00
0x1A00:01 (4) = 0x60410010
0x1A00:02 (4) = 0x60640020
0x1A00:00 (1) = 0x02
0x1C12:01 (2) = 0x1600

Drives

Axis	Ctrl Mode	Model	Pos	Alias
0	ECAT Pos		0	0
1	ECAT Pos		0	0
2	ECAT Pos	Estun ED3L	1	0

Modify STARTUP Program Browse database...



Motion 1

BASE (n)

The axis group consists of:
Axes n, n+1, n+2 etc.

Example on MC405 set:
BASE(2)
Axis group is 2, 3, 4, 5, 6, 7 etc.

BASE (x, y, z)

This specifies the axis group as:
Axes x, y, and z

Example on MC508 set:
BASE(1,2,5)
Axis group is 1, 2, 5, 0, 3, 4, 6, 7 etc.

'MOTION1' Main routine

```
FOR x=0 TO 1  
  BASE (x)  
  SPEED=200  
  ACCEL=500  
  DECEL=500  
NEXT x
```

Single axis continuous moves:

- Starts movement with the programmed speeds and accelerations
- Multiple axis can be run simultaneously

FORWARD

- Move the base axis in a forward direction


REVERSE

- Move the base axis in a reverse direction


Each Process can specify a different axis group.



Type commands into terminal channel #0



MOVE (3, 2)



MOVECIRC (endx, endy, cx, cy, dir)

NOTE: Endpoint & Centre values are RELATIVE to start position.

BASIC Programming language

WHILE

```
WHILE IN(8) = 1
  OP(10,ON) ' output 10 ON
  WA(1000) ' wait 1000ms
  OP(10,OFF) ' output 10 OFF
  WA(1000) ' wait 1000ms
WEND
```

Create a slowly flashing output

Infinity WHILE

The main loop for a machine program

```
WHILE TRUE
  .. Main program code
  ..
WEND
```

REPEAT

```
REPEAT
  OP(10,ON)
  WA(1000)
  OP(10,OFF)
  WA(1000)
UNTIL IN(8) = ON
```

The same flashing output -
will always flash at least once.

Infinity REPEAT

Infinite loop

```
REPEAT
  .. Code in continuously
  .. repeating loop
UNTIL FALSE
```

FOR

```
FOR a = 8 TO 15
  OP(a,ON)
  WA(1000)
  OP(a,OFF)
NEXT a
```

FOR & STEP

```
FOR a = 14 TO 8 STEP -2
  OP(a,ON)
  WA(1000)
  OP(a,OFF)
NEXT a
```

Counting down

FOR & Condition

```
FOR x = 1 TO 2047
  IF x > AIN(0) THEN
    VR(10) = x
    EXIT
  ELSEIF IN(1) = ON THEN
    CONTINUE
  ENDIF
  a = 2 * x
  AOUT(2) = a - 512
NEXT x
```

IF

Multiple Actions

```
IF IN(8) = ON THEN
  OP(10, ON)
  x = 10.5
  distance = SPEED ^ 2 / (2 * DECEL)
ENDIF
```



SWITCH CASE

```
Var_1 = 45  
  
SELECT_CASE var_1  
  CASE 1  
    OP(8, ON)  
  CASE 2, 3, 4  
    OP(9, ON)  
  CASE 30, 50  
    OP(10, ON)  
    OP(15, ON)  
  CASE 45  
    OP(11, ON)  
  CASE ELSE  
    OP(8, 15, 0)  
END_CASE
```

GOTO

```
x = 1  
y = 2  
z = x + y  
GOTO label1  
  
a = x + 2  
b = y * z  
label1:  
a = x + 10  
b = y / z
```

```
GOSUB sub1  
STOP  
  
sub1:  
  x = 2  
  y = y + 3  
RETURN
```

FUNCTION

```
FUNCTION set_axis(v, axis_number AS INTEGER)  
  SPEED AXIS(axis_number) = v  
  ACCEL AXIS(axis_number) = v * 10  
  DECEL AXIS(axis_number) = v * 10  
ENDFUNC
```

Functions must be placed in a BASIC Library.



WHILE .. WEND

```
WHILE IN(8) = 1
    OP(10,ON) ' output 10 ON
    WA(1000) ' wait 1000ms
    OP(10,OFF) ' output 10 OFF
    WA(1000) ' wait 1000ms
WEND
```

Create a slowly flashing output

The main loop for a machine program

```
WHILE TRUE

    .. Main program code
    ..

WEND
```

Syntax:

```
WHILE condition
    Commands
WEND
```

Parameters:

condition:	Any valid logical TrioBASIC expression
commands:	TrioBASIC statements that you wish to execute

REPEAT .. UNTIL

REPEAT

OP (10 ,ON)

WA (1000)

OP (10 ,OFF)

WA (1000)

UNTIL IN (8) = ON

*The same flashing output -
will always flash at least once.*

Infinite loop

REPEAT

.. Code in continuously
.. repeating loop

UNTIL FALSE

Syntax:

```
REPEAT  
  commands  
UNTIL expression
```

Parameters:

expression:	Any valid TrioBASIC expression
commands:	TrioBASIC statements that you wish to execute

FOR .. NEXT .. LOOPS

```
FOR a = 8 TO 15
```

```
  OP (a,ON)
```

Flashes all 8 outputs in sequence

```
  WA (1000)
```

```
  OP (a,OFF)
```

```
NEXT a
```

```
FOR a = 8 TO 14 STEP 2
```

```
  OP (a,ON)
```

Flashes only even numbered outputs

```
  WA (1000)
```

```
  OP (a,OFF)
```

```
NEXT a
```

```
FOR a = 14 TO 8 STEP -2
```

```
  OP (a,ON)
```

```
  WA (1000)
```

```
  OP (a,OFF)
```

```
NEXT a
```

Counting down


Syntax:

```
FOR variable = start TO end [STEP increment]  
  commands  
NEXT variable
```

Parameters:

commands:	Trio BASIC statements that you wish to execute
variable:	A valid Trio BASIC variable. Either a global VR variable, or a local variable may be used.
start:	The initial value for the variable
end:	The final value for the variable
increment:	The value that the variable is incremented by, which may be positive or negative

EXIT and CONTINUE



Syntax:

EXIT_LOOP

Syntax:

CONTINUE

FOR .. NEXT loop must normally complete to the last value of x.

To come out of the FOR .. NEXT loop early, use EXIT.

The program then continues on the line after NEXT x.

CONTINUE forces the program to go back to the top of the loop.

AOUT(2) is then not set on that pass round the loop.

IF .. THEN .. ENDIF

Single Action

```
IF IN(8) = ON THEN OP(10, ON)
```

Multiple Actions

```
IF IN(8) = ON THEN  
    OP(10, ON)  
    x = 10.5  
    distance = SPEED ^ 2 / (2 * DECEL)  
ENDIF
```

This form is clearer to read

```
IF IN(8) = ON THEN  
    OP(10, ON)  
ENDIF
```

Syntax:

```
IF condition THEN  
    commands  
ELSEIF expression THEN  
    commands  
ELSE  
    commands  
ENDIF
```

Parameters:

condition:	Any valid logical TrioBASIC expression
commands:	TrioBASIC statements that you wish to execute

IF .. ELSE .. ELSEIF

```
IF IN(8)= ON THEN
    OP(10,ON)
    OP(11,ON)
ELSE
    OP(10,OFF)
    OP(11,ON)
ENDIF
```

```
IF IN(8)= ON THEN
    OP(10,ON)
ELSEIF IN(9)=ON THEN
    stop_all()
ELSEIF data = 22 THEN
    value_test(1, 30)
ELSE
    PRINT #5, "Not found"
ENDIF
```


Use an IF structure to report the operating state of a machine.

```
IF operating_state = 0 THEN
    PRINT#5, "Machine Running"
ELSEIF operating_state = 1 THEN
    PRINT#5, "Machine Idle"
ELSEIF operating_state = 2 THEN
    PRINT#5, "Machine Jammed"
ELSE
    PRINT#5, "Machine in unknown state"
ENDIF
```

SELECT .. CASE

```
Var_1 = 45
```

```
SELECT_CASE var_1  
  CASE 1  
    OP(8, ON)  
  CASE 2, 3, 4  
    OP(9, ON)  
  CASE 30, 50  
    OP(10, ON)  
    OP(15, ON)  
  CASE 45  
    OP(11, ON)  
  CASE ELSE  
    OP(8, 15, 0)  
END_CASE
```



Syntax:

```
SELECT "program"[, program_type]
```

- 1) SELECT_CASE checks one variable.
- 2) Each CASE that numerically equals the value causes execution of code between 2 CASE statements.
- 3) The program then continues after END_CASE.
- 4) This form is ideal for several actions dependant on the value of a variable.



```
FUNCTION set_axis(v, axis_number AS INTEGER)
    SPEED AXIS(axis_number) = v
    ACCEL AXIS(axis_number) = v * 10
    DECEL AXIS(axis_number) = v * 10
ENDFUNC
```

Functions must be placed in a BASIC Library.

A Function can have values passed to it.

In the calling program:

```
set_axis(25, 0)
set_axis(30, 1)
```

A Function can return a value

The returned value can be a single value or an array containing multiple values.

Syntax:

```
FUNCTION name([param1 AS type[, param2 AS type[, param3 AS type .... ]]])
....
RETURN x
ENDFUNC
```

Parameters:

param1:	First optional parameter to be passed into the function
param2:	The second parameter if required
param3:	The third parameter if required
paramN:	Up to 16 parameters may be passed



Circular interpolated moves

`MOVECIRC(end1, end2, centre1, centre2, direction)`

1 .. CW

0 .. CCW


If the end point is not on the circular arc, the arc will end at the angle specified between the centre and the endpoint



Contoured Motion-MERGE Command


Merged moves:

- Enables moves to be joined without having to ramp speed down to zero
- The programmer is responsible for sensible merges
 - Ex: do not merge moves that reverse direction



MERGE = state

- Set MERGE to be either ON or OFF



merge_move:

```
BASE(0,1) 'set base array
MERGE=ON 'set MERGE state
MOVEABS(0,50) 'run a sequence of moves
MOVE(0,100)
MOVECIRC(50,50,50,0,1)
MOVE(100,0)
MOVECIRC(50,-50,0,-50,1)
MOVE(0,-100)
MOVECIRC(-50,-50,-50,0,1)
MOVE(-100,0)
MOVECIRC(-50,50,0,50,1)
WAIT IDLE
MERGE=OFF
RETURN
```


AXIS ENABLE & Servo State & WDOG

AXIS_ENABLE

Can be used to independently disable an axis. ON by default, can be set to OFF to disable the axis.

The axis is enabled if `AXIS_ENABLE = ON` and `WDOG = ON`.
On stepper axis `AXIS_ENABLE` will turn on the **hardware** enable outputs.

`AXIS_ENABLE = ON` 'Enable the axis

SERVO_ENABLE

Enable axis 1 to run under closed loop control and axis 1 as open loop.
`SERVO AXIS(0)=ON` 'Axis 0 is under servo control-**Closed** loop
`SERVO AXIS(1)=OFF` 'Axis 1 is run **Open** loop

WDOG

Controls the WDOG relay contact used for enabling **external drives**.
The `WDOG= ON` command **MUST** be issued in a program prior to executing moves.

LIMIT_BUFFERED:

- Increases buffered moves from 2 (MTYPE and NTYPE) to up to 64
- Enables many small moves to be MERGED together
- Increases path speed
- Useful when generating move profiles from CAD data

LIMIT_BUFFERED = value

MOVES_BUFFERED:

- Parameter to read the number of buffered motion commands

This sets the maximum number of moves that the controller can buffer.

You can increase the machine speed when using [MERGE](#) or [CORNER_MODE](#) by increasing the number of moves buffered.

Each controller has its own maximum buffer size, indicated by [BUFFERSIZE](#) .

```
Channel #0
Terminal Edit Search
>>?buffersize
64
>>
```

MCS40 Buffer Size

In AXIS PARAMETERS

Axis Parameters		
Parameter	Axis (0)	Axis
Control		
LOOKAHEAD_FACTOR	1	
Drive		
DRIVE_ENABLE	0	

Running and Stopping programs

RUN “program_name” [, process]

- Runs a program on a particular process
- The process can be left off and it will run on the highest process number available
- Program must exist else an error occurs at runtime

```
IF TABLE(27) = 1 AND PROC_STATUS PROC(2) = 0 THEN  
  RUN "REGIST",2
```

STOP

- Stops the current program


```
'### This Example will set some esse  
'for Axis#2 and perform a Soft Reset  
STOP "ALARM"  
STOP "HMI_COMMAND"
```

STOP “program_name” [, process]


- Stops a specified program
- The process can be left off and it will stop all instances of the program
- Program must exist else an error occurs at runtime

HALT

- Stops all programs



Stop Motion methods



```
CONNECT(1, 0) AXIS(1) 'Axis 1 follows axis 0  
BASE(0)  
REPEAT  
  MOVE(1000) AXIS (0)  
  MOVE(-100000) AXIS (0)  
  MOVE(100000) AXIS (0)  
UNTIL IN (2) = OFF 'Stop button pressed?  
RAPIDSTOP(2)
```

Motion can be stopped either across all axis or on a single axis

CANCEL

- Stops the running move on the base axis

RAPIDSTOP

- Stops the motion on all axis

CANCEL(2) and RAPIDSTOP(2)

- Stops the motion, clears buffered moves and the PMOVE

Axis Parameters	
Parameter	Axis (0)
ATYPE	Enc
UNITS	1.0
▲ Gains	
P_GAIN	0.0
I_GAIN	0.0
D_GAIN	0.0
OV_GAIN	0.0
VFF_GAIN	0.0
▶ Velocity profile	
▶ Limits	
▲ Positions	
DPOS	0.0
ENCODER	0
ENDMOVE	200.0
MPOS	0.0
REMAIN	0.0
▲ Axis output	
DAC	0
SERVO	0
▲ Status	
AXISSTATUS	None
FE	0.0
LINK_AXIS	-1
MTYPE	FORWARD
NTYPE	REVERSE
TABLE_POINTER	0.0
▲ Registration	
MARK	0
REG_POS	0.0
▲ Jogging	

You can print information to terminal windows in Motion perfect, the serial ports or to a file.

PRINT “*text*”

- Prints text to channel 0 on the coordinator

'Need to print double escape code (ASCII 27) to output a single escape
PRINT #5, CHR(27); CHR(27);

'Move cursor to row 14, column 10
PRINT #5, "[14;10H";

PRINT#*channel*, “*text*”


- Prints text to specified channel
- Channel 5 is a terminal window in Motion Perfect
- Other channels are shown in the manual

'Display the temperature`
PRINT #5, "Temperature: "; AIN(1);


Continuously running axes need a different “wrap around” than axes with end limits.

An axis has 4000 counts per revolution, configure [REP_DIST](#) and REP_OPTION so that it wraps from 0 to 4000.

REP_OPTION = 1
REP_DIST = 4000




REP_OPTION = 1




Multiple Axis Linked Continuous Moves


Slave axis *Master axis*



CONNECT(1, 1)



CONNECT(0.5, 1)



CONNECT(2, 1)

CONNECT(0,1) - Connection remains but slave axis does not move

connectaxis:

```
VR(10) = 1.0
```

```
BASE(0)
```

```
TICKS=5000
```

```
WHILE TICKS>0
```

```
    CONNECT (VR(10), 2)
```

```
WEND
```


```
RAPIDSTOP
```

```
RETURN
```

CONNECT does not buffer in NTYPE

Each new CONNECT simply changes the ratio

MOVE Modify



MOVEABS (100)


MOVEMODIFY (140)

MOVEMODIFY:

- Starts movement with the programmed speeds and accelerations
- Multiple axis can be run simultaneously
- No new command issued, updates end position

MOVEMODIFY(*position*)


- Set the final position to a point in the workspace



```
MOVE(10000)' Start a long move on conveyor  
REGIST(3)' set up registration  
WAIT UNTIL MARK 'MARK will be true when proximity seen  
OFFPOS=-REG_POS'set position where mark seen to 0  
MOVEMODIFY(250)'change move to stop at 250mm
```

Multiple Axis Linked Continuous Moves

```
part_seperator:
  GOSUB table_val
  BASE(1)
  CONNECT(0,0)
  REVERSE AXIS(0)
  conn_index=0
  CLUTCH_RATE=5
  WHILE IN(1)=ON
    IF IN(4,6)<>conn_index THEN
      conn_index=IN(4,6)
      CONNECT(TABLE(conn_index),0)
    ENDIF
  WEND
  RAPIDSTOP
  RETURN
table_val:
  TABLE(0,0,0.25,0.4,0.55,0.7,1,2,2.2)
  RETURN
```



Clutching a change in ratio:

- A change in connection ratio, acceleration can be defined
- This is the change in connection ratio per second
- Default is very high, attempts a step change in speed

CLUTCH_RATE=value

- Sets the value to the CLUTCH_RATE parameter

This affects operation of [CONNECT](#) by changing the connection ratio at the specified rate/second.


The connection ratio will be changed from 0 to 6 when an input is set.
It is required to take 2 second to accelerate
the linked axis so the ratio must change at 3 per second.

```
CLUTCH_RATE = 3
CONNECT(0,0)
WAIT UNTIL IN(1)=ON
CONNECT(6,0)
```

Registration

A machine adds glue to the top of a box by switching output 8. It must detect the rising edge (appearance) of and the falling edge (end) of a box. Additionally, it is required that the MPOS be reset to zero on the detection of the Z position.

```
reg = 6 'Select registration mode 6 (rising edge R, rising edge Z)
REGIST(reg)
FORWARD
WHILE IN(2) = OFF
  IF MARKB THEN 'On a Z mark MPOS is reset to zero
    OFFPOS = -REG_POSB 'Stores the latest position at which a registration mark was seen on each axis in user units.
    REGIST(reg)
  ELSEIF MARK THEN 'On R input output 8 is toggled
    IF reg = 6 THEN
      'Select registration mode 8 (falling edge R, rising edge Z)
      reg = 8
      OP(8, ON)
    ELSE
      reg = 6
      OP(8, OFF)
    ENDIF
    REGIST(reg)
  ENDIF
WEND
CANCEL
```




Registration & Windowing

It is required to detect if a component is placed on a flighted belt, so windowing is used to avoid sensing the flights. The flights are at a pitch of 120 mm and the component will be found between 30 and 90 mm. If a component is found, then an actuator is fired to push it off the belt.

```
REP_DIST = 120      'sets repeat distance to pitch of belt flights
REP_OPTION = ON
OPEN_WIN = 30       'sets window open position
CLOSE_WIN = 90      'sets window close position
REGIST(17 + 256)    'RB input registration with windowing
FORWARD             'start the belt
box_seen = 0
REPEAT
  WAIT UNTIL MPOS < 60 'wait for center point between flights
  WAIT UNTIL MPOS > 60 'so that actuator is fired between flights
  IF box_seen = 1 THEN 'was a box seen on the previous cycle?
    OP(8, ON)          'fire actuator
    WA(100)
    OP(8, OFF)         'retract actuator
    box_seen = 0
  ENDIF
  IF MARKB THEN box_seen = 1 'set "box seen" flag
  REGIST(17 + 256)
UNTIL IN(2) = OFF
CANCEL              'stop the belt
WAIT IDLE
```

TOUCH PROBE



470 x 318

Parameter:

axis:	Axis to superimpose. -1 breaks the link with the other axis.
-------	---

The ADDAX command sums the movements in encoder edge units.

Using ADDAX on axis with different [UNITS](#) ,
axis 0 will move $1 * 1000 + 2 * 20 = 1040$ edges.

UNITS AXIS(0) = 1000


UNITS AXIS(1) = 20

'Superimpose axis 1 on axis 0

ADDAX(1) AXIS(0)

MOVE(1) AXIS(0)

MOVE(2) AXIS(1)




The ADDAX command is used to superimpose 2 or more movements to build up a more complex movement profile

Pieces are placed randomly onto a continuously moving belt and further along the line are transferred to a second flighted belt. A detection system gives an indication as to whether a piece is in front of or behind its nominal position, and how far.

```
expected = 2000 'Sets expected position
BASE(0)
ADDAX(1)
CONNECT(1, 2) 'Continuous geared connection to flighted belt
REPEAT
  GOSUB getoffset 'Get offset to apply
  MOVE(offset) AXIS(1) 'Make correcting move on virtual axis
UNTIL IN(2) = OFF 'Repeat until stop signal on input 2
RAPIDSTOP
ADDAX(-1) 'Clear ADDAX connection
STOP
```

Getoffset: 'Subroutine to register the position of the
'piece and calculate the offset


```
BASE(0)
REGIST(3)
WAIT UNTIL MARK
seenat = REG_POS
offset = expected - seenat
RETURN
```



ADDAX + RGIST

An XY marking machine must mark boxes as they move along a conveyor. Using [CONNECT](#) enables the X marking axis to follow the conveyor. A virtual axis is used to program the marking absolute positions; this is then superimposed onto the X axis using ADDAX.

```
ATYPE AXIS(3) = 0 'Set axis 3 as virtual axis
SERVO AXIS(3) = ON
DEFPOS(0) AXIS(3)
ADDAX (3) AXIS(0) 'Connect axis 3 requirement to axis 0
WHILE IN(2) = ON
  REGIST(3) 'Registration input detects a box on the conveyor
  WAIT UNTIL MARK OR IN(2) = OFF
  IF MARK THEN
    CONNECT(1, 2) AXIS(0) 'Connect axis 0 to the moving belt
    BASE(3, 1) 'Set the drawing motion to axis 3 and 1
    'Draw the M
    MOVEABS(1200, 0) 'Move A > B
    MOVEABS(600, 1500) 'Move B > C
    MOVEABS(1200, 3000) 'Move C > D
    MOVEABS(0, 0) 'Move D > E
    WAIT IDLE
    BASE(0)
    CANCEL 'Stop axis 0 from following the belt
    WAIT IDLE
    MOVEABS(0) 'Move axis 0 to home position
  ENDIF
WEND
CANCEL
```




MOVELINK

A flying shear cuts a long sheet of paper into cards every 160 m whilst moving at the speed of the material. The shear can travel up to 1.2 m of which 1 m is used in this example. The paper distance is measured by an encoder; the unit conversion factor being set to give units of meters on both axes: (Note that axis 7 is the link axis)

```
WHILE IN(2) = ON
  MOVELINK(0, 150, 0, 0, 7)      'Dwell (no movement) for 150m
  MOVELINK(0.3, 0.6, 0.6, 0, 7)  'Accelerate to paper speed
  MOVELINK(0.7, 1.0, 0, 0.6, 7)  'Track the paper then decelerate
  WAIT LOADED 'Wait until acceleration movelink is finished
  OP(8, ON) 'Activate cutter
  MOVELINK(-1.0, 8.4, 0.5, 0.5, 7) 'Retract cutter back to start
  WAIT LOADED
  OP(8, OFF) 'Deactivate cutter at end of outward stroke
WEND
```

Syntax:

```
MOVELINK (distance, link_dist, link_acc, link_dec, link_axis[, link_options[, link_pos[, base_dist]]]).
```





PSWITCH

Imagine the same situation as in Example 1, where output 11 must give a falling edge signal to the “cam switch” system, so that the output must be off from 80° after TDC for a period of 120°.

The values for all the PSWITCH parameters:

```
axis_number = 0  
op_number = 11  
op_state = OFF  
setpos = 80 ' degrees after TDC  
reset_pos = setpos + 120 ' degrees
```


```
PSWITCH(24,ON,axis_number,op_number,op_state,setpos,reset_pos)
```




FRAME - ROBOT

A FRAME is a transformation which enables the user to program in one coordinate system when the machine or robot does not have a direct or one-to-one mechanical connection to this coordinate system.


FRAME=1, 2 axis SCARA



FRAME=2, XY single belt




FRAME=10, Cartesian to Polar




FRAME - ROBOT


FRAME=13, Dual arm Parallel




FRAME=14, Delta Robot




FRAME=15, 4 axis SCARA




FRAME = 16, 3 Axis Robot with 2 Axis Wrist



FRAME=17, Multi-wire camera




FRAME 119 (Draft)



Companies Overview

“TRIO and ESTUN”

ESTUN
AUTOMATION





Thank You

Reza Marzban

Business Development Specialist

Iranieq Co.

www.iranieq.com